MPX-802

QFX

WHERE THE PARTY BEGINS™

INSTRUCTION MANUAL

QFX

MPX-802 SAFETY

SAFETY
WARNING: THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN.
To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers, Close only with a dry cloth. Unit should and/or extra safety and/or all precautions as they are stated.

LA SEGURIDAD
ADVERTENCIA: EL RIESGO DE DESCARGA ELÉCTRICA, NO QUITE LA CUBIERTA DE ESTE ALTAVOZ. NO HAY PARTES DEMANDA EL POSEE LEGAMIN ADENTRO. CONSULTE TODOS LOS SERVICIOS A UNTECNICO CUALIFICADO.
Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia o la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor, tiempo adicional y/o adicional y/o todas las precauciones como se requerido adicional y/o requerido adicional y/o todas las precauciones tal como se indican.

SÉCURITÉ
AVERTISSEMENT: LE RISQUE D'ELECTROCUTION, NE RETIREZ PAS LE COUVERCLE DE CETTE ENCEINTE. IL NY A AUCUNE PIÈCE REPARABLE PAR L'UTILISATEUR À L'INTÉRIEUR. FAITES TOUJOURS REPARER PAR UN TECHNICIEN QUALIFIÉ.
Pour éviter un incendie ou un choc électrique, n'exposez pas cet équipement à la pluie ou à l'humidité. Ne stockez pas ou n'utilisez pas ce produit à proximité de liquides, de sources de chaleur comme les radiateurs, les registres de chaleur, le temps supplémentaire et/ou les précautions supplémentaires et/ou toutes les précautions telles qu'elles sont indiquées.

QFX

MPX-802 GUIDE

FUNCTIONS
1 **MIC:** Microphone input jack
2 **MODE:** Press to toggle AUX, USB, TF, FM or BT Modes
3 **VOL:** Rotate to adjust the volume level of the speaker
4 **Play/ Pause:** Press to play or pause music track
5 **NEXT/ Vol+:** Press to select Next Track on Radio Station
6 **Vol-:** Decrease volume
7 **Volume Knob/ Bass and Treble Control:** Rotate
8 **Power ON/OFF:** Power
9 **USB:** USB Port for USB Flash Drive Playback
10 **USB:** USB Port for Charging
11 **AUX IN:** 3.5mm Aux Input Jack to Connect to External Audio Source
12 **POWER:** DC 9V Charging input
13 **TF:** Micro SD card slot

FUNCTIONS
14 **MIC:** Microphone input jack
15 **MODE:** Presione para seleccionar la entrada, AUX, USB, TF, FM o BT
16 **PRESIÓN:** Presione para alternar entre reproducir y pausar la pista de música
17 **Siguiente/ Vol+:** presione para seleccionar pista siguiente de estación de radio
18 **Vol-:** disminuir el volumen
19 **Volumen Perilla de control/ Bass subiendo/ control:** girar
20 **Encendido/apagado:** Poder
21 **USB:** Puerto USB para reproducir memoria USB
22 **USB:** Puerto USB para reproducir memoria USB
23 **AUX IN:** 3.5mm Aux Input Jack to Connect to External Audio Source
24 **POWER:** Entrada de carga CC 9V
25 **TF:** Ranura para tarjeta micro SD

QFX

MPX-802 OPERATION

POWER SOURCE
1. Charge the unit at least four hours prior to first use and then recharge it as needed in the future.
2. Turn the Power knob to turn on power on/off.

CHARGE THE BATTERY
Plug the USB charging cable into the charging port. When charging, the charging indicator light shows red and turns off when fully charged.
1. Securely connect the usb charging cable to the charging port of the speaker.
2. After the battery is fully charged, disconnect the charging cable from the charging port of the speaker.

BLUETOOTH OPERATION
1. Press the MODE button to toggle to FM mode.
2. Press and hold the PLAY/PAUSE button on the control panel to automatically the FM radio.
3. Then press PREVIOUS or NEXT to select and then to saved radio stations.

BLUETOOTH
1. Press the MODE button to toggle to Bluetooth (BT) mode.
2. Open the Bluetooth setting on your phone, tablet or any other Bluetooth-enabled audio device and select "MPX802".
3. The unit and device will then connected via Bluetooth.

MPX-802 TRUE WIRELESS STEREO (TWS)
True Wireless Stereo (TWS) allows for two speakers of the same model to connect wirelessly in stereo. You will need two MPX-802 speakers in order for TWS operation to function. **To set up TWS:**
1. Turn on both mini-XL speakers, toggle the MODE button to BLUETOOTH mode on both speakers.
2. To set up TWS speakers, hold/ button on either speaker for 3 seconds. Then both speakers will connect together.
3. Next, connect your Bluetooth device (phone/tablet/laptop) to the speaker. Go to your phone/Bluetooth settings, search and connect to Bluetooth name "MPX802".
4. Connect your audio source to the "MPX802" speaker. Audio will stream from your phone and enjoy Two Wireless Stereo audio with the two MPX-802 speakers.
5. To exit TWS mode, long press the PLAY/ ⏯ button for 3 seconds to exit TWS.

FUENTE DE ALIMENTACIÓN
1. Cargue la unidad al menos cuatro horas del primer uso y luego recárgala según sea necesario en el futuro.
2. Mantenga presionado el botón de ENCENDIDO para encender/apagar.

CARGA LA BATERÍA
Conecte el cable de carga USB al puerto de carga. Durante la carga, la luz indicadora de carga se iluminará en rojo y se apagará cuando esté completamente cargada.
1. Conecte de forma segura el cable de carga USB al puerto de carga del altavoz.
2. Después de que la batería esté completamente cargada, desconecte el cable de carga del puerto de carga del altavoz.

FUNCIÓN FM
1. Presione el botón MODE para cambiar a modo FM.
2. Mantenga presionado el botón PLAY/PAUSE en el panel de control para escanear automáticamente la radio FM.
3. Luego presione PREVIOUS o SIGUIENTE para seleccionar y escuchar las estaciones de radio guardadas.

BLUETOOTH
1. Presione el botón MODE para cambiar al modo Bluetooth (BT).
2. Abra la configuración de Bluetooth en su teléfono, tableta o cualquier otro dispositivo de audio habilitado para Bluetooth y seleccione "MPX-802".
3. La unidad y el dispositivo se conectarán a través de Bluetooth.

QFX

MPX-802 OPERATION

MPX-802 ESTÉREO REAL INALÁMBRICO VERDADERO (TWS)
Con True Wireless Stereo (TWS), puede conectar dos altavoces de mini-XL del mismo modelo de forma inalámbrica en estéreo. Necesitará dos altavoces MPX-802 para que funcione el funcionamiento TWS.
Para configurar TWS:
1. Encienda ambos altavoces MPX-802, cambie el botón MODE en ambos BLUETOOTH en ambos altavoces.
2. Para configurar el funcionamiento de TWS, presione el botón TWS en un solo altavoz durante 3 segundos. Luego, ambos altavoces se conectarán entre sí.
3. A continuación, conecte su teléfono con Bluetooth (o dispositivo) a uno de los altavoces (por ejemplo, su teléfono, laptop y cualquier otro dispositivo de Bluetooth "MPX-802".
4. Conecte su fuente de audio al altavoz "MPX-802". El audio se transmitirá desde su teléfono y disfrutar del audio estéreo inalámbrico a través de los dos altavoces MPX-802.
5. Para salir del modo TWS, mantenga presionado el botón PLAY ⏯ TWS durante 3 segundos para salir del TWS.

FUENTE DE ENERGÍA
1. Cargar Capacitad es mejor antes de usarlo por primera vez y luego recárgarlo según sea necesario en el futuro.
2. Apagado el interruptor de encendido/apagado.

BLUETOOTH
1. Enciende el altavoz MPX-802 y pulsar en modo Bluetooth (BT).
2. Enciende tu pantalla Bluetooth en tu teléfono, tableta u otro dispositivo habilitado para Bluetooth y seleccione "MPX-802".
3. Conectado a BT" aparecerá en la pantalla de tu teléfono.

MPX-802 VERDADERO ESTÉREO SIN HILO (TWS)
Tres Wireless Stereo (TWS) permite el doce encontrar de mitre mediante de un conector sans fil en stéréo. Vous aurez besoin de deux haut-parleurs MPX-802 pour que le fonctionnement TWS fonctionne. Pour configurer TWS:
1. Allumez les deux haut-parleurs MPX-802, basculez le bouton MODE en mode BLUETOOTH sur les deux haut-parleurs.
2. Pour configurer le fonctionnement TWS, appuyez sur le bouton TWS d'un seul haut-parleur pendant 3 secondes.
Ensuite, les deux enceintes se connectent ensemble.
3. Ensuite, connectez votre téléphone compatible Bluetooth au haut-parleur. Accédez aux paramètres de votre téléphone/Bluetooth, recherchez et connectez-vous à Bluetooth nommé "MPX802".
4. Une fois la connexion établie, vous pouvez diffuser de la musique depuis votre téléphone et profiter d'un véritable son stéréo sans fil via les deux haut-parleurs MPX-802.
5. Pour quitter le mode TWS, appuyez longuement sur le bouton PLAY ⏯ TWS pendant 3 secondes pour quitter TWS.

QFX

LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under the Warranty, doesn't, read the instructions and set-up and troubleshooting section of the Product's owner's manual. Contact Customer Service at 1-800-664-1458 (Mon-Fri, 8:00 am-5:00 pm Central Time) or visit the QFX Customer Support Department at www.qfxusa.com.

Subject to the terms and conditions herein, QFX, Inc. (hereinafter called "QFX") warrants the original purchaser of the Product (hereinafter called "Purchaser") that for a period of one year from the date of the original purchase of the Product (hereinafter called "Warranty Period") QFX will repair or replace the Product, at QFX's sole option, free of charge, provided that the Product is installed and operated in accordance with all instructions supplied by QFX and not subjected to misuse, abuse, accidents, alterations, neglect, excessive moisture, or improper voltage.

Except for the express warranties stated in this Limited Product Warranty Policy, QFX disclaims all other warranties, whether oral or written, including, without limitation, any implied warranties of merchantability or fitness for a particular purpose. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This warranty gives you specific legal rights and you may have other rights which may vary from jurisdiction to jurisdiction.

Copyright Protected 2018©

QFX Inc.
Customer Support Department
2977 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(800) 664-1458 (CST) | (323) 604-0900
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destination excluding, Hawaii, Alaska and Canada. Shipping charges, handling charges and HDX/LX deviations, please contact the QFX Customer Service Department for a quote before shipping the product.

If you do not find your Product/Unit/ your Product model certifies in the multiple categories, and/or are unsure of which category the Product you have purchased falls into please contact Customer Support Department for assistance before shipping.

In order to determine the exact Product/Unit/ your Product model certifies you must contact QFX and provide proof of purchase to the product being returned, please refer to the table below. Failure to provide proof of purchase will result in the Product being returned to the customer without any refund to your customer for mistreatment, improper shipping, and/or any other reasons/conditions mentioned in the above text.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping costs for your item is, or if your item category and/or the item's dimensions, please contact the QFX Support Department for further assistance.

Product Category	Warranty	Labor	Shipping
Keyboards, Instruments, Photo/Pro/Pro, & Small Bluetooth Speakers	1 Year	1 Year	1 Year
Portable Audio/Cassette	$30.00	1 Year	1 Year
Large Portable Audio/Cassette	$50.00	1 Year	1 Year
Home Audio/Stereo	$50.00	1 Year	1 Year
Pro Audio/DJ Mixers	$75.00	1 Year	1 Year
Pro Audio/PA Systems	$75.00	1 Year	1 Year
Turntables	$50.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND INCLUDE ALL OTHERS EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU. THE WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION. IN NO EVENT SHALL QFX BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO, ANY LOST PROFITS OR LOSS OF BUSINESS, LOSS OF DATA OR SUBSTITUTE GOODS, REGARDLESS OF THE FORM OF ACTION WHETHER IN CONTRACT, TORT, NEGLIGENCE, STRICT LIABILITY OR OTHERWISE. NO PERSON OR FIRM IS AUTHORIZED TO ENLARGE OR ALTER THE TERMS OF THIS WARRANTY. NO PERSON OR FIRM IS AUTHORIZED TO MAKE ANY OTHER WARRANTY OR REPRESENTATION ON BEHALF OF QFX. THIS WARRANTY DOES NOT COVER DAMAGES, INCLUDING, BUT NOT LIMITED TO, THOSE RESULTING FROM IMPROPER OR INADEQUATE MAINTENANCE, ACCIDENT, MISUSE, ABUSE, NEGLIGENCE, IMPROPER INSTALLATION, CELLULAR NON-REPRESENTATIVE OR THIRD PARTY REPAIRS, ETC. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, EXCLUDED DAMAGES, INCLUDING, BUT NOT LIMITED TO, THOSE RESULTING FROM IMPROPER OR INADEQUATE MAINTENANCE, ACCIDENT, MISUSE, ABUSE, NEGLIGENCE, IMPROPER INSTALLATION, CELLULAR NON-REPRESENTATIVE OR THIRD PARTY REPAIRS, ETC. LOSS OR DAMAGE TO OTHER DATA OR SOFTWARE