PBX-63

QFX

WHERE THE PARTY BEGINS™

INSTRUCTION MANUAL

PBX-63说明书2025.9.9　　尺寸：宽127mmX高190mm

PBX-63 SAFETY / SEGURIDAD / SÉCURITÉ

QFX

SAFETY

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN.
To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers, Clean only with a dry cloth. Users should exhibit extra safety and fallow all precautions as they are stated.

LA SEGURIDAD

PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO QUITE LA CUBIERTA DE ESTE ALTAVOZ. NO HAY PARTES REPARABLES POR EL USUARIO. CONSULTE TODOS LOS SERVICIOS A UN TÉCNICO CALIFICADO.
Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia ni a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor. Limpie solamente con un paño seco. Los usuarios deben exhibir una seguridad adicional y seguir todas las precauciones tal como se indican.

SÉCURITÉ

POUR RÉDUIRE LE RISQUE D'ÉLECTROCUTION, NE RETIREZ PAS LE COUVERCLE DE CETTE ENCEINTE. IL NY A AUCUNE PIÈCE RÉPARABLE PAR L'UTILISATEUR À L'INTÉRIEUR. RÉFÉREZ TOUTE RÉPARATION À UN RÉPARATEUR QUALIFIÉ.
Pour éviter un incendie ou un choc électrique, n'exposez pas cet équipement à la pluie ou à l'humidité. Ne stockez pas ou n'utilisez pas ce produit à proximité de liquides, de sources de chaleur telles que des radiateurs, des registres de chaleur. Nettoyez uniquement avec un chiffon sec. Les utilisateurs doivent faire preuve de plus de sécurité et suivre toutes les précautions telles qu'elles sont indiquées.

REMOTE CONTROL / CONTROL REMOTO / TÉLECOMMANDE

1. Press to turn the unit ON and OFF/ Presione para encender y apagar la unidad/ Appuyez pour allumer et éteindre l'appareil/ Appuyez pour allumer et éteindre l'appareil
2. USB/SD/LINEA/AZUL/AUX
3. Canción anterior/FM CH-
4. Reproducir/Pausar/Sintonizador FM
5. Siguiente canción/FM CH+
6. Repetir
7. Stop
8. Volume Increase
9. Volume Decrease
10. Mute
11. Preset EQ Modes
12. Number Keys

*Mantenga el interruptor de alimentación de la unidad está encendida.

1. Appuyez pour allumer et éteindre l'appareil/ USB/SD/LIGNE/BLEU/AUX
2. Chanson précédente/FM CH-
3. Lecture/Pause/Tuner FM
4. Chanson suivante/FM CH+
5. Répéter
6. Arrêt
7. Augmentation du volume
8. Diminution du volume
9. Muet
10. Modes d'égalisation préréglés
11. Touches numériques

*Longue l'interrupteur d'alimentation de l'unité est allumé.

PBX-63 GUIDE / GUÍA / GUIDE

QFX

FUNCTIONS
1. POWER: 110-220VAC power input.
2. AUX IN: Extra input connection for audio devices.
3. USB & TF: USB port and TF card slot.
4. Display: LED screen displays current mode and rechargeable battery indicator.
5. MODE: Press to toggle to BT, FM, USB/TF, AUX. Press and hold to change lights.
6. PREV: Press to select previous music track or radio station.
7. PLAY: Press to start/stop/pause music playback. See TWS instruction for TWS button function.
8. NEXT: Press to select next music track or radio station.
9. Press to prioritize the sound level of the microphone over the music sound level.
10. Press to record the microphone and to playback recordings.
11. Battery indicator.
12. Microphone input
13. Switch to turn lights ON or OFF.
14. Power ON and OFF switch.
15. Speaker wire connect.
16. Treble sound control.
17. Bass sound control.
18. Microphone echo control.
19. Microphone delay control.
20. Microphone volume control.

FUNCIONES
1. ALIMENTACIÓN: Entrada de alimentación 110-220VAC.
2. AUX IN: Entrada para conectar dispositivos de audio externos.
3. USB & TF: Puerto USB y entradas para ranura para tarjeta TF.
4. Pantalla: La pantalla LED muestra el modo actual y el indicador de batería recargable.
5. MODO: Presione para alternar entre BT, FM, USB/TF, AUX. Mantenga presionado para cambiar las luces.
6. PREV: Presione para seleccionar la pista de música o estación de radio anterior.
7. REPRODUCIR: presione para reproducir o pausar la reproducción de música. Consulte las instrucciones de TWS para conocer la función del botón TWS.
8. SIGUIENTE: presione para seleccionar la siguiente pista de música o estación de radio.
9. Presione para priorizar el nivel de sonido del micrófono sobre el nivel de sonido de la música.
10. Presione para grabar el micrófono y reproducir la grabación.
11. Indicador de batería.
12. Entrada de micrófono
13. Cambia para encender o apagar las luces.
14. Interruptor de encendido y apagado.
15. Control de volumen del altavoz.
16. Control de sonido triple.
17. Control de sonido de graves.
18. Control de eco del micrófono.
19. Control de retardo del micrófono.
20. Control de volumen del micrófono.

FONCTIONS
1. PUISSANCE : entrée d'alimentation 110-220VAC.
2. AUX IN : Entrée pour connecter des appareils audio externes.
3. USB et TF : ports USB et entrées pour emplacement pour carte TF.
4. Affichage : l'écran LED affiche le mode actuel et l'indicateur de batterie rechargeable.
5. MODE : Appuyez pour basculer entre BT, FM, USB/TF, AUX. Appuyez et maintenez pour changer de lumière.
6. PREV : Appuyez pour sélectionner la piste musicale ou la station de radio précédente.
7. PLAY : Appuyez pour lire ou mettre en pause la lecture de musique. Voir les instructions TWS pour la fonction du bouton TWS.
8. SUIVANT : Appuyez pour sélectionner la piste musicale ou la station de radio suivante.
9. Appuyez pour donner la priorité au niveau sonore du microphone par rapport au niveau sonore de la musique.
10. Appuyez pour enregistrer le microphone et lire l'enregistrement.
11. Indicateur de batterie.
12. Entrée micro
13. Interrupteur pour allumer ou éteindre les lumières.
14. Interrupteur marche/arrêt.
15. Contrôle du volume du haut-parleur.
16. Contrôle des aigus.
17. Contrôle du son des basses.
18. Contrôle de l'écho du microphone.
19. Contrôle du retard du microphone.
20. Contrôle du volume du microphone.

PBX-63 OPERATION / OPERACIÓN / OPÉRATION

QFX

POWER SOURCE
1. Charge the unit at least four hours prior to first use and then recharge it as needed in the future.
2.Turn the Power knob to turn on power on/off.

CHARGE THE BATTERY
1.Plug the AC power cable into the charging port. When charging, the charging indicator light shows red and turns off when fully charged.
1.Securely connect the AC power cable to the charging port of the speaker.
2.After the battery is fully charged, disconnect the AC power cable from the charging port of the speaker.

FM FUNCTION
1. Press the MODE button to toggle to FM mode.
2. Press the PLAY/PAUSE button on the control panel to automatically the FM radio.
3. Then press PREVIOUS or NEXT to select and listen to saved radio stations.

BLUETOOTH
1. Press the MODE button to toggle to Bluetooth (BT) mode.
2. Open the Bluetooth setting on your phone, tablet or other Bluetooth-enabled audio device and select **"PBX-63"**
3. The unit and device will then connected via Bluetooth.

PBX-63 TRUE WIRELESS STEREO (TWS)
True Wireless Stereo (TWS) allows for two speakers of the same model to connect wirelessly in stereo. You will need two **PBX-63** speakers in order for TWS operation to function. **To set up TWS**
1. Turn on both **PBX-63** speakers, toggle the MODE button to BLUETOOTH mode on both speakers.
2. To set up TWS operation, press the TWS button on only one speaker for 3 seconds. Then both speakers will connect automatically.
3. Next, connect your Bluetooth-enabled phone to the speaker. Go to your phone Bluetooth settings, search and connect to Bluetooth name **"PBX-63"**
4. Once the connection has been established, you can play music from your phone and enjoy True Wireless Stereo audio playing through your two **PBX-63** speakers.
5. To exit TWS mode, long press the PLAY ►II TWS button for 3 seconds to exit TWS.

FUENTE DE ALIMENTACIÓN
1.Cargue la unidad al menos cuatro horas antes del primer uso y luego recárguela según sea necesario en el futuro.
2. Mantenga presionado el botón de ENCENDIDO para encender/apagar

CARGA LA BATERÍA
Conecte el cable de alimentación de CA al puerto de carga; durante la carga, la luz indicadora de carga se ilumina en rojo y se apaga cuando está completamente cargada.
1. Conecte de forma segura el cable de alimentación de CA al puerto de carga del altavoz.
2. Después de que la batería esté completamente cargada, desconecte el cable de alimentación CA del puerto de carga del altavoz.

FUNCIÓN FM
1. Presione el botón MODO para cambiar al modo FM.
2.Presione y mantenga presionado el botón REPRODUCIR/PAUSA en el panel de control para escuchar automáticamente la radio FM.
3.Luego presione ANTERIOR o SIGUIENTE para seleccionar y escuchar las estaciones de radio guardadas.

BLUETOOTH
1.Presione el botón MODE para cambiar al modo Bluetooth (BT).
2.Abra la configuración de Bluetooth en su teléfono, tableta o cualquier otro dispositivo de audio habilitado para Bluetooth y seleccione **"PBX-63"**.
3.La unidad y el dispositivo se conectarán a través de Bluetooth.

PBX-63 OPERATION / OPERACIÓN / OPÉRATION

QFX

PBX-63 ESTÉREO INALÁMBRICO VERDADERO (TWS)
True Wireless Stereo (TWS) permite que dos altavoces del mismo modelo se conecten de forma inalámbrica en estéreo. Necesitará dos altavoces **PBX-63** para que funcione la operación TWS. **Para configurar TWS:**
1. Encienda ambos altavoces **PBX-63**, cambie el botón MODE al modo BLUETOOTH en ambos altavoces.
2. Para configurar el funcionamiento de TWS, mantenga el botón TWS en un solo altavoz durante 3 segundos. Entonces ambos altavoces se conectarán entre sí.
3.A continuación, conecte su teléfono con Bluetooth al altavoz. Vaya a la configuración de Bluetooth de su teléfono, busque y conéctese al nombre de Bluetooth **"PBX-63"**
4.Una vez que se haya establecido la conexión, podrá reproducir música desde su teléfono y disfrutar del audio estéreo inalámbrico verdadero a través de sus dos parlantes **PBX-63**.
5.Para salir del modo TWS, mantenga presionado el botón PLAY ►II TWS durante 3 segundos para salir de TWS.

SOURCE D'ÉNERGIE
1.Chargez l'appareil au moins quatre heures avant la première utilisation, puis rechargez-le si nécessaire ultérieurement.
2. Appuyez et maintenez enfoncé le bouton POWER pour allumer/éteindre.

CHARGER LA BATTERIE
Branchez le câble d'alimentation CA dans le port de charge. Lors du chargement, le voyant de charge s'allume en rouge et s'éteint lorsqu'il est complètement chargé.
1. Connectez solidairement le câble d' alimentation CA au port de charge du haut-parleur.
2. Une fois la batterie complètement chargée, débranchez le câble d'alimentation secteur du portde charge de l'enceinte.

FONCTION FM
1.Appuyez sur le bouton MODE pour passer en mode FM.
2.Appuyez et maintenez enfoncé le bouton PLAY/PAUSE du panneau de commande pour activer automatiquement la radio FM.
3.Appuyez ensuite sur PREVIOUS ou NEXT pour sélectionner et écouter les stations de radio enregistrées.

BLUETOOTH
1.Appuyez sur le bouton MODE pour passer en mode Bluetooth (BT).
2.Ouvrez les paramètres Bluetooth sur votre téléphone, tablette ou tout autre appareil audio compatible Bluetooth et sélectionnez **"PBX-63"**
3. L'appareil et l'appareil seront ensuite connectés via Bluetooth.

PBX-63 VÉRITABLE STÉRÉO SANS FIL (TWS)
True Wireless Stereo (TWS) permet à deux enceintes du même modèle de se connecter sans fil en stéréo. Vous aurez besoin de deux haut-parleurs **PBX-63** pour que le fonctionnement TWS fonctionne. Pour configurer TWS:
1.Allumez les deux haut-parleurs **PBX-63**, basculez le bouton MODE en mode BLUETOOTH sur les deux haut-parleurs.
2.Pour configurer le fonctionnement TWS, appuyez sur le bouton TWS d'un seul haut-parleur pendant 3 secondes.
Ensuite, les deux enceintes se connecteront ensemble.
3.Ensuite, connectez votre téléphone compatible Bluetooth au haut-parleur. Accédez aux paramètres Bluetooth de votre téléphone, recherchez et connectez-vous au nom Bluetooth **"PBX-63"**
4. Une fois la connexion établie, vous pouvez écouter de la musique depuis votre téléphone et profiter d'un véritable son stéréo sans fil via vos deux haut-parleurs **PBX-63**.
5. Pour quitter le mode TWS, appuyez longuement sur le bouton PLAY ►II TWS pendant 3 secondes pour quitter TWS.

QFX

LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (1) read the information manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (2) If you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period is unique to, listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer's purchase of the Product, unless a different Coverage Period is specified in writing by an authorized Warranty provider. During the applicable Warranty Period, QFX will, at its options, during normal business hours, repair or replace the Product, or any component thereof, in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's sole and exclusive remedy and QFX's sole liability for breach of the warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of **misuse, abuse, immoderate in liquids, improper** installation, modification, improper repair, improper packaging, or improper shipping. QFX is not responsible for Defects in the Product or damage to the Product caused by: (a) accidents, improper installation, improper use, misuse, abuse, neglect, or failure to properly maintain the Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from; (b) any logo(s) or mount by Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial numbers; (c) any modification or repair to Product (or, as applicable, any component thereof) by any person other than QFX or a party authorized in writing by QFX; (d) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunctioning device attached to the Product (or, as applicable, any component thereof); (e) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (g) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, or extreme temperatures; or other conditions beyond the control of QFX.

Products sold for commercial, rental, or other non-consumer purposes ("Commercial Purposes") are not covered by Customer's commercial or rental use. In addition, Product is not covered under this warranty if: (a) Product has been used for Commercial Purposes; (b) Product is rented; (c) Product is used for Commercial Purposes; (d) Product is used in a manner otherwise than as intended by the Product's manufacturer; (e) Product is used in a manner that is contrary to the Product's rated capacity; (f) Product has been altered or otherwise compromised; or (g) the date stamped on Product's rated capacity has been altered or otherwise compromised. Any of the foregoing uses by the Customer shall be deemed a material breach of the Product's rated capacity for which QFX shall have no liability for breach of the warranty contained herein.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS". AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR (a) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS; TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL QFX BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, INDIRECT, SPECIAL, PUNITIVE, OR EXEMPLARY DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THE CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the following information: (1) a copy of the original sales receipt showing the purchase price, purchase date, and the place of purchase; (2) a description of the Product and the serial number (if any); (3) a detailed description of Customer's problem with Product; (4) Customer's full name, phone number, and return address; (5) all of the accessories that came with the Product package must be sent along with the main Product; (6) a cashier's check or money order payable to QFX, Inc., or the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, please contact QFX Customer Support Department for further instruction. Customer is responsible for all shipping charges to QFX for the Product. QFX is NOT RESPONSIBLE FOR LOSS OR DAMAGE TO RETURNED PRODUCTS. If returned Product(s) found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street 1, Vernon, CA 90058

support@qfxusa.com
(800) 884-0148 (TAEC) or (323) 417-9900
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return in the category or model number grids. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back any item. If you are not sure about the shipping cost for your item, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth Speakers	$5.00	1 Year	1 Year
Personal Stereos	$10.00	1 Year	1 Year
Portable Radio/Cassette	$15.00	1 Year	1 Year
Large Portable Radio Cassette	$20.00	1 Year	1 Year
Mobile Audio	$10.00	1 Year	1 Year
Pro Audio SBK Systems	$75.00	1 Year	1 Year
Pro Audio PBX Systems	$75.00	1 Year	1 Year
Televisions	$25.00	1 Year	1 Year
Telephones	$10.00	1 Year	1 Year
Stand Fans	$20.00	1 Year	1 Year
Portable Rechargeable Fans	$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT AND FITNESS FOR A PARTICULAR PURPOSE. SOME LEGAL JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. EXCEPT AS SPECIFICALLY SET FORTH IN THIS WARRANTY, QFX MAKES NO OTHER EXPRESS WARRANTIES OR WHERE ARE LEGAL LIMITS ARE PLACED, EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025 ©

1-800-884-2592
Mon-Fri 9AM - 5PM (PST)

support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)

www.qfxusa.com

FCC Statement
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

THANK YOU.

QFX Where the Party Begins!
We would love to hear about your PBX-63 Journey!
Tag us @QFXUSA to share your stories.

FOLLOW US @QFXUSA