

#### (4)FM Radio

Press  to enter into FM radio mode, press SCAN to enter into radio program automatic scan. Press ◀▶ for radio program manual scan, ▲▼ Top and bottom trimming, Turn the TUNER button radio station can be adjusted. Slide around to adjust radio frequency between 87.5MHz~108.0MHz.

#### (5) Bluetooth connection

Press  to enter into Bluetooth Control connection page, then click "Speaker Pro BLE" to connect to the speaker.

#### (6)Line In input - mute

Press  to enter into Line IN input page, press  to mute music, press  insert a line continue play. Press "Back" to main page.

#### (7) Equalizer regulation

Press  to enter into Sound Set page, and then turn volume or bass or treble to adjust the volume. There are 4 pre-set EQ modes: dance, Classical, Jazz and Rock. You can also press G-Eq to access the graphic equalizer to set up your preferred equalize specification.



(4)

(5)

(6)

(7)

#### FM Operation

Lightly press Power/Input button to switch to FM mode, long press PLAY/PAUSE button to automatically scan radio station, by pressing PREVIOUS or NEXT you can select a previous or next song.

#### Bluetooth:

Press the POWER/INPUT button on the panel control to select Bluetooth mode. Simultaneously open the Bluetooth setting on your phone, tablet or any other Bluetooth enabled audio device and select "QFX PBX-1211". The unit and device will then connect via Bluetooth. To control the device via your phone, tablet etc please download the App "Speaker Pro".

Once the unit and device are connected via Bluetooth, open the "Speaker Pro" App on your phone, tablet etc and press the Bluetooth button. This will enable you to control the following five modes on the device from your phone: Music, Light, USB Card, Bluetooth and Equalizer. To cancel the app, press the exit button.

#### Specifications:

Power: 20W  
Frequency Response for main speaker: 55Hz-20KHz  
Power Supply: DC9V


# QFX

## PORTABLE BATTERY SPEAKER

### User Manual PBX-1211



## PANEL LAYOUT & FUNCTIONS




- 1.LED display.
- 2.POWER/INPUT button.
- 3.TWS Wireless Bluetooth Connection
- 4.Brightness of LED light mode button
- 5.Bass/Treble/Mic/VOLUME: Master volume adjustment&Menu selection button&PUSH knob enter menu.
- 6.LINE IN.
- 7.USB: USB Player/Power Bank 5V 1A output
- 8.MIC: Microphone signal input.
- 9.Previous song.
- 10.Play/Pause (In FM mode,hold for 3 seconds the device will enter into automatic scan).
- 11.Next song.
- 12.LED CHARGE STATUS:  
RED = Charging  
GREEN = Fully charged
- 13.DC 9V external input.

## BASIC OPERATION

1. POWER/INPUT button: long press POWER/INPUT button for about 3 seconds, the machine displays "HI" and then "bLUE" to start; long press POWER/INPUT button for about 3 seconds and the machine turns off. During working state, short press POWER/INPUT button to select the mode, the sequence is USB (when USB device is connected), FM, LINE, BT.
2. Bass/Treble/Mic/VOLUME: adjust volume; PUSH knob enter menu: turn left and right to adjust the volume from 0 to 30. To press and then turn left and right, you can adjust the Treble and Bass volume, Microphone volume, and switch 12 kinds of Light Modes.
3. PLAY/PAUSE: to play or pause the music. During FM state, long press PLAY/PAUSE to automatically search radio and save.
4. PREVIOUS/NEXT: to switch the song and radio.
- 5.TWS Wireless Bluetooth Connection: under bluetooth mode, press TWS button for around 3 seconds to pairing another TWS speaker;Under FM mode, lightly press TWS to enter into automatic scan and all the scanned radio stations will be saved automatically.)  
BT pairing between a cellphone and one QFX PBX-1211 TWS speaker firstly and play music from cellphone. Turn on another QFX PBX-1211 TWS speaker and Press TWS function button, then it will play the same music you are playing in the first unit.
- 6.Brightness of LED light mode: The product has LED light brightness adjust function, press LIGHT to choose the effect.
7. USB: USB Player/Power Bank 5V 1A output.

To control the device via your phone, please find and install the app " Speaker Pro ". Open the App "Speaker Pro" on your phone, there are 7 function icons on the main page :

1. Bluetooth Music play
2. USB card play
3. Light control colour, brightness and light flash mode
4. FM Radio
5. Control Bluetooth connect
6. Line In input - mute
7. Equalizer, volume adjustment for music.



### (1) Bluetooth Music play


Press  to enter into Bluetooth Music play page, Press "Pick songs to play" to Pick Song page to choose the song you want to play, press "Done" to return to Bluetooth Music play page, also you can operate pause, play, backward, forward& volume adjustment, repeat, random play. Press "Back" to return to the main page.

### (2)USB card play

When inserting a USB into the speaker, press  to enter the USB Card play page. To choose a song and play music on the USB card, press "Play" to enter into the play control page ,where you can operate pause, play, backward, forward & volume adjustment. Press "List" to return to USB list page, press "Back" to return to the main page.

### (3) Light control colours, brightness and colour change mode

Press  to enter into Light Control page, you can select any colour to show the light colour on the speaker, as well as adjust the brightness of the light. To go back to main page, press " < " in the left corner.  
Press "Profiles" to enter into Light Effect mode page, you can choose from a total of 12 pre-set light effect modes. To return to Light Control page, press "Light" in the left corner.



(1)

(2)

(3)