


# QFX<sup>®</sup>

WHERE THE PARTY BEGINS<sup>™</sup>



## INSTRUCTION MANUAL



## FUNCTIONS:

1. USB PORT: Insert a USB with .mp3 music content for music playback.
2. TF CARD PORT: Insert a TF Card with .mp3 music content for music playback.
3. CHARGING/AUX PORT: Connect a Micro-USB to recharge the unit with a 5V, 1A min supply. Connect a mobile device with the supplied USB cable for music play back.
4. CHARGE LIGHT: The Light will turn RED when the unit is charging. When looking for Bluetooth or FM signal, the light will blink BLUE.
5. MIC INPUT: Connect a microphone using a TRS 6.35mm mic cable.
6. POWER SWITCH: Slide the switch to turn ON/OFF the unit.
7. MODE/LED BUTTON: Press to select the Bluetooth, USB/TF, or FM function. Press and hold to activate the LED lights. Press to select from 3 light modes.
8. PREVIOUS/VOLUME - : Press and hold to decrease the volume. Press to select previous track.
9. PLAY/PAUSE: Press to play or pause audio track. In FM Mode press to auto scan FM Mode. Press and hold to connect/disconnect from Bluetooth. Press and hold for TWS sync.
10. NEXT/VOLUME + : Press and hold to increase the volume. Press to select next track.
11. REM: Remote control sensor.

1. PUERTO USB: Inserte un USB con contenido de música .mp3 para la reproducción de música.
2. PUERTO DE TARJETA TF: Inserte una tarjeta TF con contenido de música .mp3 para la reproducción de música.
3. PUERTO DE CARGA / AUX: Conecte un Micro-USB para recargar la unidad con un suministro mínimo de 5V, 1A. Conecte un dispositivo móvil con el cable USB suministrado para reproducir música.
4. LUZ DE CARGA: La luz se volverá ROJA cuando la unidad se esté cargando. Cuando busque una señal de Bluetooth o FM, la luz parpadeará en AZUL.
5. ENTRADA DE MICRÓFONO: Conecte un micrófono con un cable de micrófono TRS de 6,35 mm.
6. INTERRUPTOR DE ENCENDIDO: Deslice el interruptor para encender / apagar la unidad.
7. BOTÓN MODE / LED: presione para seleccionar la función Bluetooth, USB / TF o FM. Mantenga pulsado para activar las luces LED. Presione para seleccionar entre 3 modos de luz.
8. ANTERIOR / VOLUMEN -: presione y mantenga presionado para disminuir el volumen. Presione para seleccionar la pista anterior.
9. REPRODUCCIÓN / PAUSA: presione para reproducir o pausar la pista de audio. En el modo FM, presione para buscar automáticamente el modo FM. Mantenga presionado para conectarse / desconectarse de Bluetooth. Mantenga presionado para sincronizar TWS.
10. SIGUIENTE / VOLUMEN +: presione y mantenga presionado para aumentar el volumen. Presione para seleccionar la siguiente pista.
11. REM: Sensor de control remoto.

1. PORT USB : Insérez une clé USB avec du contenu musical .mp3 pour la lecture de musique.
2. PORT DE CARTE TF : insérez une carte TF avec du contenu musical .mp3 pour la lecture de musique.
3. PORT DE CHARGE/AUX : Connectez un micro-USB pour recharger l'appareil avec une alimentation de 5V, 1 A min. Connectez un appareil mobile avec le câble USB fourni pour la lecture de musique.
4. VOYANT DE CHARGE : Le voyant deviendra ROUGE lorsque l'appareil est en charge. Lorsque vous recherchez un signal Bluetooth ou FM, le voyant clignote en BLEU.
5. MIC INPUT : connectez un microphone à l'aide d'un câble micro TRS 6,35 mm.
6. INTERRUPTEUR D'ALIMENTATION : Faites glisser l'interrupteur pour allumer/éteindre l'appareil.
7. BOUTON MODE/LED : Appuyez pour sélectionner la fonction Bluetooth, USB/TF ou FM. Appuyez et maintenez pour activer les lumières LED. Appuyez pour sélectionner parmi 3 modes d'éclairage.
8. PRÉCÉDENT/VOLUME - : Appuyez et maintenez enfoncé pour diminuer le volume. Appuyez pour sélectionner la piste précédente.
9. LECTURE/PAUSE : Appuyez pour lire ou mettre en pause la piste audio. En mode FM, appuyez pour rechercher automatiquement le mode FM. Appuyez et maintenez pour vous connecter/déconnecter de Bluetooth. Appuyez et maintenez pour la synchronisation TWS.
10. SUIVANT/VOLUME + : Appuyez et maintenez enfoncé pour augmenter le volume. Appuyez pour sélectionner la piste suivante.
11. REM : Capteur de télécommande.



1-800-864-CLUB (2582)  
Mon-Fri 9AM - 5PM (PST)



support@qfxusa.com  
Mon-Fri 9AM - 5PM (PST)

**TRUE WIRELESS STEREO (TWS)**

1. Turn ON both units and enable Bluetooth mode on both speakers. Use the mode button.
2. Press and hold the "PLAY/PAUSE/TWS" button on one of the speakers (A) until you hear a sound.
3. On your mobile device under the Bluetooth menu, search for QFX PBX-262 and connect.
4. Open your favorite music app and enjoy True Wireless Stereo.
5. To Exit MODE press and hold the TWS button.

1. Encienda ambas unidades y habilite el modo Bluetooth en ambos altavoces. Utilice el botón de modo.
2. Mantenga presionado el botón MODE en uno de los altavoces (A) hasta que escuche un sonido
3. En su dispositivo móvil en el menú de Bluetooth, busque QFX PBX-262 y conéctese.
4. Abra su aplicación de música favorita y disfrute de True Wireless Stereo.
5. Para salir de TWS, presione y mantenga presionado el botón MODE.

1. Allumez les deux unités et activez le mode Bluetooth sur les deux haut-parleurs. Utilisez le bouton mode.
2. Appuyez et maintenez enfoncé le bouton MODE sur l'un des haut-parleurs (A) jusqu'à ce que vous entendiez le son « Bluetooth Connected » (ils doivent être de la même marque et du même modèle pour fonctionner).
3. Sur votre appareil mobile, dans le menu Bluetooth, recherchez QFX PBX-262 et connectez-vous.
4. Ouvrez votre application musicale préférée et profitez de True Wireless Stereo.
5. Pour quitter TWS, appuyez sur le bouton MODE et maintenez-le enfoncé.

**HOW TO USE FM RADIO:**

1. Use the "MODE" button to enable FM mode.
2. In FM mode press the "PLAY/PAUSE" button to automatically search and store FM Channels.
3. Press next or previous button to change the saved FM Channel.

1. Presione el botón "MODE" para habilitar el modo FM.
2. En el modo FM, presione el botón "REPRODUCIR / PAUSA" para buscar y almacenar automáticamente el canal FM.
3. Presione el botón siguiente o anterior para cambiar el canal FM guardado.

1. Appuyez sur le bouton "MODE" pour activer le mode FM.
2. En mode FM, appuyez sur le bouton « PLAY/PAUSE » pour rechercher et mémoriser automatiquement la chaîne FM.
3. Appuyez sur le bouton suivant ou précédent pour changer le canal FM enregistré

**BLUETOOTH:**

Use the MODE button to enable Bluetooth on the PBX-262. Open the Bluetooth settings on your mobile device and search for QFX PBX-262. Select the option to pair both devices together. You can now sit back and enjoy the music from your favorite app. You won't need reconnect the Bluetooth again when switching through modes.

Use el botón MODE para habilitar Bluetooth en el PBX-262. Abra la configuración de Bluetooth en su dispositivo móvil y busque QFX PBX-262. Seleccione la opción para emparejar ambos dispositivos. Ahora puede sentarse y disfrutar de la música de su aplicación favorita. No necesitará volver a conectar el Bluetooth al cambiar de modo.

Utilisez le bouton MODE pour activer Bluetooth sur le PBX-262. Ouvrez les paramètres Bluetooth sur votre appareil mobile et recherchez QFX PBX-262. Sélectionnez l'option pour coupler les deux appareils ensemble. Vous pouvez maintenant vous asseoir et profiter de la musique de vot.

# THANK YOU

Enjoy your speaker and make many memories with it because  
**QFX is Where the Party Begins!**

We would love to hear about your PBX-262 Journey!  
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA





## LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at [www.qfxusa.com](http://www.qfxusa.com) for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of **misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX**. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

FOLLOW US @QFXUSA



**QFX USA® , Inc.**  
RMA Processing  
Customer Support Department  
2957 E. 46th Street | Vernon, CA 90058

✉ support@qfxusa.com  
☎ (800) 864-CLUB (2582) or (323) 864-6900  
🌐 qfxusa.com  
🕒 Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2022 ©



[www.qfxusa.com](http://www.qfxusa.com)