

BT-24

**QFX**  
WHERE THE PARTY BEGINS™



**INSTRUCTION MANUAL**



## PANEL



### Bluetooth

Switch the **M** "to Bluetooth. Search for **"QFX BT-24"** on your mobile Bluetooth device and pair/connect to it. After successful pairing, you can stream music over Bluetooth. And it will automatically connect to Bluetooth the next time you want to stream music over Bluetooth.

Press the **"◀◀"** button shortly to play the previous music track on the connected audio source.

Rotate the knob to the left for volume down.

Press the **"▶▶"** button shortly to play the next music track on the connected audio source.

Rotate the knob to the right for volume up.

Press **"▶||"** button for Play or Pause the music.

Press the **"⏻"** button for power on/off.

Press **"M"** button to change modes to Bluetooth, USB/TF, FM radio or AUX input.

Press the **"REVERB"** button for microphone reverb volume.

Press the **"ECHO"** button for microphone reverberation effect.

Press the **"TONE"** button for music effect.

Press the **"VOCAL CUT"** button for Eliminate the original sound.

### AUX Input

Connect an external audio source (portable audio player, CD player, etc.) output to the AUX audio jack input using the included 3.5mm stereo audio cable.

### FM Radio

Toggle mode **"M"** button to FM radio mode. Press and hold **"▶||"** button and the unit will auto-search and save available radio stations in your area. This process may take 1-2 minutes to complete. After it has been completed, you can press **"◀◀"** and **"▶▶"** buttons to change radio stations.

### USB/TF Music Player

Press the **"◀◀"** button shortly to play the previous music track on the connected audio source.

Rotate the knob to the left for volume down.

Press the **"▶▶"** button shortly to play the next music track on the connected audio source.

Rotate the knob to the right for volume up.

### True Wireless Stereo (TWS)

Two **BT-24** speakers can be paired together and connect to a Bluetooth device and deliver True Wireless Stereo (TWS) sound. To do so, Press-and-hold the **"M"** button, it will search for the other speaker and pairing. After successful pairing, you will here a confirming sound. Then you can connect it with your mobile phone and enjoy TWS music.

### Charging

Connect the USB power cable to Type-c USB port with computer or other USB port, the charge led light on.

### LED Lights

Press-and-hold **"☀"** button to turn LED lights ON/OFF.

Once lights are on, you can toggle the **"☀"** button to change different lights.

# PANEL



## Bluetooth

Passer le « **M** » sur Bluetooth. Recherchez « **QFX BT-24** » sur votre appareil Bluetooth mobile et associez-le/connectez-le. Une fois l'association réussie, vous pouvez diffuser de la musique via Bluetooth. Et il se connectera automatiquement au Bluetooth la prochaine fois que vous voulez diffuser de la musique via Bluetooth.

Appuyez brièvement sur le bouton « **◀◀** » pour lire le morceau de musique précédent sur la source audio connectée.

Faites tourner le bouton vers la gauche pour baisser le volume.

Appuyez brièvement sur le bouton « **▶▶** » pour lire le morceau de musique suivant sur la source audio connectée.

Faites tourner le bouton vers la droite pour augmenter le volume.

Appuyez sur le bouton « **▶||** » pour lire ou mettre en pause la musique.

Appuyez sur le bouton « **⏻** » pour allumer/éteindre.

Appuyez sur le bouton « **M** » pour changer de mode en Bluetooth, USB/TF, radio FM ou entrée AUX.

Appuyez sur le bouton « **REVERB** » pour le volume du microphone.

Appuyez sur le bouton « **ECHO** » pour l'effet de réverbération du microphone.

Appuyez sur le bouton « **TONE** » pour l'effet musical.

Appuyez sur le bouton « **VOCAL CUT** » pour éliminer le son d'origine.

## Entrée AUX

Connectez une sortie de source audio externe (lecteur audio portable, lecteur CD, etc.)

à l'entrée audio AUX à l'aide du câble audio stéréo 3,5 mm fourni.

## Radio FM

Basculez le bouton « **M** » en mode radio FM. Appuyez sur le bouton « **▶||** » et maintenez-le enfoncé pour que l'appareil recherche et enregistre automatiquement les stations de radio disponibles dans votre région. Ce processus peut prendre 1 à 2 minutes. Une fois terminé, vous pouvez appuyer sur les boutons « **◀◀** » et « **▶▶** » pour changer de station de radio.

## Lecteur de musique USB/TF

Appuyez brièvement sur le bouton « **◀◀** » pour lire le morceau de musique précédent sur la source audio connectée.

Faites tourner le bouton vers la gauche pour baisser le volume.

Appuyez brièvement sur le bouton « **▶▶** » pour lire le morceau de musique suivant sur la source audio connectée.

Faites tourner le bouton vers la droite pour augmenter le volume.

## True Wireless Stereo (TWS)

Deux enceintes **BT-24** peuvent être appairées et connectées à un appareil Bluetooth pour délivrer un son True Wireless Stereo (TWS). Pour ce faire, appuyez et maintenez le bouton « **M** », il recherchera l'autre enceinte et l'appairera. Une fois l'appairage réussi, vous entendrez un son de confirmation. Vous pouvez ensuite le connecter à votre téléphone portable et profiter de la musique TWS.

## Chargement

Connectez le câble d'alimentation USB au port USB Type-c avec l'ordinateur ou un autre port USB, le voyant de charge s'allume.

## Voyants LED

Appuyez et maintenez le bouton « **☼** » pour allumer/éteindre les voyants LED.

Une fois les voyants allumés, vous pouvez basculer le bouton « **☼** » pour changer les différents voyants.

## PANEL



### Bluetooth

Cambie la "M" a Bluetooth. Busque "QFX BT-24" en su dispositivo móvil Bluetooth y emparejelo/conéctelo. Después de un emparejamiento exitoso, puede transmitir música a través de Bluetooth. Y se conectará automáticamente a Bluetooth la próxima vez que desee transmitir música a través de Bluetooth.

Presione el botón "◀◀" brevemente para reproducir la pista de música anterior en la fuente de audio conectada.

Gire la perilla hacia la izquierda para bajar el volumen.

Presione el botón "▶▶" brevemente para reproducir la siguiente pista de música en la fuente de audio conectada.

Gire la perilla hacia la derecha para subir el volumen.

Presione el botón "▶||" para reproducir o pausar la música.

Presione el botón "⏻" para encender/apagar.

Presione el botón "M" para cambiar los modos a Bluetooth, USB/TF, radio FM o entrada AUX.

Presione el botón "REVERB" para el volumen del micrófono.

Presione el botón "ECHO" para el efecto de reverberación del micrófono.

Presione el botón "TONE" para el efecto musical.

Presione el botón "VOCAL CUT" para eliminar el sonido original.

### Entrada AUX

Conecte una fuente de audio externa (reproductor de audio portátil, reproductor de CD, etc.) a la entrada de audio AUX usando el cable de audio estéreo de 3,5 mm incluido.

### Radio FM

Alternar el modo "M" al modo de radio FM. Mantenga presionado el botón "▶||" y la unidad buscará y guardará automáticamente las estaciones de radio disponibles en su área. Este proceso puede tardar entre 1 y 2 minutos en completarse. Una vez que se haya completado, puede presionar los botones "◀◀" y "▶▶" para cambiar las estaciones de radio.

### Reproductor de música USB/TF

Presione el botón "◀◀" brevemente para reproducir la pista de música anterior en la fuente de audio conectada.

Gire la perilla hacia la izquierda para bajar el volumen.

Presione el botón "▶▶" brevemente para reproducir la siguiente pista de música en la fuente de audio conectada.

Gire la perilla hacia la derecha para subir el volumen.

### Estéreo inalámbrico verdadero (TWS)

Se pueden emparejar dos altavoces BT-24 y conectarlos a un dispositivo Bluetooth para ofrecer sonido estéreo inalámbrico verdadero (TWS). Para ello, mantenga pulsado el botón "M", buscará el otro altavoz y se emparejará. Después de que el emparejamiento se realice correctamente, oírás un sonido de confirmación. Luego, puede conectarlo con su teléfono móvil y disfrutar de la música TWS.

### Carga

Conecte el cable de alimentación USB al puerto USB tipo C con la computadora u otro puerto USB, la luz LED de carga se encenderá.

### Luces LED

Mantenga pulsado el botón "☀" para encender o apagar las luces LED.

Una vez que las luces estén encendidas, puede alternar el botón "☀" para cambiar las luces.



## LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at [www.qfxusa.com](http://www.qfxusa.com) for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

**QFX USA® , Inc.**  
RMA Processing  
Customer Support Department  
2957 E. 46th Street | Vernon, CA 90058

 [support@qfxusa.com](mailto:support@qfxusa.com)  
 (800) 864-CLUB (2582) or (323) 864-6900  
 [qfxusa.com](http://qfxusa.com)  
 **Hours of Operation: Monday - Friday, 9am - 5pm PST**

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

| PRODUCT CATEGORY                                                     | HANDLING | LABOR  | PARTS  |
|----------------------------------------------------------------------|----------|--------|--------|
| Earphones, Headphones, Pocket Radios,<br>& Small Bluetooth vSpeakers | \$5.00   | 1 Year | 1 Year |
| Personal Stereos                                                     | \$10.00  | 1 Year | 1 Year |
| Portable Radio/Cassette                                              | \$15.00  | 1 Year | 1 Year |
| Large Portable Radio Cassette                                        | \$20.00  | 1 Year | 1 Year |
| Mobile Audio                                                         | \$10.00  | 1 Year | 1 Year |
| Pro Audio SBX Systems                                                | \$75.00  | 1 Year | 1 Year |
| Pro Audio PBX Systems                                                | \$75.00  | 1 Year | 1 Year |
| Televisions                                                          | \$25.00  | 1 Year | 1 Year |
| Telephones                                                           | \$10.00  | 1 Year | 1 Year |

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025 ©



1-800-864-2582  
Mon-Fri 9AM - 5PM (PST)



[support@qfxusa.com](mailto:support@qfxusa.com)  
Mon-Fri 9AM - 5PM (PST)



[www.qfxusa.com](http://www.qfxusa.com)

# THANK YOU.

**QFX** Where the Party Begins!

We would love to hear about your BT-24 journey!  
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

