



INSTRUCTION MANUAL



LS-30 GUIDE

Installation: Before Installing the light strip, please make sure the sureface of installation is clean, we recommend to install on smooth clean surfaces.

•Begin by removing the LED strip from the reel. Measure the length of installation and cut the LED strip to the corresponding size. *The cut must ONLY be made on cut marking (See Image Below). Remove the film from the backside of the LED strip to expose the glue and begin installing. Connect the LED strips 4 pins to the 4 pin terminal found on the USB power cable. *Make sure the LED "+" Pin connects to the USB terminal marked with the triangle symbol, otherwise the light will not work (See Image Below). Supply the LED light with power.


Instalación: antes de instalar la tira de luz, asegúrese de que la cara segura de la instalación esté limpia. Recomendamos instalar sobre superficies lisas y limpias.


• Comience quitando la tira de LED del carrete. Mida la longitud de la instalación y corte la tira de LED al tamaño correspondiente. * El corte debe realizarse SOLAMENTE en la marca de corte (vea la imagen a continuación). Retire la película de la parte posterior de la tira de LED para exponer el pegamento y comenzar a instalar. Conecte las tiras de LED de 4 pines al terminal de 4 pines que se encuentra en el cable de alimentación USB. * Asegúrese de que el pin LED "+" se conecte al terminal USB marcado con el símbolo del triángulo; de lo contrario, la luz no funcionará (vea la imagen a continuación). Suministra energía a la luz LED.

Installation: avant d'installer la bande lumineuse, assurez-vous que la surface d'installation est propre, nous recommandons d'installer sur des surfaces propres et lisses.

•Commencez par retirer la bande LED de la bobine. Mesurez la longueur d'installation et coupez la bande LED à la taille correspondante. *La coupe doit être effectuée UNIQUEMENT sur le marquage de coupe (voir l'image ci-dessous). Retirez le film de l'arrière de la bande LED pour exposer la colle et commencer l'installation. Connectez les bandes LED 4 broches à la borne 4 broches présente sur le câble d'alimentation USB. * Assurez-vous que la broche « + » de la LED se connecte à la borne USB marquée du symbole du triangle, sinon la lumière ne fonctionnera pas (voir l'image ci-dessous). Alimentez la lumière LED en courant.







- 1. With lights ON, press the desired RGB color keys. 2. Press to increase color brightness. In JUMP and FADE modes, brightness UP will increase the speed of change.
- 3. Press to decrease color brightness. In JUMP and FADE modes, brightness DOWN will decrease the speed of change.
- 4. Press to turn lights ON.
- 5. Press to turn lights OFF
- 6. Press to select White lights.
- 7. Jump 3: Press to select 3 color jump lights mode. 8, Jump 7: Press to select 7 color jump lights mode.
- 9. Fade 3: Press to select 3 color fade lights mode. 10, Fade 7: Press to select 7 color fade lights mode. 11-14. Music 1-4: Four sound/music activated light modes
- 1. Con las luces ENCENDIDAS, presione las teclas de color RGB deseadas
- 2. Presione para aumentar el brillo del color. En los modos JUMP y FADE, el aumento de brillo aumentará la velocidad de cambio. 3. Presione para disminuir el brillo del color. En los modos JUMP y FADE, BAJAR el brillo
- disminuirá la velocidad de cambio.
- 4. Presione para ENCENDER las luces.
- Presione para APAGAR las luces. Presione para seleccionar Luces blancas.
- 7. Salto 3: presione para seleccionar el modo
- de luces de salto de 3 colores
- 8, Salto 7: presione para seleccionar el modo de luces de salto de 7 colores.
- 9. Fade 3: presione para seleccionar el modo de luces de atenuación de 3 colores.
- 10, Fade 7: presione para seleccionar el modo de luces de 7 colores.
- 11-14. Música 1-4: cuatro modos de luz activados por sonido/música.

- 1. Lorsque les lumières sont allumées, appuyez sur les touches de couleur RVB souhaitées.
- 2. Appuyez sur pour augmenter la luminosité des couleurs. Dans les modes JUMP et FADE. l'augmentation de la luminosité augmentera la vitesse de changement.
- 3. Appuyez sur pour diminuer la luminosité des couleurs. Dans les modes JUMP et FADE, la luminosité DOWN diminuera la vitesse de changement.
- Appuyez sur pour allumer les lumières.
- 5. Appuyez sur pour éteindre les lumières
- 6. Appuyez sur pour sélectionner Lumières blanches
- 7. Saut 3 : Appuyez pour sélectionner le mode de lumières de saut à 3 couleurs.
- 8, Jump 7 : Appuyez pour sélectionner le mode
- de lumières de saut à 7 couleurs 9. Fondu 3 : Appuyez pour sélectionner le mode
- de lumières de fondu à 3 couleurs 10. Fade 7 : Appuyez pour sélectionner le mode de lumière de fondu à 7 couleurs.
- 11-14. Musique 1-4 : Quatre modes d'éclairage activés par le son/la musique.















LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other dimatric conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (I) OF HERCHANTABILITY, (II) OF FITHESS FOR A PARTICULAR PURPOSE, OR (III) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF OPX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OPX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.

RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com

(800) 864-CLUB (2582) or (323) 864-6900

qfxusa.com

Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PROPULET CATEGORY			04.077
PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-IMPRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE IMPTED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS WADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, OR'S SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2023 ©







THANK YOU.

Enjoy your speaker and make many memories with it because QFX is Where the Party Begins!

We would love to hear about your LS-30 Journey! Tag us **@QFXUSA** to share your stories.