

BT-85


QFX

WHERE THE PARTY BEGINS™



BT-85

INSTRUCTION MANUAL



FUNCTIONS

1. USB: Insert USB drive to MP3 formatted music files or charge a mobile device (DC 5V).
2. DC 5V Charge the unit using the provided USB-C power supply.
3. AUX IN: Connect the output of an external audio device to the 3.5mm AUX input.
4. CHARGING INDICATOR: Red LED = charging, Light off = fully charged.
5. MIC: Plug in a microphone that has 1/4" (6.35mm) connector.
6. POWER/MODE: Press and hold the power button to turn unit ON or OFF. Press to change modes between BT/AUX/FM/USB.
7. LIGHT: Press to turn lights on and to change light modes. Press and hold to turn light off.
8. EQ/ECHO: Press to change microphone ECHO function. Press and hold to change EQ settings.
9. PREV/VOL: Press to select previous audio track or FM station. Press and hold to decrease the volume.
10. PLAY/PAUSE/TWS: Press to play or pause music playback. Press and hold in FM mode to begin auto scanning/storing stations. In Bluetooth mode, press and hold for 3 seconds to pair another unit of the same make and model.
11. NEXT/VOL: Press to select the next audio track or FM radio station. Press and hold to increase the volume.

FUNCIONES

1. USB: inserte la unidad USB en archivos de música con formato MP3 o cargue un dispositivo móvil (DC 5V).
2. DC 5V Cargue la unidad utilizando la fuente de alimentación USB-C provista.
3. AUX IN: conecta la salida de un dispositivo de audio externo a la entrada AUX de 3,5 mm.
4. INDICADOR DE CARGA: LED rojo = cargando, luz apagada = carga completa.
5. MIC: Conecte un micrófono que tenga un conector de 1/4" (6,35 mm).
6. ENCENDIDO/MODO: Mantenga presionado el botón de encendido para encender o apagar la unidad. Presione para cambiar los modos entre BT/AUX/FM/USB.
7. LUZ: presione para encender las luces y cambiar los modos de luz. Mantenga presionado para apagar la luz.
8. EQ/ECHO: Presione para cambiar la función ECHO del micrófono. Mantenga presionado para cambiar la configuración de EQ.
9. PREV/VOL: presione para seleccionar la pista de audio anterior o la estación de FM. Mantenga presionado para disminuir el volumen.
10. REPRODUCIR/PAUSAR/TWS: Presione para reproducir o pausar la reproducción de música. Manténgalo presionado en el modo FM para comenzar a buscar automáticamente/almacenar estaciones. En el modo Bluetooth, mantenga presionado durante 3 segundos para emparejar otra unidad de la misma marca y modelo.
11. NEXT/VOL: presione para seleccionar la siguiente pista de audio o estación de radio FM. Mantenga presionado para aumentar el volumen

LES FONCTIONS

1. USB : insérez une clé USB dans des fichiers musicaux au format MP3 ou chargez un appareil mobile (DC 5V).
2. DC 5V Chargez l'appareil à l'aide de l'alimentation USB-C fournie.
3. AUX IN : connectez la sortie d'un appareil audio externe à l'entrée AUX 3,5 mm.
4. INDICATEUR DE CHARGE : LED rouge = en charge, lumière éteinte = complètement chargée.
5. MIC : branchez un microphone doté d'un connecteur 1/4" (6,35 mm).
6. ALIMENTATION/MODE : Appuyez sur le bouton d'alimentation et maintenez-le enfoncé pour allumer ou éteindre l'appareil. Appuyez pour changer de mode entre BT/AUX/FM/USB.
7. LIGHT : Appuyez pour allumer les lumières et pour changer les modes d'éclairage. Appuyez et maintenez pour éteindre la lumière.
8. EQ/ECHO : Appuyez pour changer la fonction ECHO du microphone. Maintenez enfoncé pour modifier les paramètres d'égalisation.
9. PREV/VOL : Appuyez pour sélectionner la piste audio ou la station FM précédente. Maintenez enfoncé pour diminuer le volume.
10. PLAY/PAUSE/TWS : Appuyez pour lire ou mettre en pause la lecture de la musique. Maintenez enfoncé en mode FM pour lancer le balayage automatique/mémorisation des stations. En mode Bluetooth, appuyez et maintenez pendant 3 secondes pour coupler un autre appareil de la même marque et du même modèle.
11. NEXT/VOL : Appuyez pour sélectionner la piste audio ou la station de radio FM suivante. Appuyez et maintenez enfoncé pour augmenter le volume

BLUETOOTH

Toggle the MODE button to select BT mode on the BT-85. On your Bluetooth-enabled device, turn Bluetooth on, pair it to "QFX BT-85" and enjoy Bluetooth music from your device.

TRUE WIRELESS STEREO (TWS) CONNECTION

True Wireless Stereo (TWS) allows you connect two BT-85 units together to play Bluetooth music in wirelessly in stereo. To set up TWS:

1. Push MODE button on both speakers until both speakers are in BT mode.
2. When both speakers are in BT mode, press ►|| button twice on each unit. You will hear a beep. Next time you put both speakers in Bluetooth mode at the same time, both speakers will connect automatically.
3. On your Bluetooth-enabled device, turn Bluetooth ON and pair it to "QFX BT-85". Enjoy True Wireless Stereo (TWS) sound from your phone or tablet via Bluetooth!

BLUETOOTH

Mueva el botón MODO para seleccionar el modo BT en el BT-85. En su dispositivo habilitado para Bluetooth, active Bluetooth, conéctelo a "QFX BT-85" y disfrute de la música Bluetooth desde su dispositivo.

TRUE WIRELESS STEREO (TWS) CONEXIÓN

True Wireless Stereo (TWS) allows you connect two BT-85 units together to play Bluetooth music in wirelessly in stereo. To set up TWS:

1. Push MODE button on both speakers until both speakers are in BT mode.
2. When both speakers are in BT mode, press ►|| button twice on each unit. You will hear a beep. Next time you put both speakers in Bluetooth mode at the same time, both speakers will connect automatically.
3. On your Bluetooth-enabled device, turn Bluetooth ON and pair it to "QFX BT-85". Enjoy True Wireless Stereo (TWS) sound from your phone or tablet via Bluetooth!

BLUETOOTH

Basculez le bouton MODE pour sélectionner le mode BT sur le BT-85. Sur votre appareil compatible Bluetooth, activez Bluetooth, associez-le à "QFX BT-85" et profitez de la musique Bluetooth depuis votre appareil.

TRUE WIRELESS STEREO (TWS) CONNEXION

True Wireless Stereo (TWS) allows you connect two BT-85 units together to play Bluetooth music in wirelessly in stereo. To set up TWS:

1. Push MODE button on both speakers until both speakers are in BT mode.
2. When both speakers are in BT mode, press ►|| button twice on each unit. You will hear a beep. Next time you put both speakers in Bluetooth mode at the same time, both speakers will connect automatically.
3. On your Bluetooth-enabled device, turn Bluetooth ON and pair it to "QFX BT-85". Enjoy True Wireless Stereo (TWS) sound from your phone or tablet via Bluetooth!




SPEAKER-PRO APP

The Speaker Pro App gives you full control over the music selection, volume, bass, treble, and lights. Change the radio station and change the style, intensity, and color of the light. Your phone is the remote control!

La aplicación Speaker Pro le brinda un control total sobre la selección de música, el volumen, los graves, los agudos y las luces. Cambia la emisora de radio y cambia el estilo, el intensidad y el color de la luz. ¡Tu teléfono es el mando a distancia!

L'application Speaker Pro vous donne un contrôle total sur la sélection de musique, le volume, les basses, les aigus et les lumières. Changez la station de radio et changez le style, l'intensité et la couleur de la lumière. Votre téléphone est la télécommande!



1. BLUETOOTH MUSIC: Stream music from your mobile device.
2. USB: Select and navigate MP3 music files stored on your USB drive.
3. LIGHT: Control and customize your light show.
4. FM RADIO: Navigate and control FM radio.
5. BLUETOOTH: Search for Bluetooth devices.
6. LINE: Mute the audio signal.
7. SOUND: Adjust the music equalization (EQ)

-
1. MÚSICA BLUETOOTH: Transmite música desde su dispositivo móvil.
 2. USB: seleccione y navegue por los archivos de música MP3 almacenados en su unidad USB.
 3. LUZ: Controla y personaliza tu espectáculo de luces.
 4. RADIO FM: Navega y controla la radio FM.
 5. BLUETOOTH: busca dispositivos Bluetooth.
 6. LÍNEA: silencia la señal de audio.
 7. SONIDO: Ajusta la ecualización de la música (EQ)

-
1. MUSIQUE BLUETOOTH : Diffusez de la musique depuis votre appareil mobile.
 2. USB : Sélectionnez et parcourez les fichiers musicaux MP3 stockés sur votre clé USB.
 3. LUMIÈRE : contrôlez et personnalisez votre jeu de lumière.
 4. RADIO FM : Naviguez et contrôlez la radio FM.
 5. BLUETOOTH : recherchez les appareils Bluetooth.
 6. LIGNE : coupe le signal audio.
 7. SON : ajustez l'égalisation de la musique (EQ)



1. Bluetooth Music Play: Press to enter into Bluetooth Music page. Press "Pick Songs to Play" to Pick Song page to choose the song you want to play. Press "Done" to return back to Bluetooth Music play page. You can also operate pause, play, backward, and forward. you can also adjust the volume, repeat, or select shuffle play mode.
2. USB: Insert a USB drive into the speaker and select the USB page. Choose a song from the list to play back. Use the controllers in the bottom to navigate (Pause, Play, Back, Forward).
3. Light: Control the light colors, brightness, select from the presets, or turn ON/OFF. Use the color wheel to select colors. Press "Profiles" to enter the Light Effects mode page. You can choose from a total of 12 factory selected pre-sets.
4. FM Radio: Press to enter into FM Radio mode. Select "SCAN" to begin the automatic scanning process. This will find and store local channels in a preset. Turn the digital "TUNER" dial to change radio stations (87.5MHz~108.0MHz).
5. Bluetooth: Press to enter the Bluetooth connection page. Select "BT-85" or other supported QFX Speakers.
6. Line: Press to enter the "Line Input" page. Press "OFF" to mute the music. Press "ON" to play the music. Press "Back" to exit the page.
7. Sound: Press to enter the Sound page. Press MUSIC to adjust the volume, bass and treble on the speaker. There are 4 pre-set EQ modes to choose from: Pop, Classical, Jazz or Rock. You can also press G-EQ to access the graphic equalizer to set up your preferred equalizer specification.

1. Reproducción de música Bluetooth: Pulse para entrar en la página de música Bluetooth. Presione "Elegir canciones para reproducir" en la página Elegir canción para elegir la canción que desea reproducir. Presione "Listo" para volver a la página de reproducción de música Bluetooth. También puede operar pausar, reproducir, retroceder y avanzar. también puede ajustar el volumen, repetir o seleccionar el modo de reproducción aleatoria.
2. USB: Inserte una unidad USB en el altavoz y seleccione la página USB. Elija una canción de la lista para reproducirla. Use los controladores en la parte inferior para navegar (Pausa, Reproducir, Atrás, Adelante).
3. Luz: Controle los colores de la luz, el brillo, seleccione entre los ajustes preestablecidos o encienda/apague. Utilice la rueda de colores para seleccionar los colores. Presione "Perfiles" para ingresar a la página del modo Efectos de luz. Puede elegir entre un total de 12 preajustes seleccionados de fábrica.
4. Radio FM: Pulse para entrar en el modo de radio FM. Seleccione "ESCANEAR" para comenzar el proceso de escaneo automático. Esto encontrará y almacenará los canales locales en un preajuste. Gire el dial digital "TUNER" para cambiar las estaciones de radio (87.5MHz~108.0MHz).
5. Bluetooth: Pulse para entrar en la página de conexión Bluetooth. Seleccione "BT-85" u otros altavoces QFX compatibles.
6. Línea: presione para ingresar a la página "Entrada de línea". Pulse "OFF" para silenciar la música. Pulse "ON" para reproducir la música. Pulse "Atrás" para salir de la página.
7. Sonido: Presione para ingresar a la página de Sonido. Pulse MÚSICA para ajustar el volumen, los graves y los agudos del altavoz. Hay 4 modos de ecualización preestablecidos para elegir: Pop, Clásica, Jazz o Rock. También puede presionar G-EQ para acceder al ecualizador gráfico y configurar su especificación de ecualizador preferida.

1. Lecture de musique Bluetooth : Appuyez sur pour accéder à la page Musique Bluetooth. Appuyez sur "Pick Songs to Play" sur la page Pick Song pour choisir la chanson que vous voulez jouer. Appuyez sur "Terminé" pour revenir à la page de lecture de musique Bluetooth. Vous pouvez également activer la pause, la lecture, l'arrière et l'avant. vous pouvez également régler le volume, répéter ou sélectionner le mode de lecture aléatoire.
2. USB : Insérez une clé USB dans l'enceinte et sélectionnez la page USB. Choisissez une chanson dans la liste à lire. Utilisez les contrôleurs en bas pour naviguer (Pause, Lecture, Retour, Avance).
3. Lumière : Contrôlez les couleurs de la lumière, la luminosité, sélectionnez parmi les pré-réglages ou activez/désactivez. Utilisez la roue chromatique pour sélectionner les couleurs. Appuyez sur "Profils" pour accéder à la page du mode Effets lumineux. Vous pouvez choisir parmi un total de 12 pré-réglages sélectionnés en usine.
4. Radio FM : Appuyez pour entrer en mode Radio FM. Sélectionnez "SCAN" pour lancer le processus de numérisation automatique. Cela trouvera et stockera les chaînes locales dans un pré-réglage. Tournez le cadran numérique « TUNER » pour changer de station de radio (87,5 MHz ~ 108,0 MHz).
5. Bluetooth : Appuyez sur pour accéder à la page de connexion Bluetooth. Sélectionnez "BT-85" ou d'autres haut-parleurs QFX pris en charge.
6. Ligne : Appuyez pour accéder à la page "Entrée de ligne". Appuyez sur "OFF" pour couper la musique. Appuyez sur "ON" pour jouer la musique. Appuyez sur "Retour" pour quitter la page.
7. Son : Appuyez sur pour accéder à la page Son. Appuyez sur MUSIC pour régler le volume, les graves et les aigus sur le haut-parleur. Vous avez le choix entre 4 modes d'égalisation prédéfinis : Pop, Classique, Jazz ou Rock. Vous pouvez également appuyer sur G-EQ pour accéder à l'égaliseur graphique afin de configurer votre spécification d'égaliseur préférée.



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(800) 864-CLUB (2582) or (323) 864-6900
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2023 ©



1-800-864-CLUB (2582)
Mon-Fri 9AM - 5PM (PST)



support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)



www.qfxusa.com

THANK YOU.

Enjoy your speaker and make many memories with it because
QFX is Where the Party Begins!

We would love to hear about your BT-85 Journey!
Tag us **@QFXUSA** to share your stories.



SPEAKER-PRO APP

The Speaker Pro App gives you full control over the music selection, volume, bass, treble, and lights. Change the radio station and change the style, intensity, and color of the light. Your phone is the remote control!

La aplicación Speaker Pro le brinda un control total sobre la selección de música, el volumen, los graves, los agudos y las luces. Cambia la emisora de radio y cambia el estilo, el intensidad y el color de la luz. ¡Tu teléfono es el mando a distancia!

L'application Speaker Pro vous donne un contrôle total sur la sélection de musique, le volume, les basses, les aigus et les lumières. Changez la station de radio et changez le style, l'intensité et la couleur de la lumière. Votre téléphone est la télécommande!