

SBX-21501

QFX

WHERE THE PARTY BEGINS™



INSTRUCTION MANUAL

WARNING!

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN. To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers. Clean only with a dry cloth. Users should exhibit extra safety when this symbol appears in this instruction manual and follow all precautions as they are stated.

PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO quite la cubierta en este altavoz. NO HAY PARTES REPARABLES POR EL USUARIO ADENTRO. SOLICITE EL SERVICIO A UN TECNICO CALIFICADO. Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia o la humedad. No almacene o utilice este producto cerca de líquidos, fuentes de calor, como radiadores, acumuladores de calor. Limpie sólo con un paño seco. Los usuarios deben exhibir una seguridad adicional cuando este símbolo aparece en este manual de instrucciones y siga todas las precauciones, ya que se han precisado.

SBX-21501 DISPLAY SYSTEM SETTINGS

1. Input Mode: The LED display screen will display the information of input mode for USB/SD/BLUE/ LINE/FM. When a USB flash drive / SD Card is inserted into the USB/SD input, the unit will automatically switch to USB/SD mode and begin playing Mp3 audio files from the USB flash drive / SD Card.
2. Track Number: The track number currently playing from the USB/SD will display.
3. FM Mode: All FM channels display here. Press and hold "play/pause" button for auto scan all channels.
4. AUX Mode: Both the front panel and the back panel have AUX inputs. When used together, the AUX input of the front panel takes precedence

SBX-21501 AJUSTES DEL SISTEMA DE PANTALLA

1. Modo de entrada: La pantalla LED mostrará la información del modo de entrada para USB / SD/BLUE/ LINE / FM. Cuando se inserta una unidad de tarjeta de memoria flash USB / SD en la entrada USB /
2. SD, la unidad automáticamente cambiar al modo USB / SD y comenzar la reproducción de archivos de audio .mp3 del flash USB Card unidad / SD.
3. Track Número: El número que se está reproduciendo de la pista USB / SD se mostrará Modo
4. Modo FM: Aquí se muestran todos los canales de FM. Mantenga presionado el botón "reproducir/pausar" para escanear automáticamente todos los canales
5. Modo AUX: Tanto el panel frontal como el panel posterior tienen entradas AUX. Cuando se usan juntos, la entrada AUX del panel frontal tiene prioridad

SBX-21501 BLUETOOTH

Bluetooth Mode: Open the Bluetooth of phone. Find the Bluetooth name of the unit called "QFX SBX-21501" to connect. After a successful match, you can play the music from speaker. You won't need reconnect the Bluetooth when switching mode.

SBX-21501 BLUETOOTH


Modo de Bluetooth: Abra el bluetooth de moilephone. Find el nombre del bluetooth de la unidad llamada "QFX SBX-21501" para conectarse. Después de una persona compatible, puede reproducir la música de los altavoces. Usted no tendrá que volver a conectar el Bluetooth cuando el modo de conmutación.

SBX-21501 Recording Function

Put the USB/SD card in the slot. Insert a wired mic or connect a wireless microphone and ensure that it works properly. Press "REC" to start recording sound, short press "REC" to play the recording file, press and hold to exit recording function.

SBX-21501 Función de grabación

Coloque la tarjeta USB/SD en la ranura. Inserte un micrófono con cable o conecte un micrófono inalámbrico y asegúrese de que funciona correctamente. Presione "REC" para comenzar a grabar sonido, presione brevemente "REC" para reproducir el archivo de grabación, mantenga presionado para salir de la función de grabación.




SBX-21501 REAR PANEL

1. Power Switch: ON/OFF
2. Master Volume Knob: Adjust from Min to Max
3. Treble Knob : Adjust from Min to Max
4. Bass Knob: Adjust from Min to Max
5. Mic Treble Knob : Adjust from Min to Max
6. Mic Bass Knob: Adjust from Min to Max
7. Microphone Echo Knob: Adjust from Min to Max
8. Guitar Volume Knob: Adjust from Min to Max
9. Microphone Volume Knob: Adjust from Min to Max
10. Mode Button: Toggle between AUX, USB, TF, FM, BT.
REC Button: Recording Play/Pause Button (TWS connection)
Previous Track Button: Select previous track
Next Track Button: Select next track
Repeat Button.
MIC PRIORITY: ON/OFF
11. AUX Input
12. Microphone Input 1
13. Microphone Input 2
14. Guitar Input
15. SD Card Slot
16. USB Slot
17. 7 Band EQ

SBX-21501 PANEL TRASERO

1. Interruptor de encendido: encendido/apagado
2. Perilla de volumen maestro: Ajuste de Min a Max
3. Perilla de agudos: Ajuste de Min a Max
4. Perilla de bajos: Ajuste de Min a Max
5. Perilla de agudos del micrófono: Ajuste de Min a Max
6. Perilla de bajo del micrófono: Ajuste de Min a Max
7. Perilla de eco del micrófono: Ajuste de Min a Max
8. Perilla de volumen de guitarra: Ajuste de Min a Max
9. Perilla de volumen del micrófono: Ajuste de Min a Max
10. Botón de modo: alternar entre AUX, USB, TF, FM, BT.
Botón REC: Botón de reproducción/pausa de grabación (conexión TWS) Botón de pista anterior: selecciona la pista anterior Botón de pista siguiente: selecciona la pista siguiente Botón de repetición. PRIORIDAD DE MICRÓFONO: ENCENDIDO/APAGADO
11. Entrada auxiliar
12. Entrada de micrófono 1
13. Entrada de micrófono 2
14. Entrada de guitarra
15. Ranura para tarjetas SD
16. Puerto USB
17. Ecuilizador de 7 bandas



SBX-21501 BACK PANEL

1. LED: ON/OFF
2. AUDIO INPUT: EXT/ AUX
3. SWITCH FOR EXT / AUX
4. FM Antenna
5. AC CONNECTION: 120V 60Hz

SBX-21501 BACK PANEL


1. LED ENCENDIDO/APAGADO
2. ENTRADA DE AUDIO: EXT/AUX
3. INTERRUPTOR PARA EXT / AUX
4. Antena FM
5. CONEXIÓN CA: 120V 60Hz

SBX-21501 REMOTE CONTROL

1. STANDBY: Make the unit to be standby mode.
2. Input Mode Button: Toggle between USB,SD,FM,AUX,BT
3. REC
4. KEY Number for selecting the certain track
5. PLAY REC
6. EQ
7. Mute:Mute the track
8. PLAY/PAUSE
9. CHANNEL+
10. CHANNEL-
11. VOL-:Reduce the master volume
12. VOL+: Increase the master volume
13. REP: Repeat the playing track.
14. Press to Scan Channel in FM Mode
15. Previous Track: Select previous channel
16. PLAY/PAUSE
17. Next Track: Select next channel.

SBX-21501 REMOTE CONTROL

1. STANDBY: Haga que la unidad estar en modo de espera.
2. Botón de modo de entrada: alternar entre USB, SD, FM, AUX, BT
3. REC
4. Número de tecla para seleccionar la pista determinada
5. PALY REC
6. EQ
7. Mute: silencia la pista
8. PLAY/PAUSE
9. CHANNEL +
10. CHANNEL-
11. VOL-: reduce el volumen maestro
12. VOL +: aumenta el volumen maestro
13. REP: repite la pista de reproducción.
14. Presione para escanear el canal en el modo FM
15. Pista anterior: seleccione el canal anterior
16. PLAY/PAUSE
17. Siguiente pista: selecciona el siguiente canal.



TWS CONNECTION

1. TWS connection: TWS Connection is only for two speakers, can not support quantity over 2 PCS.
2. Turn on the Speakers , press the MODE button to switch to BLUETOOTH mode, and the word“BLUE” on the LED screen will flash.
3. At the first time, please press the Play/Pause (TWS) button for 3 seconds, Then two speakers will connect together
4. Connect the phone: Open the phone Bluetooth settings, Search and Connect the main device Bluetooth Name 'QFX SBX-21501'.
5. Select music from phone and enjoy TWS playing in pairs with two Speakers.
6. Exit TWS: Long press the Play/Pause (TWS) button for 3 seconds to exit the TWS function

CONEXION TWS

1. Conexión TWS: la conexión TWS es solo para dos altavoces, no puede admitir una cantidad superior a 2 PCS.
2. Encienda los altavoces, presione el botón MODE para cambiar al modo BLUETOOTH y la palabra "AZUL" en la pantalla LED parpadeará.
3. La primera vez, presione el botón Reproducir / Pausa (TWS) durante 3 segundos, luego dos altavoces se conectarán juntos
4. Conecte el teléfono: abra la configuración de Bluetooth del teléfono, busque y conecte el nombre de Bluetooth del dispositivo principal 'QFX SBX-21501'.
5. Seleccione música desde el teléfono y disfrute de la reproducción de TWS en pares con dos altavoces.
6. Salir de TWS: mantenga presionado el botón Reproducir/Pausar (TWS) durante 3 segundos para salir de la función TWS

Product Equipment List

1. Speaker	1PC
2. Power Cable	1PC
3. MP3 Remote Control	1PC
4. User Manual	1PC
5. Wired Mic	2PCS
6. Wireless Mic	2PCS

Lista de equipos de productos

1. Altavoz	1PC
2. Cable de alimentación	1PC
3. Mando a distancia MP3	1PC
4. Manual de usuario	1PC
5. Micrófono con cable	2PCS
6. Micrófono inalámbrico	2PCS



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(800) 864-CLUB (2582) or (323) 864-6900
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2023 ©



1-800-864-CLUB (2582)
Mon-Fri 9AM - 5PM (PST)



support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)



www.qfxusa.com

THANK YOU.

Enjoy your speaker and make many memories with it because
QFX is Where the Party Begins!

We would love to hear about your SBX-21501 Journey!
Tag us **@QFXUSA** to share your stories.