


TMS-853 | TMS-1253 | TMS-1553

**QFX**<sup>®</sup>

WHERE THE PARTY BEGINS<sup>™</sup>



**INSTRUCTION MANUAL**



## SAFETY

To reduce the risk of electric shock, do not remove the cover on the speaker. There are no user-serviceable parts inside. Please refer all servicing to a qualified technician.

To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not operate this product near liquids, heat sources such as radiators or heat registers. Clean only with a dry clothes. Users should exhibit extra safety when this symbol appears in the instruction manual and follow all precautions as they are stated.

## SEGURIDAD


Para reducir el riesgo de descarga eléctrica, no retire la cubierta del altavoz. No hay partes reparables por el usuario adentro. Consulte todo el servicio a un técnico calificado. Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia o la humedad. No opere este producto cerca de líquidos o fuentes de calor como radiadores o rejillas de calefacción. Limpiar sólo con ropa seca. Los usuarios deben mostrar seguridad adicional cuando este símbolo aparece en el manual de instrucciones y seguir todas las precauciones tal como se indican.

## TMS-853 Input Panel and Controls

1. **VOLUME:** Power ON/OFF and Master Volume Control Knob
2. **TREBLE:** Treble Control Knob
3. **BASS:** Bass Control Knob
4. **ECHO:** Mic Echo Control Knob
5. **MIC.VOL:** Microphone Volume Control
6. **MODE:**
  - a. Short press to toggle AUX, USB, TF, FM Radio and Bluetooth Modes.
  - b. Press-and-hold to turn LED party lights ON or OFF.

<< Short-press to select previous track or station  
 >|| Short-press to select Play or Pause music. TWS button when connecting two speakers via True Wireless Stereo  
 >>| Short-press to select Next track or station. Press-and-hold to select or to exit Mic Priority function.
7. **USB:** USB port to play MP3 formatted music files stored on USB drives
8. **TF:** TF Card Slot to Play MP3 formatted music files stored on TF cards
9. **AUX:** 3.5mm auxiliary input jack to connect from external audio devices
10. **MIC IN:** 6.3mm microphone input jack to connect a wired microphone
11. **DC:** 9VDC power input jack
12. **CHARGE:** Battery Charging LED indicator

## TMS-853



**Panel de entrada y controles del MS-853**

1. **VOLUMEN:** Encendido/apagado y perilla de control de volumen principal
2. **TREBLE:** Perilla de control de agudos
3. **BASS:** Perilla de control de graves
4. **ECHO:** Perilla de control de eco del micrófono
5. **MIC.VOL:** Control de volumen del micrófono
6. **MODO:**
  - a. Presione brevemente para alternar los modos AUX, USB, TF, Radio FM y Bluetooth.
  - b. Mantenga presionado para encender o apagar las luces LED para fiestas.

|<< Presione brevemente para seleccionar la pista o estación anterior

>|| Presione brevemente para seleccionar Reproducir o Pausar música. Botón TWS al conectar dos altavoces mediante True Wireless Stereo

>>| Presione brevemente para seleccionar Siguiente pista o estación. Mantenga presionado para seleccionar o salir de la función Prioridad de micrófono.
7. **USB:** Puerto USB para reproducir archivos de música con formato MP3 almacenados en unidades USB
8. **TF:** Ranura para tarjeta TF para reproducir archivos de música con formato MP3 almacenados en tarjetas TF
9. **AUX:** conector de entrada auxiliar de 3,5 mm para conectar desde dispositivos de audio externos
10. **MIC IN:** conector de entrada de micrófono de 6,3 mm para conectar un micrófono con cable
11. **CC:** conector de entrada de alimentación de 9 VCC
12. **CARGA:** Indicador LED de carga de batería

**TMS-1253 / TMS-1553 Input Panel and Controls**

1. **POWER:** ON / OFF Power Switch
2. **VOLUME:** Master Volume Control Knob
3. **ECHO:** Mic Echo Control Knob
4. **MIC.VOL:** Microphone Volume Control
5. **BASS:** Bass Control Knob
6. **TREBLE:** Treble Control Knob
7. **MODE:**
  - a. Short press to toggle AUX, USB, TF, FM Radio and Bluetooth Modes.
  - b. Press-and-hold to turn LED party lights ON or OFF.

|<< Short-press to select previous track or station

>|| Short-press to select Play or Pause music. TWS button when connecting two speakers via True Wireless Stereo

>>| Short-press to select Next track or station. Press-and-hold to select or to exit Mic Priority function.
8. **TF:** TF Card Slot to Play MP3 formatted music files stored on TF cards
9. **USB:** USB port to play MP3 formatted music files stored on USB drives
10. **AUX:** 3.5mm auxiliary input jack to connect from external audio devices
11. **MIC IN:** 6.3mm microphone input jack to connect a wired microphone
12. **CHARGE:** Battery charging LED indicator
13. **DC:** 13.5VDC power input jack

**TMS-853 / TMS-1253 / TMS-1553 OPERATION****RECHARGEABLE BATTERY**

Be sure to completely charge the internal battery prior to first use in order to maximize the battery's lifespan. Once connected to a power source, your QFX speaker will begin charging. It will take from 4-5 hours to fully recharge the battery. Even if power is low, the unit will power on when connected to a power source. When the battery is charging, the indicator light will be red color. Once fully charged, the light will turn off. When the speaker will not be used for many months, it is recommended that you fully recharge the battery at least once every 60 days.

**BLUETOOTH**

Enable Bluetooth on your mobile device. On the device, find the Bluetooth name of the QFX speaker to connect; either QFX TMS-853, QFX-1253 or QFX-1553. After successful pairing, you can stream music wirelessly from our Bluetooth device.

**DISPLAY**

The LED screen will display the following information:

- Input Mode (displays USB, TF, Bluetooth, AUX or FM)
- When the USB drive or TF card is inserted, it will switch to USB/TF mode and begin playing your MP3 formatted music files. The track number currently playing from the USB/TF will be displayed.
- In FM radio mode, the FM radio station channels will be displayed. Short-press the Play/Pause button while in FM mode to auto-scan and save the radio stations received in your area.


**TRUE WIRELESS STEREO (TWS)**

Two of the exact same model QFX speakers can be paired together and connect to a Bluetooth device and deliver True Wireless Stereo (TWS) sound. To do so:

- Turn both speakers power ON
- Select Bluetooth mode on both speakers
- Press the Play/Pause button on one speaker only for 3 seconds. Then the speakers will connect together.
- Next, to connect to your Bluetooth device, search for the QFX model number (QFX TMS-853, QFX-1253 or QFX-1553).
- After successful pairing, you can stream music wirelessly from your Bluetooth device to both speakers in True Wireless Stereo (TWS).
- Press-and-hold TWS to exit True Wireless Stereo mode.


**REMOTE CONTROL**

- STANDBY:** Make the unit to be standby mode.
- Input Mode Button:** Toggle between USB,TF,FM,AUX,BT
- Mute:** Mute the track
- PLAY/PAUSE**
- Previous Track:** Select previous channel
- Next Track:** Select next channel.
- EQ:** Select EQ mode.
- VOL-:** Reduce the master volume
- VOL+:** Increase the master volume
- REP:** Repeat the playing track.
- Press to Scan Channel in FM Mode
- 12-21.** KEY Number for selecting the certain TF card.




12--21

## TMS-1253



## TMS-1553



### Panel de entrada y controles TMS-1253 / TMS-1553

1. **ALIMENTACIÓN:** Interruptor de encendido/apagado
2. **VOLUMEN:** Perilla de control de volumen maestro
3. **ECHO:** Perilla de control de eco del micrófono
4. **MIC.VOL:** Control de volumen del micrófono
5. **BASS:** Perilla de control de graves
6. **TREBLE:** Perilla de control de agudos
7. **MODO:**
  - a. Short press to toggle AUX, USB, TF, FM Radio and Bluetooth Modes.
  - b. Press-and-hold to turn LED party lights ON or OFF.
  - << Short-press to select previous track or station
  - >| Short-press to select Play or Pause music. TWS button when connecting two speakers via True Wireless Stereo
  - >>| Short-press to select Next track or station. Press-and-hold to select or to exit Mic Priority function.
8. **TF:** Ranura para tarjeta TF para reproducir archivos de música con formato MP3 almacenados en tarjetas TF
9. **USB:** Puerto USB para reproducir archivos de música con formato MP3 almacenados en unidades USB
10. **AUX:** conector de entrada auxiliar de 3,5 mm para conectar desde dispositivos de audio externos
11. **MIC IN:** conector de entrada de micrófono de 6,3 mm para conectar un micrófono con cable
12. **CARGA:** Indicador LED de carga de batería
13. **CC:** conector de entrada de alimentación de 13,5 VCC

## OPERACIÓN TMS-853 / TMS-1253 / TMS-1553

### BATERÍA RECARGABLE

Asegúrese de cargar completamente la batería interna antes del primer uso para maximizar su vida útil. Una vez conectado a una fuente de alimentación, su altavoz QFX comenzará a cargarse. Se necesitarán entre 4 y 5 horas para recargar completamente la batería. Incluso si la energía es baja, la unidad se encenderá cuando esté conectada a una fuente de energía. Cuando la batería se esté cargando, la luz indicadora será de color rojo. Una vez cargada completamente, la luz se apagará. Cuando el altavoz no se vaya a utilizar durante muchos meses, se recomienda recargar completamente la batería al menos una vez cada 60 días.

### BLUETOOTH

Habilite Bluetooth en su dispositivo móvil. En el dispositivo, busque el nombre de Bluetooth del altavoz QFX para conectarse; ya sea QFX TMS-853, QFX-1253 o QFX-1553. Después de un emparejamiento exitoso, podrá transmitir música de forma inalámbrica desde nuestro dispositivo Bluetooth.

### MOSTRAR

La pantalla LED mostrará la siguiente información:

- Modo de entrada (muestra USB, TF, Bluetooth, AUX o FM)
- Cuando se inserta la unidad USB o la tarjeta TF, cambiará al modo USB/TF y comenzará a reproducir sus archivos de música formateados en MP3. Se mostrará el número de pista que se reproduce actualmente desde el USB/TF.
- En el modo de radio FM, se mostrarán los canales de la estación de radio FM. Presione brevemente el botón Reproducir/Pausa mientras está en modo FM para buscar automáticamente y guardar las estaciones de radio recibidas en su área.

### VERDADERO ESTÉREO INALÁMBRICO (TWS)

Dos altavoces QFX exactamente del mismo modelo se pueden emparejar y conectar a un dispositivo Bluetooth y ofrecer sonido estéreo inalámbrico verdadero (TWS). Para hacerlo:

- Encienda ambos altavoces
- Seleccione el modo Bluetooth en ambos altavoces
- Presione el botón Reproducir/Pausa en un solo altavoz durante 3 segundos. Luego los altavoces se conectarán entre sí.
- Luego, para conectarse a su dispositivo Bluetooth, busque el número de modelo QFX (QFX TMS-853, QFX-1253 o QFX-1553).
- Después de un emparejamiento exitoso, puede transmitir música de forma inalámbrica desde su dispositivo Bluetooth a ambos parlantes en True Wireless Stereo (TWS).
- Mantenga presionado TWS para salir del modo True Wireless Stereo.

### MANDO A DISTANCIA

- |        |   |                                     |
|--------|---|-------------------------------------|
| 1.     | <b>STANDBY:</b>   | pone la unidad en modo de espera.   |
| 2.     | <b>Botón de modo de entrada:</b>  | alternar entre USB, TF, FM, AUX, BT |
| 3.     | <b>Silenciar:</b>   | silencia la pista.                  |
| 4.     | <b>REPRODUCIR/PAUSAR</b>  |                                     |
| 5.     | <b>Pista anterior:</b>  | seleccione el canal anterior        |
| 6.     | <b>Siguiente pista:</b>   | seleccione el siguiente canal.      |
| 7.     | <b>EQ:</b>  | seleccione el modo EQ.              |
| 8.     | <b>VOL-:</b>  | Reduce el volumen principal.        |
| 9.     | <b>VOL+:</b>  | incrementa el volumen principal     |
| 10.    | <b>REP:</b>   | repite la pista en reproducción.    |
| 11.    | Presione para escanear canales en modo FM   | 12--21                              |
| 12-21. | Número de CLAVE para seleccionar la pista determinada para la unidad flash USB o la tarjeta TF. |                                     |





## LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at [www.qfxusa.com](http://www.qfxusa.com) for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.





This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

**QFX USA®, Inc.**  
RMA Processing  
Customer Support Department  
2957 E. 46th Street | Vernon, CA 90058

 support@qfxusa.com  
 (800) 864-CLUB (2582) or (323) 864-6900  
 qfxusa.com  
 Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2024 ©



**1-800-864-CLUB (2582)**  
**Mon-Fri 9AM - 5PM (PST)**



**support@qfxusa.com**  
**Mon-Fri 9AM - 5PM (PST)**



[www.qfxusa.com](http://www.qfxusa.com)

# THANK YOU.

**QFX** Where the Party Begins!

We would love to hear about your TMS Journey!  
Tag us **@QFXUSA** to share your stories.

**FOLLOW US @QFXUSA**

