



SAFETY PRECAUTIONS:

KEEP AWAY FROM CHILDREN.
AVOID WATER AND EXTREME CONDITIONS.
CLEAN GENTLY.
STORE IN A COOL, DRY PLACE.
NEVER DISPOSE IN FIRE.
PROTECT FROM SHARP OBJECTS AND DROPS.
DON'T TAKE IT APART.
CHARGE MONTHLY IF NOT IN USE.
USE INDOORS ONLY.
DON'T THROW THE BATTERY IN FIRE.
WARRANTY VOID IF TAMPERED WITH

PRECAUCIONES DE SEGURIDAD:

MANTENER FUERA DEL ALCANCE DE LOS NIÑOS.
EVITAR EL AGUA Y CONDICIONES EXTREMAS.
LIMPIAR SUAVEMENTE.
ALMACENAR EN UN LUGAR FRESCO Y SECO.
NO TIRAR AL FUEGO.
MANEJAR CON CUIDADO.
NO DESARMAR.
CARGAR MENSUALMENTE.
SOLO PARA USO EN INTERIORES.
NO DESECHAR LA BATERÍA EN EL PUEGO.
LA GARANTÍA SE ANULA SI SE MANIPULA O MODIFICA.

PRÉCAUTIONS DE SÉCURITÉ:

TENIR HORS DE PORTÉE DES ENFANTS. ÉVITER L'EAU ET LES CONDITIONS EXTRÉMES. NETTOYER DOUCEMENT. STOCKER DANS UN ENDROIT FRAIS ET SEC. NE PAS JETER AU FEU. MANIPULER AVEC PRÉCAUTION. NE PAS DÉMONTER. RECHARGER MENSUELLEMENT. USAGE INTÉRIEUR SEULEMENT. NE PAS JETER LA BATTERIE AU FEU. LA GARANTIE EST ANNULÉE SI MODIFIÉE.




BT-31 GUIDE / GUÍA / GUIDE

Press and Hold (1) to turn Speaker ON/OFF

Top of speaker:

- 1. Volume + / Next
- 2. Light switch
- 3. ON/OFF / Play/Pause / Answer Call
- 4. Mode
- 5. Volume / Previous





Parte superior del altavoz:

- 1. Volumen + / Siguiente
- 2. Interruptor de luz
- 3. Encendido / Apagado / Reproducir-Pausar / Contestar
- 4. Modo
- 5. Volumen / Anterior


() Maintenir enfoncé pour allumer/éteindre.

3 U M 5 U

Haut-parleur:

- 1. Volume + / Suivant
- 2. Interrupteur de lumière
- 3. Marche/Arrêt / Lecture-Pause / Répondre
- 4. Mode
- 5. Volume / Précédent

Speaker Inputs / Entradas del altavoz / Entrées du haut-parleur





Charging:

Connect the cable to the speaker and a charger.

Red light means charging, off when done (Takes 2-3 hours).

TF Mode:

Insert Micro SD Card. Music will automatically start to play.

USB Mode:

Insert a USB Flash Drive. Music will automatically start to play.

FM Radio:

Press "M" for radio.

- Use + or for stations.
- · Hold + or to adjust volume.

Bluetooth:

Activate Bluetooth on your device and search for "QFX BT-31". Select it from the list.

TWS Mode:

- 1. Hold down the "M" key to activate pairing on one device.
- 2. Then, do the same on the other device.
- 3. You'll hear a sound indicating a successful connection.

SPECIFICATIONS:

- · With FM, AUX, Bluetooth®, USB/TF card & TWS function
- Bluetooth®: V5.0
- Input: 5V
- Battery Capacity: 1200 mAh
- Charge time: up to 3 hours
 Play time: up to 2-3 hours
- Play time: up to 2-3 hours
 Standby time: up to 5 hours
- · Operating range: 33 feet (10m)
- Battery: 3.7V Built-in Li-ion
- · Compatible with most Bluetooth® enabled tablets and smartohones



Carga:

Conecta el cable al altavoz y al cargador. La luz roja indica carga; se apaga cuando está lista (2-3 horas).

Modo TF:

Inserta una tarjeta Micro SD. La música empezará sola.

Modo USB:

Inserta una memoria USB. La música empezará sola.

Radio FM:

Presiona "M" para la radio. Usa + o - para cambiar de estación. Mantén pulsado + o - para ajustar el volumen.

Bluetooth:

Activa Bluetooth y busca "QFX BT-31". Selecciona.

Modo TWS:

Mantén pulsada "M" en un dispositivo. Haz lo mismo en el otro. Oirás un sonido que confirma la conexión.

Chargement:

Branchez le câble au haut-parleur et à un chargeur.
La lumière rouge indique la charge; elle s'éteint quand c'est fini (2-3 heures).

Mode TF:

Insérez une carte Micro SD. La musique commence seule.

Mode USB:

Insérez une clé USB. La musique commence seule.

Radio FM:

Appuyez sur "M" pour la radio.

Utilisez + ou - pour changer de station.

Maintenez + ou - enfoncé pour ajuster le volume.

Bluetooth:

Activez Bluetooth et recherchez "QFX BT-31". Sélectionnez.

Mode TWS:

Maintenez "M" enfoncé sur un appareil.

Faites de même sur l'autre. Vous entendrez un son de confirmation de connexion.





LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qbusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the OFX Customer Support Department.

Subject to the terms and conditions herein, OFX, Inc., (herein after called "OFX") warrants to the original purchaser of the Product "Coustomer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as itside below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a delichel Perioduc for any component thereoft during the applicable Warranty Period. OFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either; (i) repair the Product for, as applicable, any component thereof) or (ii) replace the Product for, as applicable, any component thereof) with a new or refurbished Product for, as applicable, any component thereof) in either case free of charge to Customer for Parts andfor Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges forced below, for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and GFX sole liability for beach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. GPX is not responsible for warranty replacement should the GPX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by GPX in addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the afteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or mailunction of any device used with the Product (or, as applicable, any component thereof), (c) cosmetic damage to the Product (or, as applicable, any component thereof), (c) cosmetic damage to the Product (or, as applicable, any component thereof), (c) cosmetic damage to the Product (or, as applicable, any component thereof), (c) cosmetic damage to the Product (or, as applicable, any component thereof), (c) cosmetic damage to the Product (or, as applicable, any component thereof), (c) cosmetic damage to the Product (or, as applicable, any component thereof), (c) cosmetic damage to the Product (or, or or other cinatic conditions or (c) any acts of GOCI.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or iflesaving applications. GPX disclaims any Warranty for any of the foreigning uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnity OPX for any damages claimed against of CPX for such used.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE
PROVIDED" AS IS "AND ORS DISCLAMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (I) OF
MERCHANTABILITY, (II) OF FITNISS FOR A PARTICULAR PUPPOSE, OR (III) OF FON-HIPRINGEMENT OF THIRD PARTY RIGHTS, TO THE
MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL LOF SE LUBLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY
MOIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST
PROPIETS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF
LUBLILITY (INCLUDING NEGLICAENCE) AND EVEN IF OF HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, GRY AGRECATE
LUBLILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE
PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CALSING THE DAMAGES, FAY N.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warring: Some Products may contain components that are small enough to be seallowed. Please keep out of reach of children, in order for the nature to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and includer. (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, if a cashier's check or money order payable to QFX, Inc., in the amount specified for the lem in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.

RMA Processing Customer Support Department 2957 E. 46th Street | Vernon. CA 90058 support@gfxusa.com

(800) 864-CLUB (2582) or (323) 864-6900

gfxusa.com

O Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. GPX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telenhones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE, SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HERBIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, GFX SHALL NOT BE LIBBLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM THE USE OTHER LEAST. HEROY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from

jurisdiction to jurisdiction. Copyright Protected 2024 ©







THANK YOU.

QFX Where the Party Begins!

We would love to hear about your BT-31 Journey! Tag us @QFXUSA to share your stories.







