

CAM-26



INSTRUCTION MANUAL

WARNING!

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN

To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers or under extreme weather conditions. Clean only with a dry cloth. Users should exhibit extra safety when the WARNING or CAUTION symbol appears in this instruction manual and follow all precautions as they are stated.

¡ADVERTENCIA!

PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO quite la cubierta de este altavoz. No hay partes reparables por el usuario adentro. Remítir todo servicio a un técnico calificado

Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia ni a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor o bajo condiciones climáticas extremas. Limpiar solamente con un paño seco. Los usuarios deben mostrar una seguridad adicional cuando aparece el símbolo de ADVERTENCIA o PRECAUCIÓN en este manual de instrucciones y seguir todas las precauciones tal como se indican.


AVERTISSEMENT !

POUR RÉDUIRE LE RISQUE DE CHOC ÉLECTRIQUE, NE RETIREZ PAS LE CAPOT DE CET ENCEINTE. IL N'Y A AUCUNE PARTIE RÉPARABLE PAR L'UTILISATEUR À L'INTÉRIEUR. CONFIEZ TOUTE RÉPARATION À UN TECHNICIEN QUALIFIÉ.

Pour éviter les incendies ou les chocs électriques, n'exposez pas cet appareil à la pluie ou à l'humidité. Ne stockez ni n'utilisez ce produit à proximité de liquides, de sources de chaleur comme des radiateurs, des registres de chaleur ou dans des conditions climatiques extrêmes. Nettoyez uniquement avec un chiffon sec. Les utilisateurs doivent faire preuve de prudence lorsqu'ils voient le symbole d'AVERTISSEMENT ou de PRÉCAUTION dans ce manuel d'instructions et suivre toutes les précautions telles qu'indiquées.

CONNECTIONS

Position the CAM-26 over the car mirror and secure it using the two elastic bands as shown:



Elastic Bands / Bandas elásticas

CONEXIONES

Coloque el CAM-26 sobre el espejo del automóvil y fíjelo usando las dos bandas elásticas como se muestra:

Connect the included backup camera to the device as shown:



Conecte la cámara de respaldo incluida al dispositivo como se muestra:

Thank you for purchasing the QFX CAM-26. Please refer these instructions to gain a better understand of its functions and operation.



1. USB Input: Connect the supplied USB side of the Car 12VDC-to-mini USB cable to this input.
2. AV Input: Connect the supplied backup camera cable to this input or 3.5mm stereo audio cable.
3. TF Card Slot: insert a TF card with media files stored on (music, photos, images, videos, etc.).
4. GPS: GPS port.
5. Mounting Clips: Align the CAM-26 unit in front of your rear view mirror and use the supplied rubber elastic bands (#6) to secure it to the mounting clips and behind your rear view mirror.
6. Rubber Elastic Band x 2
7. Power ON/OFF Switch
8. Reset Button: Using a paper clip or small point pen/pencil, press to reset the system to the its default setting.
9. High Definition Front View Camera with Slide-out Positioning
10. Video Screen Display
11. Onscreen Display

OPERATION

- Insert a high-speed TF card into the TF card slot (3) in order to record and playback video, photos, etc. NOTE: If your TF card is not recording properly, go to the Settings menu, toggle to the "Format" function to reformat the TF card.

Onscreen Display (10) Functions/Controls

- Once the unit is connected to automobile power connection to the USB port using the supplied cable, the unit will start to record video (Red on-screen button). You can stop video (press again and changes to White on-screen button).
- Select the on-screen functions to operate the device.
 - Functions: Record Video, Take Photo, Microphone ON/OFF, Lock, Playback, Settings, Set Screen Brightness, Antenna Wireless Strength, USB Connection, Time/Date Display
 - If the device functions become unstable for any reason, you can press the reset button (8) to restart the device.

The images below show the Settings menus that you can toggle through to adjust specific parameters and or to move up or down the menu list. Here of Settings menu names and functions:

Date/Time Display	Year, Month, Day, Day
Resolution	2K, 1440P or 1080P
Loop Recording	1 minute, 3 minutes, 5 minutes, OFF
Exposure	-3 to +3 in increments of 1
Screen Saver	OFF, 1 minute, 2 minutes
Key Sound	ON or OFF
Format	Press "Confirm" to format TF card
Language	Choose your preferred language
Default	Reset unit to factory default settings
Version	Version Display ON or OFF
Pull Images	Original image, Image
WiFi	WiFi ON/OFF. Scan QR Code to run App.

SETTINGS MENUS


If you want to connect the device to a PC, there are three modes that you can choose from once you are connected to the powered USB port on the PC. These include:

- Mass Storage: you can copy/paste files to/from the TF card.
- PC Camera: you may use device as a PC-connected camera.
- REC Mode: navigates to the same initial screen as power-up from a PC.

Gracias por adquirir la cámara QFX CAM-26. Consulte estas instrucciones para comprender mejor sus funciones y su funcionamiento.



1. Entrada USB: Conecte el lado USB provisto del cable de 12 V CC a mini USB del automóvil a esta entrada.
2. Entrada AV: Conecte el cable de la cámara de respaldo provisto a esta entrada o el cable de audio estéreo de 3,5 mm.
3. Ranura para tarjeta TF: inserte una tarjeta TF con archivos multimedia almacenados (música, fotos, imágenes, videos, etc.).
4. GPS: puerto GPS.
5. Clips de montaje: Alinee la unidad CAM-26 frente a su espejo retrovisor y use las bandas elásticas de goma provistas (#6) para asegurarla a los clips de montaje y detrás de su espejo retrovisor.
6. Banda elástica de goma x 2
7. Interruptor de encendido/apagado
8. Botón de reinicio: Con un clip o un bolígrafo o lápiz pequeño, presione para restablecer el sistema a su configuración predeterminada.
9. Cámara de visión frontal de alta definición con posicionamiento deslizable
10. Pantalla de video
11. Pantalla en pantalla

OPERACIÓN

- Inserte una tarjeta TF de alta velocidad en la ranura para tarjetas TF (3) para grabar y reproducir videos, fotos, etc. NOTA: Si su tarjeta TF no graba correctamente, vaya al menú Configuración y cambie a la función "Formato" para reformatear la tarjeta TF.

Visualización en pantalla (10) Funciones/Controles

- Una vez que la unidad esté conectada a la toma de corriente del automóvil al puerto USB mediante el cable suministrado, la unidad comenzará a grabar video (botón rojo en pantalla). Puede detener el video (presione nuevamente y cambiará al botón blanco en pantalla).
- Seleccione las funciones en pantalla para operar el dispositivo.
 - Funciones: Grabar video, Tomar foto, Activar/desactivar micrófono, Bloquear, Reproducir, Configuraciones, Establecer brillo de pantalla, Intensidad inalámbrica de antena, Conexión USB, Visualización de fecha y hora
 - Si las funciones del dispositivo se vuelven inestables por algún motivo, puede presionar el botón de reinicio (8) para reiniciar el dispositivo.

Las imágenes a continuación muestran los menús de configuración que puede recorrer para ajustar parámetros específicos o para desplazarse hacia arriba o hacia abajo en la lista de menús. A continuación, se muestran los nombres y funciones del menú de configuración:

Fecha/Hora Visualización	Año, Mes, Día, Día
Resolución	2K, 1440P o 1080P
Grabación en bucle	1 minuto, 3 minutos, 5 minutos, OFF
Exposición	-3 a +3 en incrementos de 1
Protector de pantalla	OFF, 1 minuto, 2 minutos
Sonido de teclas	ON o OFF
Formato	Presione "Confirmar" para formatear la tarjeta TF
Idioma	Elija su idioma preferido
Predeterminado	Restablecer la unidad a la configuración predeterminada de fábrica
Versión	Versión Visualización ON o OFF
Extraer imágenes	Imagen original, Imagen
WiFi WiFi	ON/OFF. Escanee el código QR para ejecutar la aplicación.

MENÚS DE CONFIGURACIÓN



Si desea conectar el dispositivo a una PC, hay tres modos que puede elegir una vez que esté conectado al puerto USB con alimentación de la PC. Estos son:

- Almacenamiento masivo: puede copiar y pegar archivos hacia y desde la tarjeta TF.
- Cámara para PC: puede usar el dispositivo como una cámara conectada a una PC.
- Modo de grabación: navega a la misma pantalla inicial que al encender el dispositivo desde una PC.



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(800) 864-CLUB (2582) or (323) 864-6900
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your prouuct or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth Speakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2024 ©


1-800-864-2582
Mon-Fri 9AM - 5PM (PST)


support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)



www.qfxusa.com

THANK YOU.

QFX Where the Party Begins!

We would love to hear about your CAM-26 Journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

