

HP-E140



INSTRUCTION MANUAL

Key Operating Instructions

⏻: Press and hold for 3 seconds to power on and power off.

📞: Press to answer calls.

📞: Press and hold to reject calls.

📞: Press twice to redial last call.

⏮: Press to Play/Pause music.

In FM mode, press to search FM stations.

⏮: Press and hold to decrease volume.

⏮: In Wireless/MP3 mode press for previous track.

⏮: In FM mode Press to tune to the previous station.

⏭: Press and hold to increase volume.

⏭: In Wireless/MP3 mode press for next track.

⏭: In FM mode Press to tune to the next station.

M: Mode switching button (Bluetooth, MP3, and FM Player)

LED Indicator

1. In pairing mode red & blue light will rapidly flash.

When pairing is complete blue light will gradually flash.

2. In MP3 mode the blue light will gradually flash while playing music.

3. In FM mode when listening to the radio station blue light will stay on.


When searching for radio station blue light will rapidly be flashing.

4. When charging the red light will gradually flash.

When charging is complete the red light will change turn blue.

Connecting Auxiliary port

1. Insert audio line directly to the AUX port for a wired connection.



There are many ways to enjoy your QFX headphones:

1. Wirelessly connect via Bluetooth (search on your device and connect to "QFX HP-E140") and then listen to streaming music or conduct mobile phone calls.
2. You can connect an audio source to the AUX jack using a 3.5mm stereo mini cable.
3. Insert a TF card with MP3 formatted songs on it and play for hours of uninterrupted music listening.
4. Play FM radio stations.

CHARGING

- Plug in the includes USB cable to a powered USB port. Recharging time is 2 hours.
- Turn off the headphones when not in use. But if you keep power ON, the headphones can remain powered for up to 18 hours.
- Operating time on a full charge is up to 6 hours based on usage (Bluetooth music/calls, TF music player, FM radio, AUX input, etc.)

Instrucciones de funcionamiento

- ⏻: Presione por 3 segundos para encender y apagar.
 - ▶||: Presione para contestar llamadas.
 - ||◀: Mantenga presionado para rechazar llamada.
 - ▶||: Presione dos veces para volver a marcar la última llamada.
 - ||◀: Presione para reproducir/pausar música.
- En el modo FM, presione para buscar estaciones de FM.

- ◀◀: Mantenga presionado para bajar el volumen.
- ◀◀: In Wireless/MP3 mode press for previous track.
- ◀◀: En modo inalámbrico/MP3, presione para ver la pista anterior.

- ▶▶: En modo inalámbrico/MP3, presione para ver la pista anterior.
- ▶▶: En modo inalámbrico/MP3 presione para la siguiente pista.
- ▶▶: En modo FM Presione para sintonizar la siguiente estación.

M: En modo FM Presione para sintonizar la siguiente estación

Indicador LED

1. En el modo de emparejamiento, la luz roja y azul parpadeará rápidamente.
Cuando se complete el emparejamiento, la luz azul parpadeará gradualmente.
2. En el modo MP3, la luz azul parpadeará gradualmente mientras se reproduce música.
3. En modo FM Cuando escuche la estación de radio, la luz azul permanecerá encendida.
Cuando busque una estación de radio, la luz azul parpadeará rápidamente.
4. Al cargar, la luz roja parpadeará gradualmente.
Cuando se complete la carga, la luz roja cambiará a azul.

Conexión auxiliar

1. Inserte la línea de audio directamente al puerto AUX para una conexión por cable.
La conexión por cable puede desactivar los botones de acceso directo.

Hay muchas formas de disfrutar de tus auriculares QFX:

1. Conéctalos de forma inalámbrica a través de Bluetooth (busca en tu dispositivo y conéctate a "QFX HP-E140") y luego escucha música en streaming o realiza llamadas telefónicas.
2. Puedes conectar una fuente de audio al conector AUX utilizando un cable mini estéreo de 3.5 mm.
3. Inserta una tarjeta TF con canciones en formato MP3 y reproduce horas de música sin interrupciones.
4. Escucha estaciones de radio FM.

CARGA

- Conecta el cable USB incluido a un puerto USB con energía. El tiempo de carga es de 2 horas.
- Apaga los auriculares cuando no los estés usando. Pero si los mantienes encendidos, pueden permanecer encendidos durante hasta 18 horas.
- El tiempo de funcionamiento con una carga completa es de hasta 6 horas según el uso (música/llamadas Bluetooth, reproductor de música TF, radio FM, entrada AUX, etc.).



Instructions d'utilisation clés

⏻ : Appuyez et maintenez pendant 3 secondes pour allumer et éteindre.

⏮ : Appuyez pour répondre aux appels.

⏮ : Appuyez et maintenez pour rejeter les appels.

⏮ : Appuyez deux fois pour recomposer le dernier appel.

⏮ : Appuyez pour lire/mettre en pause la musique.

En mode FM, appuyez pour rechercher des stations FM.

⏪ : Appuyez et maintenez pour diminuer le volume.

⏪ : En mode sans fil/MP3, appuyez sur la piste précédente.

⏪ : En mode FM Appuyez pour syntoniser la station précédente.

⏩ : Appuyez et maintenez pour augmenter le volume.

⏩ : En mode sans fil/MP3, appuyez pour accéder à la piste suivante.

⏩ : En mode FM Appuyez pour syntoniser la station suivante.

M : Bouton de changement de mode (Bluetooth, MP3 et FM Player)

Indicateur LED

1. En mode d'appairage, les voyants rouge et bleu clignoteront rapidement.

Une fois l'appairage terminé, la lumière bleue clignote progressivement.

2. En mode MP3, la lumière bleue clignote progressivement pendant la lecture de musique.

3. En mode FM Lorsque vous écoutez la station de radio, la lumière bleue reste allumée. Lors de la recherche d'une station de radio, la lumière bleue clignote rapidement.

4. Lors du chargement, le voyant rouge clignote progressivement.

Une fois la charge terminée, le voyant rouge deviendra bleu.

Connexion au port auxiliaire

1. Insérez la ligne audio directement dans le port AUX pour une connexion filaire.

La connexion filaire peut désactiver les boutons de raccourci.

Il y a plusieurs façons de profiter de vos écouteurs QFX :

1. Connectez-les sans fil via Bluetooth (recherchez sur votre appareil et connectez-vous à "QFX HP-E140") puis écoutez de la musique en streaming ou passez des appels téléphoniques.

2. Vous pouvez connecter une source audio à la prise AUX en utilisant un câble mini-stéréo de 3,5 mm.

3. Insérez une carte TF avec des chansons au format MP3 et écoutez de la musique pendant des heures sans interruption.


4. Écoutez des stations de radio FM.

CHARGEMENT

• Branchez le câble USB fourni dans un port USB alimenté. Le temps de chargement est de 2 heures.

• Éteignez les écouteurs lorsque vous ne les utilisez pas. Mais s'ils restent allumés, ils peuvent rester allumés pendant jusqu'à 18 heures.

• Le temps de fonctionnement sur une charge complète est de jusqu'à 6 heures en fonction de l'utilisation (musique/appels Bluetooth, lecteur de musique TF, radio FM, entrée AUX, etc.).





LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(800) 864-CLUB (2582) or (323) 864-6900
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your prouuct or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2024 ©


1-800-864-2582
Mon-Fri 9AM - 5PM (PST)


support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)



www.qfxusa.com

THANK YOU.

QFX Where the Party Begins!

We would love to hear about your HP-E140 Journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

