

MPX-1202



INSTRUCTION MANUAL

## Warning!

To reduce the risk of electric shock, do not remove the cover on this speaker. There are no user-serviceable parts inside. Seek service from a qualified technician. To prevent fires or electric shock, do not expose this equipment to rain or moisture. Do not store or use this product near liquids, heat sources such as radiators, or heat accumulators. Clean only with a dry cloth. Users should exercise additional caution when this symbol appears in this instruction manual and follow all precautions as specified.

## ¡Advertencia!

PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO quite la cubierta en este altavoz. No hay partes reparables por el usuario adentro. SOLICITE EL SERVICIO A UN TÉCNICO CALIFICADO Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia o la humedad. No almacene o utilice este producto cerca de líquidos, fuentes de calor, como radiadores, acumuladores de calor. Limpie sólo con un paño seco. Los usuarios deben exhibir una seguridad adicional cuando este símbolo aparece en este manual de instrucciones y siga todas las precauciones, ya que se han precisado.

## Attention !

Pour réduire le risque de choc électrique, ne retirez pas le couvercle de ce haut-parleur. Il n'y a pas de pièces réparables par l'utilisateur à l'intérieur. Faites appel à un technicien qualifié pour le service. Pour éviter les incendies ou les chocs électriques, ne exposez pas cet équipement à la pluie ou à l'humidité. Ne pas stocker ou utiliser ce produit près de liquides, de sources de chaleur telles que les radiateurs ou les accumulateurs de chaleur. Nettoyez uniquement avec un chiffon sec. Les utilisateurs doivent faire preuve d'une prudence supplémentaire lorsque ce symbole apparaît dans ce manuel d'instructions et suivre toutes les précautions spécifiées.

### MPX-1202 DISPLAY SYSTEM SETTINGS

Input Mode: The LED display will show input mode information for USB/TF/BT/AUX/FM. When a USB flash memory card/TF card unit is inserted into the USB/TF input, the unit automatically switches to USB/TF mode and starts playing .mp3 audio files from the USB flash card unit/TF.

Track Number: The number of the track playing from the USB/TF will be displayed.

FM Mode: All FM channels are displayed here. Press the "play/pause" button to automatically scan all.

### MPX-1202 AJUSTES DEL SISTEMA DE PANTALLA

1. Modo de entrada: La pantalla LED mostrará la información del modo de entrada para USB / TF/BT/ AUX / FM. Cuando se inserta una unidad de tarjeta de memoria flash USB / TF en la entrada USB /TF, la unidad automáticamente cambiará al modo USB / TF y comenzará la reproducción de archivos de audio.mp3 del flash USB Card unidad / TF.
2. Track Número: El número que se está reproduciendo de la pista USB / TF se mostrará Modo
3. FM: Todos los canales de FM pantalla aquí. Presione el botón "reproducir / pausa" para escanear automáticamente todos los canales

### MPX-1202 PARAMÈTRES DU SYSTÈME D'AFFICHAGE

1. Mode d'entrée : L'affichage LED affichera les informations du mode d'entrée pour USB/TF/BT/AUX/FM. Lorsqu'une unité de carte mémoire flash USB/TF est insérée dans l'entrée USB/TF, l'unité passe automatiquement en mode USB/TF et commence la lecture des fichiers audio .mp3 de l'unité de carte flash USB/TF.
2. Numéro de piste : Le numéro de la piste en cours de lecture depuis l'USB/TF sera affiché.
3. Mode FM : Tous les canaux FM sont affichés ici. Appuyez sur le bouton "lecture/pause" pour scanner automatiquement tous les canaux.

## Charging

Connect the USB-C cable to the Micro-USB port. Connect the other end of the USB cable to a 5V, 1A power source (PC USB port, AC USB adapter, etc.). Watch the charging status indicator near the volume power knob.

## Bluetooth

Turn on the speaker, and it will automatically be in Bluetooth ready mode. Enable your Bluetooth device and connect to "QFX MPX-1202". After pairing the device, you can stream music from your device.

## USB/TF Card

Connect a USB drive or TF card with MP3 music files to enjoy for hours. Press the "▶||" button to play/pause music. Press the "◀◀" or "▶▶" button to go to the previous or next track. Adjust the volume knob to set the desired sound level.

## AUX Input

In AUX mode, connect an external audio device to the AUX input and adjust the volume as needed.

## FM Radio

In FM mode, press "▶||" to automatically search for FM channels. This operation will scan all FM stations and save them in memory. The scanning process will take several minutes and cannot be interrupted. Once completed, you can press the "◀◀" or "▶▶" buttons to advance or go back to radio stations. Adjust the volume knob to set the desired sound level.

## TWS Connection

You must have two MPX-1202 speakers to set up True Wireless Stereo (TWS) operation. Turn on the power for both units. Search for and select "QFX MPX-1202" from the Bluetooth devices list on your mobile Bluetooth device. Once both units are connected/paired, press the ▶||/TWS button on one speaker for a few seconds. Then, both speakers will automatically connect in True Wireless Stereo (TWS) mode. Your Bluetooth music will now play in discrete L/R stereo from both speakers.

## CONTROL PANEL

LED Display: Displays the current mode or function.

POWER ON/OFF/Volume: Turn the knob to power on and off the unit and control the speaker volume.

DC-5V: USB-C charging port.

BASS: Adjusts the bass level.

TREBLE: Adjusts the treble level.

▶▶: In FM/USB/TF/Bluetooth modes, press to go to the next channel/track. Press and hold to fast forward through the song file.

▶|| TWS: In USB/TF/Bluetooth modes, press to play and pause music.

◀◀: In FM/USB/TF/Bluetooth modes, press to go to the previous channel or track. Press and hold to rewind through the song file.


MODE/LED ON: Press to switch between various modes (Bluetooth, USB, TF, AUX, FM radio). Press and hold to TURN ON or TURN OFF the party LED lights.

TF Slot: Connect a USB drive with MP3 music files to enjoy for hours.

USB Port: Connect a USB drive with MP3 music files to enjoy for hours.

AUX: Connect an external audio device to this 3.5mm input.

MIC IN: Connect a wired microphone to this input.



## Cargando

Conecta el cable USB-C al puerto Micro-USB. Conecta el otro extremo del cable USB a una fuente de alimentación de 5V, 1A (puerto USB de la PC, adaptador USB de CA, etc.). Observa el indicador de estado de carga cerca de la perilla de volumen.

## Bluetooth

Enciende el altavoz y automáticamente estará en modo Bluetooth listo. Habilita tu dispositivo Bluetooth y conéctate a "QFX MPX-1202". Después de emparejar el dispositivo, puedes transmitir música desde tu dispositivo.

## Tarjeta USB/TF

Conecta una unidad USB o una tarjeta TF con archivos de música MP3 para disfrutar durante horas. Presiona el botón "▶||" para reproducir/pausar música. Presiona el botón "◀◀" o "▶▶" para ir a la pista anterior o siguiente. Ajusta la perilla de volumen para establecer el nivel de sonido deseado.

## Entrada AUX

En modo AUX, conecta un dispositivo de audio externo a la entrada AUX y ajusta el volumen según sea necesario.

## Radio FM


En modo FM, presiona "▶||" para buscar automáticamente los canales de FM. Esta operación escaneará todas las estaciones de FM y las guardará en la memoria. El proceso de escaneo tomará varios minutos y no se puede interrumpir. Una vez completado, puedes presionar los botones "◀◀" o "▶▶" para avanzar o retroceder a las estaciones de radio. Ajusta la perilla de volumen para establecer el nivel de sonido deseado.

## Conexión TWS

Debes tener dos altavoces MPX-1202 para configurar la operación de True Wireless Stereo (TWS). Enciende la alimentación para ambas unidades. Busca y selecciona "QFX MPX-1202" en la lista de dispositivos Bluetooth en tu dispositivo Bluetooth móvil. Una vez que ambas unidades estén conectadas/emparejadas, presiona el botón ▶||/TWS en uno de los altavoces durante unos segundos. Luego, ambos altavoces se conectarán automáticamente en modo True Wireless Stereo (TWS). Tu música Bluetooth ahora se reproducirá en estéreo L/R discreto desde ambos altavoces.

## PANEL DE CONTROL

1. Pantalla LED: Muestra el modo o función actual.
2. APAGADO/ENCENDIDO/Volumen: Gire la perilla para encender y apagar la unidad y controlar el volumen del altavoz.
3. DC-5V: puerto de carga USB-C.
4. BASS: Ajusta el nivel de graves.
5. AGUDOS: Ajusta el nivel de agudos.
6. ▶▶: En modo FM/USB/TF/Bluetooth, presione para pasar al siguiente canal/pista. Mantenga presionado para avanzar a través del archivo de canción.
7. ▶||: En los modos USB/TF/Bluetooth, presione para reproducir y pausar la música.
8. ◀◀: En los modos FM/USB/TF/Bluetooth, presione para pasar al canal o pista anterior. Mantenga presionado para avanzar hacia atrás a través del archivo de canción.
9. MODO/LED ENCENDIDO: Presione para cambiar varios modos (Bluetooth, USB, TF, AUX, radio FM). Mantenga presionado para ENCENDER o APAGAR las luces LED de fiesta.
10. Ranura TF: conecte una unidad USB con archivos de música MP3 para disfrutar durante horas.
11. Puerto USB: conecte una unidad USB con archivos de música MP3 para disfrutar durante horas.
12. AUX: conecte un dispositivo de audio externo a esta entrada de 3,5 mm.
13. MIC IN: Conecte un micrófono con cable a esta entrada.



### En cours de chargement

Connectez le câble USB-C au port Micro-USB. Connectez l'autre extrémité du câble USB à une source d'alimentation 5V, 1A (port USB de l'ordinateur, adaptateur USB secteur, etc.). Surveillez l'indicateur d'état de charge près du bouton de réglage du volume.

### Bluetooth

Allumez le haut-parleur, il sera automatiquement en mode Bluetooth prêt. Activez votre appareil Bluetooth et connectez-vous à "QFX MPX-1202". Après avoir apparié l'appareil, vous pouvez diffuser de la musique depuis votre appareil.

### Carte USB/TF

Connectez une clé USB ou une carte TF contenant des fichiers musicaux MP3 pour des heures de plaisir. Appuyez sur le bouton "►||" pour lire/mettre en pause la musique. Appuyez sur les boutons "◀◀" ou "▶▶" pour passer à la piste précédente ou suivante. Ajustez le bouton de volume pour régler le niveau sonore désiré.

### Entrée AUX

En mode AUX, connectez un appareil audio externe à l'entrée AUX et ajustez le volume selon vos besoins.

### Radio FM


En mode FM, appuyez sur "►||" pour rechercher automatiquement les canaux FM. Cette opération scannera toutes les stations FM et les enregistrera en mémoire. Le processus de numérisation prendra plusieurs minutes et ne peut pas être interrompu. Une fois terminé, vous pouvez appuyer sur les boutons "◀◀" ou "▶▶" pour avancer ou reculer entre les stations de radio. Ajustez le bouton de volume pour régler le niveau sonore désiré.

### Connexion TWS

Vous devez avoir deux haut-parleurs MPX-1202 pour configurer l'opération de Stéréo Sans Fil Véritable (TWS). Allumez l'alimentation pour les deux unités. Recherchez et sélectionnez "QFX MPX-1202" dans la liste des appareils Bluetooth de votre appareil Bluetooth mobile. Une fois que les deux unités sont connectées/appairées, appuyez sur le bouton ►||/TWS sur un haut-parleur pendant quelques secondes. Ensuite, les deux haut-parleurs se connecteront automatiquement en mode Stéréo Sans Fil Véritable (TWS). Votre musique Bluetooth sera maintenant diffusée en stéréo L/R discret à partir des deux haut-parleurs.

## PANNEAU DE CONTRÔLE

1. Affichage LED : affiche le mode ou la fonction actuelle.
2. OFF/ON/Volume : Tournez le bouton pour allumer et éteindre l'appareil et contrôler le volume du haut-parleur.
3. DC-5V : port de chargement USB-C.
4. BASS : Règle le niveau des basses.
5. TREBLE : Règle le niveau des aigus.
6. ►|| : En mode FM/USB/TF/Bluetooth, appuyez pour passer à la chaîne/piste suivante. Maintenez enfoncé pour avancer dans le fichier de chanson.
7. ►|| TWS : En modes USB/TF/Bluetooth, appuyez pour lire et mettre en pause la musique.
8. ◀◀ : En modes FM/USB/TF/Bluetooth, appuyez pour passer à la chaîne ou à la piste précédente. Maintenez enfoncé pour avancer en arrière dans le fichier de chanson.
9. MODE/LED allumée : appuyez pour changer de mode (Bluetooth, USB, TF, AUX, radio FM). Appuyez et maintenez enfoncé pour allumer ou éteindre les lumières de fête LED.
10. Emplacement TF : branchez une clé USB avec des fichiers musicaux MP3 pour des heures de plaisir.
11. Port USB : branchez une clé USB contenant des fichiers musicaux MP3 pour des heures de plaisir.
12. AUX : connectez un périphérique audio externe à cette entrée 3,5 mm.
13. MIC IN : connectez un microphone filaire à cette entrée.





## LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at [www.qfxusa.com](http://www.qfxusa.com) for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

**QFX USA®, Inc.**  
RMA Processing  
Customer Support Department  
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com  
(800) 864-CLUB (2582) or (323) 864-6900  
qfxusa.com  
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your prouuct or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

| PRODUCT CATEGORY                                                  | HANDLING | LABOR  | PARTS  |
|-------------------------------------------------------------------|----------|--------|--------|
| Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers | \$5.00   | 1 Year | 1 Year |
| Personal Stereos                                                  | \$10.00  | 1 Year | 1 Year |
| Portable Radio/Cassette                                           | \$15.00  | 1 Year | 1 Year |
| Large Portable Radio Cassette                                     | \$20.00  | 1 Year | 1 Year |
| Mobile Audio                                                      | \$10.00  | 1 Year | 1 Year |
| Pro Audio SBX Systems                                             | \$75.00  | 1 Year | 1 Year |
| Pro Audio PBX Systems                                             | \$75.00  | 1 Year | 1 Year |
| Televisions                                                       | \$25.00  | 1 Year | 1 Year |
| Telephones                                                        | \$10.00  | 1 Year | 1 Year |

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2024 ©

  
1-800-864-2582  
Mon-Fri 9AM - 5PM (PST)

  
support@qfxusa.com  
Mon-Fri 9AM - 5PM (PST)



[www.qfxusa.com](http://www.qfxusa.com)

# THANK YOU.

**QFX** Where the Party Begins!

We would love to hear about your MPX-1202 Journey!  
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

