



WHERE THE PARTY BEGINS™



INSTRUCTION MANUAL



WARNING!



TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN

To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers or under extreme weather conditions. Clean only with a dry cloth. Users should exhibit extra safety when the WARNING or CAUTION symbol appears in this instruction manual and follow all precautions as they are stated.



¡ADVERTENCIA!



PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO quite la cubierta de este altavoz. No hay partes reparables por el usuario adentro. Remitir todo servicio a un técnico calificado

Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia ni a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor o bajo condiciones climáticas extremas. Limpiar solamente con un paño seco. Los usuarios deben mostrar una seguridad adicional cuando aparece el símbolo de ADVERTENCIA o PRECAUCIÓN en este manual de instrucciones y seguir todas las precauciones tal como se indican.



AVERTISSEMENT !



POUR RÉDUIRE LE RISQUE DE CHOC ÉLECTRIQUE, NE RETIREZ PAS LE CAPOT DE CET ENCEINTE. IL N'Y A AUCUNE PARTIE RÉPARABLE PAR L'UTILISATEUR À L'INTÉRIEUR. CONFIEZ TOUTE RÉPARATION À UN TECHNICIEN QUALIFIÉ.


Pour éviter les incendies ou les chocs électriques, n'exposez pas cet appareil à la pluie ou à l'humidité. Ne stockez ni n'utilisez ce produit à proximité de liquides, de sources de chaleur comme des radiateurs, des registres de chaleur ou dans des conditions climatiques extrêmes. Nettoyez uniquement avec un chiffon sec. Les utilisateurs doivent faire preuve de prudence lorsqu'ils voient le symbole d'AVERTISSEMENT ou de PRÉCAUTION dans ce manuel d'instructions et suivre toutes les précautions telles qu'indiquées.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

FCC ID: 2AOMX-BTR4567

1. LED FLASHLIGHT SWITCH
2. DC 5V INPUT
3. AUX INPUT
4. TF CARD SLOT
5. CHARGE LED
6. USB PORT
 - Charge an external device or play your favorite tunes
7. PLAYER LED
8. MODE
9. PREV
10. PLAY/PAUSE
11. NEXT
12. TELESCOPIC ANTENNA
13. BAND SWITCH
14. LED FLASHLIGHT
15. RADIO DISPLAY
16. SPEAKER
17. TUNING
18. VOLUME
19. BATTERY COMPARTMENT
20. SOLAR PANEL



RADIO OPERATION

1. Choose Your Band: Use the band switch to select between MP3, FM, AM, SW, or BT.
2. Set the Volume: Turn the "TUNING" button to adjust the volume to your desired level.
3. Adjust Antenna: Position the antenna for optimal reception.
4. Turn Off the Radio: To switch off the radio, turn the "VOLUME" knob to the lowest setting.
5. Light Control: Use the lamp switch button to turn the light on and off.

USB/ TF OPERATION

1. Turn On the Radio: Power on the device.
2. Insert USB or TF Card: Insert your USB drive or TF card with your music files.
3. Select Music: Use the ◀◀ or ▶▶ buttons to navigate through your music selection.
4. Play or Pause: Press the ▶|| button to play or pause the music.
5. Adjust Volume: Turn volume knob to decrease or increase volume.


BLUETOOTH AUDIO

Select the MP3 BT switch setting. Enable Bluetooth on your mobile device and pair it to "QFX RETRO-15". Once paired, you can stream music from your Bluetooth device and hear it through the radio's speaker.

AUX INPUT

Connect the output of an external audio device to the AUX input jack. The unit will automatically enter AUX mode. Play audio/music from your external audio device and listen to it through the radio's speaker.

1. INTERRUPTOR DE LINTERNA LED
2. ENTRADA DE CC DE 5 V
3. ENTRADA AUXILIAR
4. RANURA PARA TARJETA TF
5. LED DE CARGA
6. PUERTO USB
 - Carga un dispositivo externo o reproduce tus canciones favoritas
7. LED DE REPRODUCTOR
8. MODO
9. ANTERIOR
10. REPRODUCCIÓN/PAUSA
11. SIGUIENTE
12. ANTENA TELESCÓPICA
13. CAMBIADOR DE BANDA
14. LINTERNA LED
15. PANTALLA DE RADIO
16. PARAVOZ
17. SINTONIZACIÓN
18. VOLUMEN
19. COMPARTIMIENTO DE BATERÍA
20. PANEL SOLAR



FUNCIONAMIENTO DE RADIO


1. Seleccione su banda: utilice el interruptor de banda para seleccionar entre MP3, FM, AM, SW o BT.
2. Ajuste el volumen: gire el botón "TUNING" para ajustar el volumen al nivel deseado.
3. Ajuste la antena: coloque la antena para una recepción óptima.
4. Apague la radio: para apagar la radio, gire la perilla "VOLUME" al ajuste más bajo.
5. Control de la luz: utilice el botón del interruptor de la lámpara para encender y apagar la luz.

USB/ TF OPERATION

1. Encender la radio: Encender el dispositivo.
2. Insertar USB o tarjeta TF: Insertar la unidad USB o tarjeta TF con los archivos de música.
3. Seleccionar música: Utilizar los botones ◀◀ o ▶▶ para navegar por la selección de música.
4. Reproducir o pausar: Pulsar el botón ▶|| para reproducir o pausar la música.
5. Ajustar el volumen: Girar la perilla de volumen para aumentar o disminuir el volumen.

1. INTERRUPTEUR DE LAMPE DE POCHE À LED
2. ENTRÉE CC 5 V
3. ENTRÉE AUX
4. EMPLACEMENT POUR CARTE TF
5. DEL DE CHARGE
6. PORT USB

- Chargez un appareil externe ou écoutez vos morceaux préférés

7. DEL DU LECTEUR
8. MODE
9. PRÉCÉDENT
10. LECTURE/PAUSE
11. SUIVANT
12. ANTENNE TÉLESCOPIQUE
13. COMMUTATEUR DE BANDE
14. LAMPE DE POCHE À LED
15. AFFICHAGE RADIO
16. HAUT-PARLEUR
17. RÉGLAGE
18. VOLUME
19. COMPARTIMENT DE PILES
20. PANNEAU SOLAIRE

FONCTIONNEMENT RADIO

1. Choisissez votre bande : utilisez le commutateur de bande pour sélectionner entre MP3, FM, AM, SW ou BT.
2. Réglez le volume : tournez le bouton « TUNING » pour régler le volume au niveau souhaité.
3. Réglez l'antenne : positionnez l'antenne pour une réception optimale.
4. Éteignez la radio : pour éteindre la radio, tournez le bouton « VOLUME » sur le réglage le plus bas.
5. Contrôle de l'éclairage : utilisez le bouton de l'interrupteur de la lampe pour allumer et éteindre la lumière.

USB/ TF OPERATION

1. Allumer la radio : Allumez l'appareil.
2. Insérer une clé USB ou une carte TF : Insérez votre clé USB ou votre carte TF contenant vos fichiers musicaux.
3. Sélectionner de la musique : Utilisez les boutons ◀◀ ou ▶▶ pour parcourir votre sélection musicale.
4. Lecture ou pause : Appuyez sur le bouton ▶▶ pour lire ou mettre en pause la musique.
5. Régler le volume : Tournez le bouton de volume pour diminuer ou augmenter le volume.



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(800) 864-CLUB (2582) or (323) 864-6900
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your prouuct or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025 ©



1-800-864-2582
Mon-Fri 9AM - 5PM (PST)



support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)



www.qfxusa.com

THANK YOU.

QFX Where the Party Begins!

We would love to hear about your RETRO-15 Journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

