



INSTRUCTION MANUAL



TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN

To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers or under extreme weather conditions. Clean only with a dry cloth. Users should exhibit extra safety when the WARNING or CAUTION symbol appears in this instruction manual and follow all precautions as they are stated.

/\ ¡ADVERTENCIA! /\

PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO QUITE LA CUBIERTA DE ESTE ALTAVOZ. NO HAY PARTES REPARABLES POR EL USUARIO ADENTRO. REMITIR TODO SERVICIO A UN TÉCNICO CALIFICADO

Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia ni a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor o bajo condiciones climáticas extremas. Limpiar solamente con un paño seco. Los usuarios deben mostrar una seguridad adicional cuando aparece el símbolo de ADVERTENCIA o PRECAUCIÓN en este manual de instrucciones y seguir todas las precauciones tal como se indican.

Note:

- 1. Please read this manual carefully before using this speaker.
- 2. Connection: Bluetooth, TF card, USB, FM and 6.35mm Mic Input
- 3. This device has a built-in rechargeable battery. When the battery is low, you need to charge it promptly. If you won't be using the device for an extended period, turn it off to conserve the battery power.
- 4. Keep this product be away from the fire, liquid, etc...

Nota:

- 1. Por favor, lea este manual detenidamente antes de usar este altavoz.
- 2. Conexión: Bluetooth, tarjeta TF, USB, FM y entrada de micrófono de 6,35 mm
- 3. Este dispositivo tiene una batería recargable integrada. Cuando la batería esté baja, debe cargarla de inmediato. Si no va a usar el dispositivo durante un período prolongado, apáguelo para conservar la energía de la batería.
- Mantenga este producto alejado del fuego, líquidos, etc.





Note:

- 1. Button ON/OFF: turn ON/OFF this product by this switch.
- 2. AUX input to connect from an external audio device.
- DC 5V: this charging port is for battery recharging. Plug the USB charging cable into the charging port, and connect adaptor or other power sources. You need charge this product in time when the power is low.
- TF Card Slot: When inputing TF/SD card with MP3 music, Press the Mode(M) button to toggle to USB drive mode, then music will play automatically
- USB SLOT: when inputting USB with MP3 musics, then you can enjoy your happy time with your favorite songs.
- 6. Display Screen
- 7. Mode:
 - a. Press to change modes
 - b. Press and hold to turn lights ON or OFF

8. HI/V-

- a. Press for previous track.
- b. Press and hold to decrease volume.
- 9. | PLAY/PAUSE
 - a. Press to Play/Pause current track.
 - b. In FM Mode, Press and Hold to scan through Radio stations.

10.**№ /V+**


- a. Press for next track.
- b. Press and hold to increase volume.

Bluetooth Audio Playing:

- 1. Press the "ON" button to turn on the speaker, and then press "M" to switch to Bluetooth Mode.
- 2. On your Bluetooth device, such as a mobile phone, ensure Bluetooth is enabled and ready for connection
- 3. Search for the speaker's Bluetooth name: TMS-101 on your phone's list, and connect to it. Once paired, you can play music from your phone and adjust the volume directly from your phone.

True Wireless Stereo (TWS) Setting:





Note:

- 1. Botón ON/OFF: Encienda/Apague este producto usando este interruptor.
- 2. Entrada AUX para conectar desde un dispositivo de audio externo.
- 3. DC 5V: Este puerto de carga es para recargar la batería. Conecte el cable de carga USB al puerto y conéctelo a un adaptador u otra fuente de alimentación. Cargue este producto de inmediato cuando la energía esté baja.
- 4. Ranura para Tarjeta TF: Al insertar una tarjeta TF/SD con música MP3, presione el botón de Modo (M) para cambiar al modo de unidad USB, y la música se reproducirá automáticamente.
- Ranura USB: Al insertar una unidad USB con música MP3, puede disfrutar de sus canciones favoritas.
- 6. Pantalla de visualización:
- 7. Modo:
 - a. Presione brevemente para cambiar los modos.
 - b. Mantenga presionado para encender o apagar las luces.

8. K4/V-

- a. Presione brevemente para la pista anterior
- b. Mantenga presionado para disminuir el volumen.

9. | Reproducir/Pausar:

- a. Presione para reproducir/pausar la pista actual.
- b. En modo FM, presione y mantenga presionado para escanear entre estaciones de radio.

10.**№** /V+

- a. Presione brevemente para la siguiente pista.
- b. Mantenga presionado para aumentar el volumen.

Reproducción de Audio por Bluetooth:

- 1. Presione el botón "ON" para encender el altavoz y luego presione "M" para cambiar al modo Bluetooth.
- En su dispositivo Bluetooth, como un teléfono móvil, asegúrese de que el Bluetooth esté activado y listo para la conexión.
- Busque el nombre del altavoz: TMS-101 en la lista de su teléfono y conéctese a él. Una vez emparejado, puede reproducir música desde su teléfono y ajustar el volumen directamente desde su teléfono.

Configuración de True Wireless Stereo (TWS):





LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, CFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable) repoult (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and OFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof); and the Product (or, as applicable, any component thereof); (a) cosmetic damage to the Product (or, as applicable, any component thereof); (a) cosmetic damage to the Product (or, as applicable, any component thereof); (a) cosmetic damage to the Product (or, as applicable, any component thereof); (a) cosmetic damage to the Product (or, as applicable, any component thereof); (a) cosmetic damage to the Product (or, as applicable, any component thereof); (a) cosmetic damage to the Product (or, as applicable, any component thereof); (a) cosmetic damage to the Product (or, as applicable, any component thereof); (a) cosmetic damage to the Product (or, as applicable, any component thereof); (a) cosmetic damage to the Product (or, as applicable, any component thereof); (b) and the Product (or, as applicable, any component thereof); (b) and the

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (I) OF MERCHANTABILITY, (II) OF FITNESS FOR A PARTICULAR PURPOSE, OR (III) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES. IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.

RMA Processing Customer Support Department 2957 E. 46th Street | Vernon, CA 90058 support@qfxusa.com

(800) 864-CLUB (2582) or (323) 864-6900

qfxusa.com

Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2024 ©







THANK YOU.

QFX Where the Party Begins!

We would love to hear about your TMS-101 Journey! Tag us @QFXUSA to share your stories.

FOLLOW US @QFXUSA







