



WHERE THE PARTY BEGINS™



INSTRUCTION MANUAL



## WARNING!



TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN

To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers or under extreme weather conditions. Clean only with a dry cloth. Users should exhibit extra safety when the WARNING or CAUTION symbol appears in this instruction manual and follow all precautions as they are stated.



## ¡ADVERTENCIA!



PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO quite la cubierta de este altavoz. No hay partes reparables por el usuario adentro. Remítir todo servicio a un técnico calificado

Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia ni a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor o bajo condiciones climáticas extremas. Limpiar solamente con un paño seco. Los usuarios deben mostrar una seguridad adicional cuando aparece el símbolo de ADVERTENCIA o PRECAUCIÓN en este manual de instrucciones y seguir todas las precauciones tal como se indican.



## AVERTISSEMENT !



POUR RÉDUIRE LE RISQUE DE CHOC ÉLECTRIQUE, NE RETIREZ PAS LE CAPOT DE CET ENCEINTE. IL N'Y A AUCUNE PARTIE RÉPARABLE PAR L'UTILISATEUR À L'INTÉRIEUR. CONFIEZ TOUTE RÉPARATION À UN TECHNICIEN QUALIFIÉ.

Pour éviter les incendies ou les chocs électriques, n'exposez pas cet appareil à la pluie ou à l'humidité. Ne stockez ni n'utilisez ce produit à proximité de liquides, de sources de chaleur comme des radiateurs, des registres de chaleur ou dans des conditions climatiques extrêmes. Nettoyez uniquement avec un chiffon sec. Les utilisateurs doivent faire preuve de prudence lorsqu'ils voient le symbole d'AVERTISSEMENT ou de PRÉCAUTION dans ce manuel d'instructions et suivre toutes les précautions telles qu'indiquées.

### BATTERY

The BT-29 is a rechargeable battery powered portable speaker. Be sure that you have completely charged the battery prior to first use to maximize the battery's lifespan. Once the power adaptor is connected to a power source, it will automatically begin charging (6-8 hours to fully charge the battery) Even if the battery power is low, it will power on when connected to a power source. When the battery is charging, the battery indicator light is red. When the battery charge fully, the indicator light will turn off. Upon completion of the charging, please disconnect the unit. When not in use, the speaker should always be set OFF to prevent the unit from draining the battery. When the unit is not used for prolonged periods of time, the battery will gradually lose its power. It is recommended to fully charge the battery at least every 60 days. When battery is completely empty, the unit cannot perform at 100% of the volume when immediately connected to power source. It is suggested to charge for a while before using with 100% volume. The unit may work and charge with lower-level volume. The volume level would be increased as the unit is charging.

### BATERÍA

El BT-29 es un altavoz portátil que funciona con batería recargable. Asegúrese de haber cargado completamente la batería antes del primer uso para maximizar su vida útil. Una vez que el adaptador de corriente esté conectado a una fuente de alimentación, comenzará a cargarse automáticamente (entre 6 y 8 horas para cargar completamente la batería). Incluso si la carga de la batería es baja, se encenderá cuando se conecte a una fuente de alimentación. Cuando la batería se esté cargando, la luz indicadora de batería estará roja. Cuando la batería esté completamente cargada, la luz indicadora se apagará. Una vez completada la carga, desconecte la unidad. Cuando no esté en uso, el altavoz debe estar siempre apagado para evitar que la unidad agote la batería. Cuando la unidad no se utilice durante períodos prolongados de tiempo, la batería perderá energía gradualmente. Se recomienda cargar completamente la batería al menos cada 60 días. Cuando la batería esté completamente agotada, la unidad no podrá funcionar al 100 % del volumen cuando se conecte inmediatamente a la fuente de alimentación. Se recomienda cargar durante un tiempo antes de usar con el volumen al 100 %. La unidad puede funcionar y cargarse con un volumen más bajo. El nivel del volumen aumentará a medida que la unidad se carga.


### BATTERIE

Le BT-29 est un haut-parleur portable alimenté par batterie rechargeable. Assurez-vous d'avoir complètement chargé la batterie avant la première utilisation pour maximiser la durée de vie de la batterie. Une fois l'adaptateur secteur connecté à une source d'alimentation, il commencera automatiquement à se charger (6 à 8 heures pour charger complètement la batterie). Même si la batterie est faible, il s'allumera lorsqu'il sera connecté à une source d'alimentation. Lorsque la batterie est en charge, le voyant de la batterie est rouge. Lorsque la batterie est complètement chargée, le voyant s'éteint. Une fois la charge terminée, veuillez débrancher l'appareil. Lorsqu'il n'est pas utilisé, le haut-parleur doit toujours être éteint pour éviter que l'appareil ne vide la batterie. Lorsque l'appareil n'est pas utilisé pendant des périodes prolongées, la batterie perd progressivement sa puissance. Il est recommandé de charger complètement la batterie au moins tous les 60 jours. Lorsque la batterie est complètement vide, l'appareil ne peut pas fonctionner à 100 % du volume lorsqu'il est immédiatement connecté à la source d'alimentation. Il est suggéré de charger pendant un certain temps avant de l'utiliser à 100 % du volume. L'appareil peut fonctionner et se charger à un volume inférieur. Le niveau de volume augmente pendant que l'appareil est en charge.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

FCC ID: 2AOMX-BT579



#### Functions

1. Telescopic Antenna
2. Flash Light
3. Mode And Light Button
4. Prev Button
5. Play/Pause/Bt Call Button
6. Next Button
7. Speaker
8. Strap

9. Solar Panel
10. TF Card Slot
11. USB Slot
12. AUX In Jack
13. Power Indicator Light
14. On/Off Switch
15. DC 5V In Jack
16. Charge Indicator Light

#### Radio Use

Press the Power Switch to turn the radio, press and hold the " + " button to increase the volume, then pull out the antenna. It will automatically play the searched channels, press " - " to play the previous radio, press " + " to play the next radio.

#### USB and TF Card Use


Press the Power Switch to turn the radio, press and hold the " + " button to increase the volume, and then insert the U disk or TF card with MP3 songs into the radio, the music will be played automatically. If you want to choose to play USB, TF card or Bluetooth, just press the "MODE" button to convert. Press the " - " or " + " button to select previous and next songs. Press and hold these two buttons for 3 seconds, the song can be played back or forward quickly. And the playback can be paused by pressing the "⏸" button.

#### Bluetooth Music Playback

1. Press the Power Switch to turn the radio, press and hold the " + " button to increase the volume, press "MODE", after hearing the Bluetooth prompt sound, turn on the Bluetooth function of the mobile phone to pair and connect with the Bluetooth name "QFX BT-29".
2. After the connection is successful, you can open the mobile phone player to play music.
3. To select a song, press the " - " or " + " button to select up and down songs, and press the "⏸" button to pause playback.
4. When dialing and answering the phone, the speaker of the radio has a prompt sound of "beep". Press the "📞" button once to make a phone call, and then you can make a call with the other party. At the end of the call, press the "📞" button again to hang on.

#### AUX In Use

Press the Power Switch to turn the radio, press and hold the " + " button to increase the volume, and plug the other end of the AUX connection cable into the "AUX IN" input port to play music. Press the "⏸" button to mute. Press the "MODE" button to switch the Bluetooth connection.



#### Funciones

- |                                           |                                      |
|-------------------------------------------|--------------------------------------|
| 1. Antena Telescópica                     | 9. Panel Solar                       |
| 2. Luz De Flash                           | 10. Ranura Para Tarjeta TF           |
| 3. Botón De Modo Y Luz                    | 11. Ranura USB                       |
| 4. Botón Anterior                         | 12. Entrada Auxiliar                 |
| 5. Botón De Reproducción/Pausa/Llamada Bt | 13. Luz Indicadora De Encendido      |
| 6. Botón Siguiente                        | 14. Interruptor De Encendido/Apagado |
| 7. Altavoz                                | 15. Entrada De Cc De 5 V             |
| 8. Correa                                 | 16. Luz Indicadora De Carga          |

#### Uso de la radio

Presione el interruptor de encendido para encender la radio, presione prolongadamente el botón "+" para aumentar el volumen y luego retire la antena. Reproducirá automáticamente los canales buscados. Presione "-" para reproducir la radio anterior y "+" para reproducir la siguiente radio.

#### Uso de USB y tarjeta TF


Presione el interruptor de encendido para encender la radio, presione prolongadamente el botón "+" para aumentar el volumen y luego inserte el disco U o la tarjeta TF con canciones MP3 en la radio, la música se reproducirá automáticamente. Si desea elegir reproducir USB, tarjeta TF o Bluetooth, simplemente presione el botón "MODE" para convertir. Presione el botón "-" o "+" para seleccionar las canciones anteriores y siguientes. Mantenga presionados estos dos botones durante 3 segundos, la canción se puede reproducir hacia atrás o hacia adelante rápidamente. Y la reproducción se puede pausar presionando el botón "⏸".

#### Reproducción de música por Bluetooth

1. Presione el interruptor de encendido para encender la radio, presione prolongadamente el botón "+" para aumentar el volumen, presione "MODE", luego de escuchar el sonido de aviso de Bluetooth, encienda la función Bluetooth del teléfono móvil para emparejarlo y conectarlo con el nombre de Bluetooth "QFX BT-29".
2. Una vez que la conexión sea exitosa, puede abrir el reproductor del teléfono móvil para reproducir música.
3. Para seleccionar una canción, presione el botón "-" o "+" para seleccionar canciones hacia arriba y hacia abajo, y presione el botón "⏸" para pausar la reproducción.
4. Al marcar y contestar el teléfono, el altavoz de la radio emite un sonido de aviso de "bip". Presione el botón "📞" una vez para hacer una llamada telefónica, y luego puede hacer una llamada con la otra persona. Al finalizar la llamada, presione el botón "📞" nuevamente para colgar.

#### Entrada auxiliar, uso

Presione el interruptor de encendido para encender la radio, mantenga presionado el botón "+" para aumentar el volumen y conecte el otro extremo del cable de conexión AUX al puerto de entrada "AUX IN" para reproducir música. Presione el botón "🔇" para silenciar. Presione el botón "MODE" para cambiar la conexión Bluetooth.



### Fonctions

1. Antena telescópica
2. Luz de flash
3. Botón de modo y luz
4. Botón anterior
5. Botón de reproducción/pausa/llamada Bluetooth
6. Botón siguiente
7. Altavoz
8. Correa

9. Panel solar
10. Ranura para tarjeta TF
11. Ranura USB
12. Entrada auxiliar
13. Luz indicadora de encendido
14. Interruptor de encendido/apagado
15. Entrada de CC de 5 V
16. Luz indicadora de carga

### Utilisation de la radio

Appuyez sur l'interrupteur d'alimentation pour allumer la radio, appuyez longuement sur le bouton « + » pour augmenter le volume, puis retirez l'antenne. Elle lira automatiquement les chaînes recherchées, appuyez sur « - » pour écouter la radio précédente, appuyez sur « + » pour écouter la radio suivante.

### Utilisation USB et carte TF

Appuyez sur l'interrupteur d'alimentation pour allumer la radio, appuyez longuement sur le bouton « + » pour augmenter le volume, puis insérez le disque U ou la carte TF avec des chansons MP3 dans la radio, la musique sera lue automatiquement. Si vous souhaitez choisir de lire via USB, carte TF ou Bluetooth, appuyez simplement sur le bouton « MODE » pour convertir. Appuyez sur le bouton « - » ou « + » pour sélectionner les chansons précédentes et suivantes. Appuyez et maintenez ces deux boutons pendant 3 secondes, la chanson peut être lue en arrière ou en avant rapidement. Et la lecture peut être mise en pause en appuyant sur le bouton « ⏸ ».

### Lecture de musique Bluetooth

1. Appuyez sur l'interrupteur d'alimentation pour allumer la radio, appuyez longuement sur le bouton « + » pour augmenter le volume, appuyez sur « MODE », après avoir entendu le son de l'invite Bluetooth, activez la fonction Bluetooth du téléphone mobile pour coupler et vous connecter avec le nom Bluetooth « QFX BT-29 ».
2. Une fois la connexion établie, vous pouvez ouvrir le lecteur de téléphone mobile pour écouter de la musique.
3. Pour sélectionner une chanson, appuyez sur le bouton « - » ou « + » pour sélectionner les chansons de haut en bas, et appuyez sur le bouton « ⏸ » pour mettre la lecture en pause.
4. Lorsque vous composez et répondez au téléphone, le haut-parleur de la radio émet un son d'invite de « bip ». Appuyez une fois sur le bouton « ⏸ » pour passer un appel téléphonique, puis vous pouvez passer un appel avec l'autre partie. À la fin de l'appel, appuyez à nouveau sur le bouton « ⏸ » pour raccrocher.

### Entrée auxiliaire

Appuyez sur l'interrupteur d'alimentation pour allumer la radio, maintenez enfoncé le bouton « + » pour augmenter le volume et branchez l'autre extrémité du câble de connexion AUX sur le port d'entrée « AUX IN » pour écouter de la musique. Appuyez sur le bouton « ⏸ » pour couper le son. Appuyez sur le bouton « MODE » pour changer la connexion Bluetooth.



## LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at [www.qfxusa.com](http://www.qfxusa.com) for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

**QFX USA®, Inc.**  
RMA Processing  
Customer Support Department  
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com  
(800) 864-CLUB (2582) or (323) 864-6900  
qfxusa.com  
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your prouuct or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

| PRODUCT CATEGORY                                                  | HANDLING | LABOR  | PARTS  |
|-------------------------------------------------------------------|----------|--------|--------|
| Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers | \$5.00   | 1 Year | 1 Year |
| Personal Stereos                                                  | \$10.00  | 1 Year | 1 Year |
| Portable Radio/Cassette                                           | \$15.00  | 1 Year | 1 Year |
| Large Portable Radio Cassette                                     | \$20.00  | 1 Year | 1 Year |
| Mobile Audio                                                      | \$10.00  | 1 Year | 1 Year |
| Pro Audio SBX Systems                                             | \$75.00  | 1 Year | 1 Year |
| Pro Audio PBX Systems                                             | \$75.00  | 1 Year | 1 Year |
| Televisions                                                       | \$25.00  | 1 Year | 1 Year |
| Telephones                                                        | \$10.00  | 1 Year | 1 Year |

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025 ©



1-800-864-2582  
Mon-Fri 9AM - 5PM (PST)



support@qfxusa.com  
Mon-Fri 9AM - 5PM (PST)



[www.qfxusa.com](http://www.qfxusa.com)

# THANK YOU.

**QFX** Where the Party Begins!

We would love to hear about your BT-29 Journey!  
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

