


R-81



WHERE THE PARTY BEGINS™



INSTRUCTION MANUAL



FUNCTIONS

1. TELESCOPIC ANTENNA
2. BAND SWITCH
3. VOLUME CONTROL
4. TUNING KNOB
5. FUNCTION BUTTON
6. BATTERY COMPARTMENT (BACK)
7. DC 5V IN JACK
8. AUX IN JACK
9. DC 7.5V JACK
10. LED LIGHT
11. TF CARD SLOTR
12. USB SLOT
13. HANDLE
14. SOLAR PANEL
15. USB 5V OUTPUT JACK
16. CHARGE INDICATOR LIGHT
17. POWER INDICATOR LIGHT
18. PREV/REW BUTTON
19. REPEAT BUTTON
20. NEXT F.F. BUTTON
21. PLAY/PAUSE BUTTON
22. LIGHT ON/OFF/OUTPUT BUTTON
23. SPEAKERS

FUNCIONES

1. ANTENA TELESCÓPICA
2. CONMUTADOR DE BANDA
3. CONTROL DE VOLUMEN
4. MANDO DE SINTONIZACIÓN
5. BOTÓN DE FUNCIÓN
6. COMPARTIMENTO DE LAS PILAS (PARTE TRASERA)
7. TOMA DC 5V
8. CONECTOR AUX IN
9. TOMA CC 7,5 V
10. LUZ LED
11. RANURA TARJETA TF
12. RANURA USB
13. MANIJA
14. PANEL SOLAR
15. TOMA DE SALIDA USB 5V
16. INDICADOR LUMINOSO DE CARGA
17. LUZ INDICADORA DE ENCENDIDO
18. BOTÓN PREV/REW
19. BOTÓN REPEAT
20. BOTÓN SIGUIENTE F.F
21. BOTÓN PLAY/PAUSE
22. BOTÓN DE ENCENDIDO/APAGADO/ SALIDA DE LA LUZ
23. ALTAVOCES

LES FONCTIONS

1. ANTENNE TÉLESCOPIQUE
2. COMMUTATEUR DE BANDE
3. CONTRÔLE DU VOLUME
4. BOUTON DE SYNTONISATION
5. BOUTON DE FONCTION
6. COMPARTIMENT DES PILES (À L'ARRIÈRE)
7. PRISE D'ENTRÉE C.C. 5V
8. PRISE D'ENTRÉE AUXILIAIRE
9. PRISE DC 7.5V
10. ÉCLAIRAGE LED
11. FENTE POUR CARTE TF
12. LOGEMENT USB
13. POIGNÉE
14. PANNEAU SOLAIRE
15. PRISE DE SORTIE USB 5V
16. VOYANT DE CHARGE
17. VOYANT D'ALIMENTATION
18. BOUTON PREV/REW
19. BOUTON REPEAT
20. BOUTON F.F. SUIVANT
21. BOUTON LECTURE/PAUSE
22. BOUTON MARCHE/ARRÊT/SORTIE DE LA LUMIÈRE
23. HAUT-PARLEURS

RADIO FUNCTION

1. Put Um rechargeable battery into battery compartment paying careful attention to the polarity.
2. Turn the volume control clockwise , the radio can be turned on when you hear the sound of "bi " keep on turning this knob to adjust the volume. Turn off the radio by turning the volume control anti-clockwise until you hear the sound of "bi".
3. Adjust the band selector ,and then turn the tuning knob to receiver the different programmes from AM/FM/SW1-2.
4. When listen to the programmes from FM ,Please pull out the antenna and change the length to make the listening clear.
5. When listen to the programmes from AM, please change the radio's position until receiving the best signal.
6. When you don't want to listen to the radio, please turn it off and disconnect the DC power cord or take out the batteries. When you don't want to use the radio for along time, please take out the batteries from the unite.

FUNCIÓN RADIO

1. Coloque la batería Um rechargeable en el compartimento de la batería prestando especial atención a la polaridad.
2. Gire el control de volumen en el sentido de las agujas del reloj , la radio se encenderá cuando oiga el sonido de «bi » siga girando este mando para ajustar el volumen. Apague la radio girando el control de volumen en sentido antihorario hasta que oiga el sonido de «bi».
3. Ajuste el selector de banda ,y luego gire el mando de sintonización para recibir los diferentes programas de AM/FM/SW1-2.
4. Cuando escuche los programas de FM, por favor saque la antena y cambie la longitud para que la escucha sea clara.
5. Cuando escuche los programas de AM, cambie la posición de la radio hasta recibir la mejor señal.
6. Cuando no desee escuchar la radio, apáguela y desconecte el cable de alimentación de CC o extraiga las pilas.
Si no va a utilizar la radio durante mucho tiempo, saque las pilas de la unidad.

FONCTION RADIO

1. Placez la pile Um rechargeable dans le compartiment à piles en faisant attention à la polarité.
2. Tournez le bouton de réglage du volume dans le sens des aiguilles d'une montre, la radio peut être allumée lorsque vous entendez le son « bi », continuez à tourner ce bouton pour régler le volume. Éteignez la radio en tournant le bouton de volume dans le sens inverse des aiguilles d'une montre jusqu'à ce que vous entendiez le son « bi ».
3. Réglez le sélecteur de bande, puis tournez le bouton de réglage pour recevoir les différents programmes AM/FM/SW1-2.
4. Lorsque vous écoutez les programmes FM, tirez l'antenne et modifiez sa longueur pour que l'écoute soit plus claire.
5. Lorsque vous écoutez les programmes AM, changez la position de la radio jusqu'à ce qu'elle reçoive le meilleur signal.
6. Lorsque vous ne voulez plus écouter la radio, éteignez-la et débranchez le cordon d'alimentation ou retirez les piles. Si vous ne souhaitez pas utiliser la radio pendant un certain temps, retirez les piles de l'unité.

USB/TF CARD PLAYBACK FUNCTION

1. Turn on the power.
2. Set the function selector to USB(TF).
3. Insert a USB flash drive(or a TF card) with MP3 format music, the unit will play automatically. Press PAUSE/PLAY button to hold the playback, press it again to continue the playback. Press repeat button to repeat the playing song, press PREV button to select the previous song and F.F button to the next song.

FUNCIÓN DE REPRODUCCIÓN DE TARJETAS USB/TF

1. Encienda el aparato.
2. Ponga el selector de función en USB(TF).
3. Insérte una unidad flash USB(o una tarjeta TF) con música en formato MP3, la unidad reproducirá automáticamente. Pulse el botón PAUSE/PLAY para detener la reproducción, púlselo de nuevo para continuar la reproducción. Pulse el botón de repetición para repetir la canción que se está reproduciendo, pulse el botón PREV para seleccionar la canción anterior y el botón F.F para pasar a la siguiente canción.

FONCTION DE LECTURE DES CARTES USB/TF

1. Mettez l'appareil sous tension.
2. Réglez le sélecteur de fonction sur USB(TF).
3. Insérez une clé USB (ou une carte TF) contenant de la musique au format MP3, l'appareil lira automatiquement. Appuyez sur la touche PAUSE/PLAY pour suspendre la lecture, appuyez à nouveau sur cette touche pour poursuivre la lecture. Appuyez sur la touche Repeat pour répéter la chanson en cours de lecture, appuyez sur la touche PREV pour sélectionner la chanson précédente et sur la touche F.F pour passer à la chanson suivante.

BLUETOOTH FUNCTION

1. Push function switch to USB/TF position.
2. After listening to Bluetooth,open mobile Bluetooth device to search and connect "R-81".
3. After the success of the mobile phone player directly to open the play music.

FUNCIÓN BLUETOOTH

1. Ponga el conmutador de funciones en la posición USB/TF.
2. Después de escuchar Bluetooth,abra el dispositivo móvil Bluetooth para buscar y conectar «R-81».
3. Después del éxito del reproductor de teléfono móvil directamente para abrir la reproducción de música.

FONCTION BLUETOOTH

1. Pousser le commutateur de fonction en position USB/TF.
2. Après avoir écouté le Bluetooth, ouvrez le dispositif mobile Bluetooth pour rechercher et connecter le «R-81».
3. Après le succès du lecteur de téléphone mobile, ouvrir directement le lecteur de musique.

NOTE

1. This model includes built in rechargeable battery. In order to prolong battery life and product normal use, charging time please keep 6-8 hours.
2. Please replace batteries of the same brand and model when renew the battery.
3. This product is not waterproof and should not be exposed to rain during outdoor use.
4. Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions at open site. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
5. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
6. **WARNING:** The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.
7. **WARNING:** The mains plug is used as disconnect device, the disconnect device shall remain readily operable
8. No naked flame sources, such as lighted candles, should be placed on the apparatus.
9. Attention should be drawn to environmental aspects of battery disposal.

NOTA

1. Con el fin de prolongar la vida de la batería y el uso normal del producto, el tiempo de carga por favor mantenga 6-8 horas.
2. Por favor, reemplace las baterías de la misma marca y modelo cuando renueve la batería.
3. Este producto no es impermeable y no debe exponerse a la lluvia durante su uso en exteriores.
4. No instale este equipo en un espacio cerrado o edificado, como una librería o similar, y mantenga unas buenas condiciones de ventilación al aire libre. No se debe impedir la ventilación cubriendo las aberturas de ventilación con elementos como periódicos, manteles, cortinas, etc.
5. **ADVERTENCIA:** Para reducir el riesgo de incendio o descarga eléctrica, no exponga este aparato a la lluvia ni a la humedad. No exponga el aparato a goteos ni salpicaduras y no coloque objetos que contengan líquidos, como jarrones, sobre el aparato.
6. **ADVERTENCIA:** La batería (batería o baterías o paquete de baterías) no debe exponerse a un calor excesivo como el del sol, el fuego o similares.
7. **ADVERTENCIA:** El enchufe de red se utiliza como dispositivo de desconexión, el dispositivo de desconexión debe permanecer fácilmente operable.
8. No deben colocarse sobre el aparato fuentes de llama desnuda, como velas encendidas.
9. Debe prestarse atención a los aspectos medioambientales de la eliminación de baterías.

NOTE

1. Afin de prolonger la durée de vie de la batterie et de permettre une utilisation normale du produit, le temps de charge doit être compris entre 6 et 8 heures.
2. Veuillez remplacer les piles par des piles de la même marque et du même modèle.
3. Ce produit n'est pas étanche et ne doit pas être exposé à la pluie lors d'une utilisation extérieure.
4. N'installez pas cet appareil dans un espace confiné ou encastré, tel qu'une bibliothèque ou un appareil similaire, et veillez à ce que les conditions de ventilation soient bonnes à l'extérieur. La ventilation ne doit pas être entravée en couvrant les ouvertures de ventilation avec des articles tels que des journaux, des nappes, des rideaux, etc.
5. **AVERTISSEMENT:** Pour réduire les risques d'incendie ou d'électrocution, ne pas exposer cet appareil à la pluie ou à l'humidité. L'appareil ne doit pas être exposé à des gouttes ou à des éclaboussures et aucun objet rempli de liquide, tel qu'un vase, ne doit être placé sur l'appareil.
6. **AVERTISSEMENT:** La batterie (batterie ou piles ou bloc-piles) ne doit pas être exposée à une chaleur excessive telle que le soleil, le feu ou autre.
7. **AVERTISSEMENT:** La prise de courant est utilisée comme dispositif de déconnexion ; le dispositif de déconnexion doit rester facilement utilisable.
8. Aucune source de flamme nue, telle qu'une bougie allumée, ne doit être placée sur l'appareil.
9. L'attention doit être attirée sur les aspects environnementaux de l'élimination des piles.



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

 support@qfxusa.com
 (800) 864-CLUB (2582) or (323) 864-6900
 qfxusa.com
 Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your prouuct or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025©



1-800-864-2582
Mon-Fri 9AM - 5PM (PST)



support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)

www.qfxusa.com

THANK YOU.

QFX Where the Party Begins!

We would love to hear about your **R-81** journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

