

BT-101



WHERE THE PARTY BEGINS™



INSTRUCTION MANUAL



TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN

To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers or under extreme weather conditions. Clean only with a dry cloth. Users should exhibit extra safety when the WARNING or CAUTION symbol appears in this instruction manual and follow all precautions as they are stated.



PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO quite la cubierta de este altavoz. No hay partes reparables por el usuario adentro. Remitir todo servicio a un técnico calificado

Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia ni a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor o bajo condiciones climáticas extremas. Limpiar solamente con un paño seco. Los usuarios deben mostrar una seguridad adicional cuando aparece el símbolo de ADVERTENCIA o PRECAUCIÓN en este manual de instrucciones y seguir todas las precauciones tal como se indican.



POUR RÉDUIRE LE RISQUE DE CHOC ÉLECTRIQUE, NE RETIREZ PAS LE CAPOT DE CET ENCEINTE. IL N'Y A AUCUNE PARTIE RÉPARABLE PAR L'UTILISATEUR À L'INTÉRIEUR. CONFIEZ TOUTE RÉPARATION À UN TECHNICIEN QUALIFIÉ.

Pour éviter les incendies ou les chocs électriques, n'exposez pas cet appareil à la pluie ou à l'humidité. Ne stockez ni n'utilisez ce produit à proximité de liquides, de sources de chaleur comme des radiateurs, des registres de chaleur ou dans des conditions climatiques extrêmes. Nettoyez uniquement avec un chiffon sec. Les utilisateurs doivent faire preuve de prudence lorsqu'ils voient le symbole d'AVERTISSEMENT ou de PRÉCAUTION dans ce manuel d'instructions et suivre toutes les précautions telles qu'indiquées.

BATTERY

The BT-101 is a rechargeable battery powered PA loudspeaker. Be sure that you have completely charged the battery prior to first use to maximize the battery's lifespan. Once the power adaptor is connected to a power source, it will automatically begin charging (2-3 hours to fully charge the battery). Even if the battery power is low, it will power on when connected to a power source. When the battery is charging, the battery indicator light is red. When the battery charge fully, the indicator light will turn off. Upon completion of the charging, please disconnect the unit. When not in use, the speaker should always be set OFF to prevent the unit from draining the battery. When the unit is not used for prolonged periods of time, the battery will gradually lose its power. It is recommended to fully charge the battery at least every 60 days. When battery is completely empty, the unit cannot perform at 100% of the volume when immediately connected to power source. It is suggested to charge for a while before using with 100% volume. The unit may work and charge with lower-level volume. The volume level would be increased as the unit is charging.

BATERÍA

El BT-101 es un altavoz PA con batería recargable. Asegúrese de haber cargado completamente la batería antes del primer uso para maximizar su vida útil. Una vez que el adaptador de corriente esté conectado a una fuente de alimentación, comenzará a cargarse automáticamente (2-3 horas para cargar completamente la batería). Incluso si la carga de la batería es baja, se encenderá cuando se conecte a una fuente de alimentación. Cuando la batería se está cargando, la luz indicadora de la batería está roja. Cuando la batería se cargue por completo, la luz indicadora se apagará. Al finalizar la carga, desconecte la unidad. Cuando no esté en uso, el altavoz siempre debe estar APAGADO para evitar que la unidad agote la batería. Cuando la unidad no se utiliza durante períodos prolongados de tiempo, la batería perderá energía gradualmente. Se recomienda cargar completamente la batería al menos cada 60 días. Cuando la batería está completamente vacía, la unidad no puede funcionar al 100% del volumen cuando se conecta inmediatamente a la fuente de alimentación. Se sugiere cargar durante un tiempo antes de usarlo con el 100% del volumen. La unidad puede funcionar y cargarse con un volumen de nivel más bajo. El nivel de volumen aumentará a medida que la unidad se esté cargando.

BATTERIE

Le BT-101 est un haut-parleur de sonorisation alimenté par batterie rechargeable. Assurez-vous d'avoir complètement chargé la batterie avant la première utilisation afin de maximiser la durée de vie de la batterie. Une fois que l'adaptateur secteur est connecté à une source d'alimentation, il commencera automatiquement à se charger (2-3 heures pour charger complètement la batterie). Même si la batterie est faible, il s'allumera lorsqu'il sera connecté à une source d'alimentation. Lorsque la batterie est en charge, le voyant de la batterie est rouge. Lorsque la batterie est complètement chargée, le voyant s'éteint. Une fois la charge terminée, veuillez débrancher l'appareil. Lorsqu'il n'est pas utilisé, le haut-parleur doit toujours être éteint pour éviter que l'appareil ne décharge la batterie. Lorsque l'appareil n'est pas utilisé pendant une période prolongée, la batterie perd progressivement sa puissance. Il est recommandé de charger complètement la batterie au moins tous les 60 jours. Lorsque la batterie est complètement vide, l'appareil ne peut pas fonctionner à 100 % du volume lorsqu'il est immédiatement connecté à une source d'alimentation. Il est suggéré de charger pendant un certain temps avant de l'utiliser avec un volume de 100 %. L'appareil peut fonctionner et se charger avec un volume inférieur. Le niveau de volume augmenterait à mesure que l'appareil est en charge.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

FCC ID: 2A4QS-RS-436

Specifications:

Bluetooth version: V5.3

Working distance: 10m

Speaker: 6W

What is included in the box:

- 1x Speaker
- 1x USB cable
- 1x User Manual

Operations:


1. Knob for power ON/OFF & Volume control
2. USB charging socket - DC 5V: connect to your mobile phone charger (not included) with charging cable (provided). 5V 1A is the suitable phone charger to use.

2A. When speaker is low battery, charge the unit, using the USB charging cable included, to your mobile phone charger (not included).

Status: red LED during charging mode/ LED off when fully charged.

3. MODE button: press to mode switch
4. Press to PREVIOUS song
5. PLAY/PAUSE: press to play/pause.
6. Press to NEXT song
7. TWS pairing button

8. Press to switch to different LED mode
9. USB port: Support MP3 format
10. TF slot: Used to read the Mp3 files
11. 3.5mm jack: Aux-in, connect with MP3 or other outlet via audio cable.
12. L rear handle for easy carry



BT WIRELESS CONNECTION

The BT Wireless's pairing name is: "QFX BT-101"

If your device cannot search for "QFX BT-101" please ensure that the speaker is in BT Wireless mode. If still have BT Wireless connection problems, please switch off both BT Wireless device and BT Wireless speaker. Then start again, to scan for BT Wireless device.

USB MP3 Player

Insert MP3 music files into USB and plug in the USB port, the machine will play the music files automatically. The unit is designed to play MP3 audio files contained in a USB key. If the files are not in MP3 format, the files cannot be read successfully.

TWS MODE

Play BT-101 speaker from the same mobile device Turn on both speaker Press TWS button for one of the unit. you will hear a sound. Press TWS button for the other unit, you will hear a sound, Pair your mobile device to any of the 2x speaker, you are now able to play your music on both speaker at the same time, without any cable.

FM RADIO

In order for the Radio Mode to work, a USB cable must be connected to the type c USB port of the Speaker during use, Press the "M" Mode button to switch to the Radio Mode. Once Radio mode is selected, press the "pause" button to scan available FM radio stations (please allow 1-2 minutes for the initial scan to be completed, the scan is complete once it remains on one radio station), and then use the previous song/next song button to scroll through the available FM radio stations.

HANDS FREE CALLS

When receiving a phone call,
Press PLAY/PAUSE button once to answer the call.
Press PLAY/PAUSE button a second time to end the call.
Press and Hold PLAY/PAUSE button to reject the call.
Double press PLAY/PAUSE button to dial the last call.

Especificaciones::

Versión de Bluetooth: V5.3

Distancia de funcionamiento: 10 m

Altavoz: 6 W

Qué incluye la caja:

1 altavoz

1 cable USB

1 manual de usuario

Funcionamiento:

1. Perilla para encender/apagar y controlar el volumen

2. Toma de carga USB - DC 5V: conéctelo al cargador de su teléfono móvil (no incluido) con el cable de carga (incluido). 5V 1A es el cargador de teléfono adecuado para usar.

2A. Cuando el altavoz tenga poca batería, cargue la unidad, utilizando el cable de carga USB incluido, al cargador de su teléfono móvil (no incluido). Estado: LED rojo durante el modo de carga / LED apagado cuando está completamente cargado.

3. Botón MODE: presione para cambiar de modo

4. Presione para ir a la canción ANTERIOR

5. PLAY/PAUSE: presione para reproducir/pausar.

6. Presione para ir a la SIGUIENTE canción

7. Botón de emparejamiento TWS


8. Presione para cambiar a un modo LED diferente

9. Puerto USB: compatible con formato MP3

10. Ranura TF: se utiliza para leer archivos Mp3

11. Conector de 3,5 mm: entrada auxiliar, conéctelo con MP3 u otro dispositivo a través de un cable de audio.

12. Asa trasera en forma de L para transportarlo fácilmente



CONEXIÓN INALÁMBRICA BT

El nombre de emparejamiento de BT Wireless es: "QFX BT-101"

Si su dispositivo no puede buscar "QFX BT-101", asegúrese de que el altavoz esté en modo inalámbrico BT. Si sigue teniendo problemas de conexión inalámbrica BT, apague tanto el dispositivo inalámbrico BT como el altavoz inalámbrico BT. Luego, vuelva a comenzar para buscar el dispositivo inalámbrico BT.

Reproductor MP3 USB

Inserte archivos de música MP3 en el USB y conéctelo al puerto USB; la máquina reproducirá los archivos de música automáticamente.

La unidad está diseñada para reproducir archivos de audio MP3 contenidos en una memoria USB.

Si los archivos no están en formato MP3, no se podrán leer correctamente.

MODO TWS

Reproducir el altavoz BT-101 desde el mismo dispositivo móvil Encender ambos altavoces Presionar el botón TWS de una de las unidades. Escuchará un sonido. Presionar el botón TWS de la otra unidad. Escuchará un sonido. Vincular el dispositivo móvil a cualquiera de los 2 altavoces. Ahora podrá reproducir su música en ambos altavoces al mismo tiempo, sin ningún cable.

RADIO FM

Para que funcione el modo de radio, se debe conectar un cable USB al puerto USB tipo C del altavoz durante el uso. Presione el botón de modo "M" para cambiar al modo de radio. Una vez seleccionado el modo de radio, presione el botón "pausa" para escanear las estaciones de radio FM disponibles (espere de 1 a 2 minutos para que se complete el escaneo inicial; el escaneo se completa una vez que permanece en una estación de radio) y luego use el botón de canción anterior/siguiente canción para desplazarse por las estaciones de radio FM disponibles.

LLAMADAS MANOS LIBRES

Al recibir una llamada telefónica, presione el botón REPRODUCIR/PAUSA una vez para responder la llamada. presione el botón REPRODUCIR/PAUSA una segunda vez para finalizar la llamada. Presione y mantenga presionado el botón REPRODUCIR/PAUSA para rechazar la llamada. Presione dos veces el botón REPRODUCIR/PAUSA para marcar la última llamada.

Spécifications

Version Bluetooth : V5.3

Distance de travail : 10 m

Haut-parleur : 6 W

Ce qui est inclus dans la boîte :

- 1 haut-parleur
- 1 câble USB
- 1 manuel d'utilisation


Opérations :

1. Bouton marche/arrêt et contrôle du volume
2. Prise de charge USB - DC 5V : connectez-la à votre chargeur de téléphone portable (non inclus) avec le câble de charge (fourni). 5V 1A est le chargeur de téléphone approprié à utiliser.

2A. Lorsque la batterie du haut-parleur est faible, chargez l'appareil, à l'aide du câble de charge USB fourni, sur votre chargeur de téléphone portable (non inclus).

Statut : LED rouge pendant le mode de charge/LED éteinte lorsqu'elle est complètement chargée.

3. Bouton MODE : appuyez pour changer de mode
4. Appuyez pour passer à la chanson PRÉCÉDENTE



5. LECTURE/PAUSE : appuyez pour lire/mettre en pause.
6. Appuyez pour passer à la chanson SUIVANTE
7. Bouton d'appairage TWS
8. Appuyez pour passer à un mode LED différent
9. Port USB : prend en charge le format MP3
10. Emplacement TF : Utilisé pour lire les fichiers Mp3
11. Prise jack 3,5 mm : entrée auxiliaire, connexion avec MP3 ou autre sortie via un câble audio.
12. Poignée arrière en L pour un transport facile

CONNEXION SANS FIL BT

Le nom d'appairage du BT Wireless est : "QFX BT-101" Si votre appareil ne peut pas rechercher "QFX BT-101", assurez-vous que l'enceinte est en mode BT Wireless. Si vous rencontrez toujours des problèmes de connexion BT Wireless, veuillez éteindre l'appareil BT Wireless et l'enceinte BT Wireless. Puis recommencez pour rechercher l'appareil BT Wireless.

Lecteur MP3 USB

Insérez les fichiers musicaux MP3 dans le port USB et branchez-le sur le port USB. L'appareil lira automatiquement les fichiers musicaux. L'appareil est conçu pour lire les fichiers audio MP3 contenus dans une clé USB. Si les fichiers ne sont pas au format MP3, ils ne peuvent pas être lus avec succès..

MODE TWS

Jouez la musique de l'enceinte BT-101 à partir du même appareil mobile. Allumez les deux enceintes. Appuyez sur le bouton TWS de l'une des unités. Vous entendrez un son. Appuyez sur le bouton TWS de l'autre unité, vous entendrez un son. Associez votre appareil mobile à l'une des 2 enceintes. Vous pouvez désormais écouter votre musique sur les deux enceintes en même temps, sans aucun câble.

RADIO FM

Pour que le mode radio fonctionne, un câble USB doit être connecté au port USB de type C de l'enceinte pendant l'utilisation. Appuyez sur le bouton Mode « M » pour passer en mode radio. Une fois le mode radio sélectionné, appuyez sur le bouton « pause » pour rechercher les stations de radio FM disponibles (attendez 1 à 2 minutes pour que la recherche initiale soit terminée, la recherche est terminée une fois qu'elle reste sur une station de radio), puis utilisez le bouton chanson précédente/chanson suivante pour faire défiler les stations de radio FM disponibles.

APPELS MAINS LIBRES

Lorsque vous recevez un appel téléphonique, appuyez une fois sur le bouton PLAY/PAUSE pour répondre à l'appel. appuyez une deuxième fois sur le bouton PLAY/PAUSE pour mettre fin à l'appel. Appuyez et maintenez le bouton PLAY/PAUSE pour rejeter l'appel. Appuyez deux fois sur le bouton PLAY/PAUSE pour composer le dernier numéro.



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, BT-101 number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(800) 864-CLUB (2582) or (323) 864-6900
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product BT-101 conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or BT-101 number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025 ©



1-800-864-2582
Mon-Fri 9AM - 5PM (PST)



support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)



www.qfxusa.com

THANK YOU.

QFX Where the Party Begins!

We would love to hear about your BT-101 Journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

