

HP-E120




WHERE THE PARTY BEGINS™



INSTRUCTION MANUAL

HP-E120 ANC SCREEN TRUE WIRELESS EARBUDS + CHARGING CASE

Thank you for purchasing the QFX HP-E120 ANC Screen True Wireless Earbuds and Charging Case. Please read these instructions for proper use care of this product.



① **Charging case:** When not using the earbuds, you can keep them stored in the charging case to recharge.



② **Touch sensor area:** Each earbud can control volume, phone calls and music playback.

③ **ON/OFF/RESET button:**

Press to light up the charging case screen. When the lid of the charging case is closed, press and hold the button for 5 seconds to enter charging case power on/off option, and then press once again to enter the reset option. When the lid of the charging case is opened, press and hold the button for 5 seconds to self-test whether the earbuds are connected.


④ **Charging port:** This is the charging port of the charging case. Connect your USB-C cable to charge your charging case.

⑤ **Lanyard hole:** Hole for using the lanyard.

BOX CONTENTS**Earbuds****Charging Case****Lanyard****Eartips****Charging Cable****Manual**

FITTING SOFT GEL EAR TIPS

The package includes a set of small, medium and large size soft gel ear tips. Select the size that fits best and provides the most comfort for long use.



Place the earbud in the ear canal then rotate and adjust it in order to achieve the best fit.

**QUICK TIPS FOR ENSURING PROPER OPERATION**

- Make sure that the earbuds are completely dry before putting them in the charging case.
- The left or right earbud can be used independently for music and phone calls. Simply choose one and take out of the case to connect it.
- Choosing the correct size ear tip will vastly improve in audio quality due to the proper seal for the speaker driver. Test all ear tips to determine which one provides the best results.

TURNING EARBUDS POWER ON/OFF

- To turn OFF the earbuds when they are not in the charging case, press and hold the touch sensing area for 8 seconds.
- To turn ON the earbuds when they are not in the charging case, press and hold the touch sensing area for 3 seconds.



Note: If the earbuds is taken out of the charging case without any Bluetooth connection, it will automatically turn off after 5 minutes.

CHARGING THE EARBUDS

When placing the earbuds in the charging case, it will automatically recharge the earbuds.

When fully charged, 100% is displayed at the top of the screen.

When battery power is less than 3.3V, you will hear a prompt sound.

**RECHARGING THE CHARGING CASE**

To recharge the charging case, connect the USB-C cable to a computer USB port or use an USB-to-AC power adapter (not included) that provides a minimum of 5VDC, 500mA minimum power, when charging the case, its digital power display on the top of screen. It will continue charging up to a maximum 100% fully-charged level.



HP-E120 TOUCH CONTROLS

LEFT AND RIGHT EARBUD TOUCH CONTROLS

LEFT
TOUCH
SENSOR



RIGHT
TOUCH
SENSOR

Left Earbud Touch Sensor Controls

PLAY/PAUSE: Single-tap

VOLUME UP/DOWN:
Swipe down/down on the
earbuds sensor control area

NEXT TRACK: Double-tap

PREVIOUS TRACK: Triple-tap

ANSWER: Single-tap

HANG UP: Single-tap

REJECT INCOMING CALLS:
Press and hold for 2 seconds

SWITCH ANC ON/TRANSPARENCY
/ANC OFF MODE:
Press and hold for 3 seconds and release

Right Earbud Touch Sensor Controls

PLAY/PAUSE: Single-tap

VOLUME UP/DOWN:
Swipe down/down on the
earbuds sensor control area

NEXT TRACK: Double-tap

PREVIOUS TRACK: Triple-tap

ANSWER: Single-tap

HANG UP: Single-tap

REJECT INCOMING CALLS:
Press and hold for 2 seconds

VOICE ASSISTANT:
Press and hold for 3 seconds and
release

FIRST TIME CONNECTION TO BLUETOOTH

- 1.Remove the earbuds from the charging case. A "power on" sound will be heard, on your Bluetooth enabled device, head on over to your Bluetooth settings and select 'QFX HP-E120' from the list to connect.
- 2.After first time setup is completed, the earbuds will automatically reconnect in the future.

CHARGING CASE SCREEN FUNCTION:

- Play/Pause/Next/Previous Music
- Lyrics display (click on the lyrics to enter full screen display, swipe right to exit full screen)
- Equalizer options
- Ambient options (normal/ANC/transparency)
- Spatial audio options
- Volume Up/Down
- Brightness options
- Find L/R TWS earbuds
- Camera remote
- Wallpaper
- Stop timer(5min/10min/15min/20min/25min/30min/60min are the settable time)
- Touch to wake options
- Language options

SPECIFICATIONS:


- Bluetooth version: 5.4
- Protocol: HFP/HSP/A2DP/AVRCP /AVDTP/SPP/RFCOMM/HID
- Bluetooth chipset: AB5632F
- Charging case: 300mAh
- Earbuds: 30mAh
- Play time: 2-4H
- Charging time: 2-3H
- Charging case: 60.5x23x2x45.2mm
- Earbuds: 25x18x33mm
- N.W.: 64g
- Charging port: Type-C
- Input power: 5V/500mA
- Noise reduction effect: 25dB(±3dB)

CAUTION


- Do not keep the earbuds and case stored in extreme heat, cold, and humidity environments.
- Fully dry off the earbuds before placing them in the charging case.
- In order to maintain proper function, do not crush or compress the earbuds or soft gel inserts.
- Earbuds can increase the intensity of sound. Maintain lower volume levels when used for long periods.

AURICULARES HP-E120 ANC CON PANTALLA VERDADERAMENTE INALÁMBRICOS + ESTUCHE DE CARGA

Gracias por adquirir los auriculares inalámbricos QFX HP-E120 ANC Screen True Wireless y su estuche de carga. Lea estas instrucciones para un uso y cuidado adecuados de este producto.



- ① Estuche de carga: Cuando no use los auriculares, guárdelos en el estuche para recargarlos.
- ② Sensor táctil: Cada auricular controla el volumen, las llamadas y la reproducción de música.
- ③ Botón de encendido/apagado/reinicio: Presione para iluminar la pantalla del estuche de carga. Con la tapa del estuche cerrada, mantenga presionado el botón durante 5 segundos para encender/apagar el estuche y luego vuelva a presionarlo para reiniciar. Con la tapa del estuche abierta, mantenga presionado el botón durante 5 segundos para comprobar si los auriculares están conectados.
- ④ Puerto de carga: Este es el puerto de carga del estuche. Conecte el cable USB-C para cargar el estuche.
- ⑤ Orificio para el cordón: Orificio para usar el cordón.

CONTENIDO DE LA CAJA**Auriculares****Estuche de carga****Acollador****Puntas para los oídos****Cable de carga****Manual**

AJUSTE DE LAS PUNTAS DE OÍDO DE GEL SUAVE

El paquete incluye un juego de tapones de gel suave de tamaño pequeño, mediano y grande.

Seleccione el tamaño que mejor se adapte y le brinde la mayor comodidad para un uso prolongado.

PUNTA DE
LA OREJA



Coloque el auricular en el canal auditivo, luego gírelo y ajústelo para lograr el mejor ajuste.

**CONSEJOS RÁPIDOS PARA GARANTIZAR UN FUNCIONAMIENTO CORRECTO**

- Asegúrese de que los auriculares estén completamente secos antes de colocarlos en el estuche de carga.
- El auricular izquierdo o derecho se puede usar independientemente para música y llamadas. Simplemente elija uno y sáquelo del estuche para conectarlo.
- Elegir el tamaño correcto de almohadilla mejorará considerablemente la calidad del audio gracias al sellado adecuado del controlador del altavoz. Pruebe todas las almohadillas para determinar cuál ofrece los mejores resultados.

ENCENDIDO/APAGADO DE LOS AURICULARES



- Para apagar los auriculares cuando no estén en el estuche de carga, mantenga pulsada la zona táctil durante 8 segundos.
- Para encender los auriculares cuando no estén en el estuche de carga, mantenga pulsada la zona táctil durante 3 segundos.

Nota: Si se sacan los auriculares del estuche de carga sin ninguna conexión Bluetooth, se apagará automáticamente después de 5 minutos.

CARGA DE LOS AURICULARES

Al colocar los auriculares en el estuche de carga, se recargarán automáticamente.

Cuando estén completamente cargados, se mostrará el 100 % en la parte superior de la pantalla.

**RECARGA DEL ESTUCHE DE CARGA**

Para recargar el estuche de carga, conecta el cable USB-C al puerto USB de una computadora o usa un adaptador de corriente USB a CA (no incluido) que proporcione un mínimo de 5 V CC y 500 mA. Al cargar el estuche, la pantalla digital de carga se mostrará en la parte superior de la pantalla. Continuará cargándose hasta alcanzar el 100 % de carga completa.

QFX HP-E120 CONTROLES TÁCTILES

CONTROLES TÁCTILES DE LOS AURICULARES IZQUIERDO Y DERECHO

SENSOR
TÁCTIL
IZQUIERDO



SENSOR
TÁCTIL
DERECHO

Controles del sensor táctil del auricular izquierdo

REPRODUCIR/PAUSAR: Un solo toque

SUBIR/BAJAR VOLUMEN: Desliza el dedo hacia abajo en el área de control del sensor de los auriculares.

SIGUIENTE PISTA: Doble toque

PISTA ANTERIOR: Triple toque

RESPUESTA: Un solo toque

COLGAR: Un solo toque

RECHAZAR LLAMADAS ENTRANTES: Mantenga pulsado durante 2 segundos

ACTIVAR/DESACTIVAR ANC/TRANSPARENCIA /MODO ANC: Mantenga pulsado durante 3 segundos y suelte.

Controles del sensor táctil del auricular derecho

REPRODUCIR/PAUSAR: Un solo toque

SUBIR/BAJAR VOLUMEN: Desliza el dedo hacia abajo en el área de control del sensor de los auriculares.

SIGUIENTE PISTA: Doble toque

PISTA ANTERIOR: Triple toque

RESPUESTA: Un solo toque

COLGAR: Un solo toque

RECHAZAR LLAMADAS ENTRANTES: Mantenga pulsado durante 2 segundos

ASISTENTE DE VOZ: Mantenga pulsado durante 3 segundos y suelte

PRIMERA CONEXIÓN A BLUETOOTH

1. Retire los auriculares del estuche de carga. Se oirá un sonido de encendido. En su dispositivo con Bluetooth, acceda a la configuración de Bluetooth y seleccione "QFX HP-E120" en la lista para conectarlos.
2. Tras la configuración inicial, los auriculares se conectarán automáticamente en el futuro.

FUNCIÓN DE PANTALLA DEL ESTUCHE DE CARGA:

- Reproducir/Pausa/Siguiente/Música anterior
- Visualización de la letra (haga clic en la letra para acceder a la pantalla completa; deslice hacia la derecha para salir de la pantalla completa)
- Opciones del ecualizador
- Opciones de ambiente (normal/ANC/transparencia)
- Opciones de audio espacial
- Subir/bajar volumen
- Opciones de brillo
- Encuentra auriculares TWS L/R
- Control remoto de la cámara
- Fondo de pantalla
- Temporizador de parada (tiempo configurable: 5 min, 10 min, 15 min, 20 min, 25 min, 30 min y 60 min)
- Opciones de toque para activar
- Opciones de idioma

PRESUPUESTO:


- Versión de Bluetooth: 5.4
- Protocolo: HFP/HSP/A2DP/AVRCP/AVDTP/SP-P/RFCOMM/HID/AVDTP/SPP/RFCOMM/HID
- Conjunto de chips Bluetooth: AB5632F
- Estuche de carga: 300 mAh
- Auriculares: 30 mAh
- Tiempo de juego: 2-4 horas
- Tiempo de carga: 2-3H
- Estuche de carga: 60,5 x 23 x 45,2 mm
- Auriculares: 25 x 18 x 33 mm
- Peso neto: 64 g
- Puerto de carga: Tipo-C
- Potencia de entrada: 5 V/500 mA
- Efecto de reducción de ruido: 25 dB (±3 dB)

PRECAUCIÓN

- No guarde los auriculares ni el estuche en ambientes con calor, frío o humedad extremos.
- Seque completamente los auriculares antes de colocarlos en el estuche de carga.
- Para garantizar un funcionamiento correcto, no aplaste ni comprima los auriculares ni las almohadillas de gel.
- Los auriculares pueden aumentar la intensidad del sonido. Mantenga el volumen bajo si los usa durante períodos prolongados.

Casque HP-E120 ANC avec écran tactile SANS FIL + ÉTUI DE CHARGE

Merci d'avoir acheté les écouteurs sans fil QFX HP-E120 ANC Screen et l'étui de chargement. Lisez ces instructions pour une utilisation et un entretien appropriés de ce produit.



Étui de chargement : lorsque vous ne les utilisez pas, rangez les écouteurs dans l'étui pour les recharger.

Capteur tactile : chaque écouteur contrôle le volume, les appels et la lecture de musique.


Bouton d'alimentation/réinitialisation : appuyez pour éclairer l'écran du boîtier de charge. Avec le couvercle du boîtier fermé, appuyez sur le bouton et maintenez-le enfoncé pendant 5 secondes pour allumer/éteindre le boîtier, puis appuyez à nouveau pour le redémarrer. Avec le couvercle du boîtier ouvert, appuyez sur le bouton et maintenez-le enfoncé pendant 5 secondes pour vérifier si les écouteurs sont connectés.

Port de charge : il s'agit du port de charge du boîtier. Connectez le câble USB-C pour charger le boîtier.

Trou pour cordon : Trou pour utiliser le cordon.

CONTENU DE LA BOÎTE

Casques



Étui de chargement




Cordon



Conseils pour les oreilles



Câble de charge



Manuel



MISE EN PLACE DES EMBOUTS AURICULAIRES EN GEL SOUPLE

Le paquet comprend un ensemble de bouchons d'oreilles en gel souple de tailles petite, moyenne et grande.

Sélectionnez la taille qui convient le mieux et offre le plus grand confort pour un port prolongé.

**CONSEIL DE
L'OREILLE**

Placez l'écouteur dans votre conduit auditif, puis tournez-le et ajustez-le pour un ajustement optimal.

**CONSEILS RAPIDES POUR ASSURER UN BON FONCTIONNEMENT**

- Assurez-vous que les écouteurs sont complètement secs avant de les placer dans l'étui de chargement.
- L'écouteur gauche ou droit peut être utilisé indépendamment pour la musique et les appels. Il suffit d'en prendre un et de le sortir de l'étui pour le connecter.
- Choisir la bonne taille de coussinet d'oreille améliorera considérablement la qualité audio en scellant correctement le haut-parleur. Essayez tous les pads pour déterminer lequel donne les meilleurs résultats.

Allumer/éteindre le casque

- Pour éteindre les écouteurs lorsqu'ils ne sont pas dans l'étui de chargement, maintenez la zone tactile enfoncée pendant 8 secondes.
- Pour allumer les écouteurs lorsqu'ils ne sont pas dans l'étui de chargement, maintenez la zone tactile enfoncée pendant 3 secondes.



Remarque : si les écouteurs sont retirés de l'étui de chargement sans aucune connexion Bluetooth, ils s'éteindront automatiquement après 5

CHARGER LES ÉCOUTEURS

Lorsque vous placez les écouteurs dans l'étui de chargement, ils se rechargent automatiquement.

Une fois complètement chargée, 100 % s'affiche en haut de l'écran.

Lorsque la batterie est inférieure à 3,3 V, vous entendrez un avertissement.

**RECHARGER LE BOÎTIER DE CHARGE**

Pour recharger le boîtier de charge, connectez le câble USB-C au port USB d'un ordinateur ou utilisez un adaptateur secteur USB vers secteur (non inclus) qui fournit un minimum de 5 V CC et 500 mA. Lors du chargement du boîtier, l'écran de chargement numérique s'affiche en haut de l'écran. Il continuera à charger jusqu'à ce qu'il atteigne 100 % de charge complète.

COMMANDES TACTILES POUR ÉCOUTEURS GAUCHE ET DROIT

**CAPTEUR
TACTILE
GAUCHE**



**CAPTEUR
TACTILE
DROITE**

Commandes du capteur tactile de l'écouteur gauche

Commandes du capteur tactile de l'écouteur droit

LECTURE/PAUSE : Touche unique

VOLUME HAUT/BAS : faites glisser votre doigt vers le bas sur la zone de contrôle du capteur du casque.

PISTE SUIVANTE : Double tap

PISTE PRÉCÉDENTE : Triple Tap

RÉPONSE : Une seule touche

RACCROCHER : Une touche

REFUSER LES APPELS ENTRANTS :
Appuyez et maintenez pendant 2 secondes

Activer/désactiver l'ANC/la transparence
/MODE ANC :

Maintenez la position pendant 3 secondes et relâchez.

LECTURE/PAUSE : Touche unique

VOLUME HAUT/BAS : faites glisser votre doigt vers le bas sur la zone de contrôle du capteur du casque.

PISTE SUIVANTE : Double tap

PISTE PRÉCÉDENTE : Triple Tap

RÉPONSE : Une seule touche

RACCROCHER : Une touche

REFUSER LES APPELS ENTRANTS :
Appuyez et maintenez pendant 2 secondes

ASSISTANT VOCAL :
Appuyez et maintenez pendant 3 secondes,
puis relâchez

PREMIÈRE CONNEXION BLUETOOTH

1. Retirez les écouteurs de l'étui de chargement. Vous entendrez un son de mise sous tension. Sur votre appareil compatible Bluetooth, accédez aux paramètres Bluetooth et sélectionnez « QFX HP-E120 » dans la liste pour vous connecter.
2. Après la configuration initiale, les écouteurs se connecteront automatiquement à l'avenir.

FONCTION D'AFFICHAGE DU BOÎTIER DE CHARGE :

- Lecture/Pause/Musique suivante/précédente
- Affichage des paroles (cliquez sur les paroles pour entrer en plein écran ; balayez vers la droite pour quitter le plein écran)
- Options d'égaliseur
- Options ambiantes (normal/ANC/transparence)
- Options audio spatiales
- -Volume haut/bas
- Options de luminosité
- Trouver des écouteurs TWS L/R
- Contrôle de la caméra à distance
- Papier peint
- Minuterie d'arrêt (temps réglable : 5 min, 10 min, 15 min, 20 min, 25 min, 30 min et 60 min)
- Appuyez sur Options pour activer
- Options de langue

CARACTÉRISTIQUES:

- Version Bluetooth : 5.4
- Protocole : HFP/HSP/A2DP/AVRCP/AVDTP/SP-P/RFCOMM/HID/AVDTP/SPP/RFCOMM/HID
- Ensemble de puces Bluetooth : AB5632F
- Boîtier de charge : 300 mAh
- Auriculaires: 30 mAh
- Casque : 30 mAh
- Temps de charge : 2-3H
- Boîtier de charge : 60,5 x 23 x 2 x 45,2 mm
- Casque : 25 x 18 x 33 mm
- Poids net : 64 g
- Port de charge : Type-C
- Puissance d'entrée : 5 V/500 mA
- Effet de réduction du bruit : 25 dB (±3 dB)

PRUDENCE

- Ne stockez pas les écouteurs ou l'étui dans des conditions de chaleur, de froid ou d'humidité extrêmes.
- Séchez complètement les écouteurs avant de les placer dans l'étui de chargement.
- Pour garantir un bon fonctionnement, n'écrasez pas et ne compressez pas les écouteurs ou les coussinets en gel.
- Les écouteurs peuvent augmenter l'intensité du son. Gardez le volume bas si vous les utilisez pendant de longues périodes.



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA® , Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

 support@qfxusa.com
 (800) 864-CLUB (2582) or (323) 864-6900
 qfxusa.com
 **Hours of Operation: Monday - Friday, 9am - 5pm PST**

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025 ©

THANK YOU.

QFX Where the Party Begins!

We would love to hear about your HP-E120 journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

