

PBX-288



WHERE THE PARTY BEGINS™



INSTRUCTION MANUAL

⚠ WARNING! ⚠

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN

To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers or under extreme weather conditions. Clean only with a dry cloth. Users should exhibit extra safety when the WARNING or CAUTION symbol appears in this instruction manual and follow all precautions as they are stated.

⚠ ¡ADVERTENCIA! ⚠

PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO quite la cubierta de este altavoz, no hay partes reparables por el usuario adentro. Remitir todo servicio a un técnico calificado

Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia ni a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor o bajo condiciones climáticas extremas. Limpiar solamente con un paño seco. Los usuarios deben mostrar una seguridad adicional cuando aparece el símbolo de ADVERTENCIA o PRECAUCIÓN en este manual de instrucciones y seguir todas las precauciones tal como se indican.

PBX-288 GUIDE / GUÍA



1. **MIC IN:** Microphone interface
2. **MODE:** Short press: Mode switch button, BT / USB / TF / FM switching; Press and hold: To enable or disable the TWS function in BT mode. Light mode switch key.
3. **FM:** FM mode: Short press this key to search for stations. Other modes: Short press this key to pause/play.
4. **Previous:** Short press: previous song; Long press: Volume -.
5. **Next:** Short press: Next track; Long press: Volume +.
6. **POWER:** Power slide ON/OFF.
7. **CHARGING PORT:** DC 5V Type-C charging port.
8. **TF CARD INPUT:** TF interface
9. **USB INPUT:** USB interface
10. **AUX:** Audio interface

1. **MIC IN:** Interfaz de micrófono
2. **MODE:** Pulsación corta: botón de cambio de modo, conmutación BT/USB/TF/FM; Mantenga presionado: para habilitar o deshabilitar la función TWS en modo BT. Tecla de cambio de modo de luz.
3. **FM:** Modo FM: presione brevemente esta tecla para buscar estaciones. Otros modos: presione brevemente esta tecla para pausar/reproducir.
4. **Previous:** Pulsación breve: canción anterior; Pulsación larga: Volumen -.
5. **Next:** Pulsación breve: Pista siguiente; Pulsación larga: Volumen +.
6. **ENCENDIDO:** Encendido/Apagado deslizante.
7. **PUERTO DE CARGA:** Puerto de carga DC 5V tipo C.
8. **ENTRADA DE TARJETA TF:** interfaz TF
9. **ENTRADA USB:** interfaz USB
10. **AUX:** Audio interface

Bluetooth

Step 1: Turn on the audio power switch and prompt the audio to turn on, which is BT mode;

Step 2: Then open BT device Settings, turn on BT, search for BT, select speaker BT and click connect.

Tip: When the BT connection is successful, there will be a prompt sound. When the speaker is used again, the BT between the speaker and the smart device will be automatically connected: After the BT connection is successful, it will be automatically disconnected when the effective distance is exceeded. When the effective distance is returned, the BT audio and smart devices will be connected again.

Bluetooth

Paso 1: Encienda el interruptor de alimentación de audio y solicite que se encienda el audio, que es el modo BT; Paso 2: Luego abra la Configuración del dispositivo BT, active BT, busque BT, seleccione el altavoz BT y haga clic en conectar.

Consejo: Cuando la conexión BT se realice correctamente, se escuchará un sonido de aviso. Cuando se vuelva a utilizar el altavoz, el BT entre el altavoz y el dispositivo inteligente se conectará automáticamente: una vez que la conexión BT se realice correctamente, se desconectará automáticamente cuando se exceda la distancia efectiva. Cuando se recupere la distancia efectiva, el audio BT y los dispositivos inteligentes se conectarán nuevamente.

True Wireless Stereo (TWS)

Step 1: Turn on two speakers of the same model at the same time and enter the BT mode;

Step 2: Long press the MODE key of one stereo. At this time, the system automatically searches for another stereo to connect to.

Tip: After the connection is successful, a prompt tone is played, indicating that the two audio systems are successfully paired, and are automatically converted to the left and right channels of the audio system to play music.

- a. This function can only be used if two speakers of the same model are turned on.
 - b. The machine has not BT connected to any device before TWS pairing.
 - c. Hold down MODE on one of the TWS to disconnect the TWS.
 - d. The audio will remember TWS pairing, and automatically connect with the original audio pair after starting up.
 - e. In the interconnection state, if one stereo is turned off, the other one is turned off at the same time.
-

True Wireless Stereo (TWS)

Paso 1: Encienda dos parlantes del mismo modelo al mismo tiempo e ingrese al modo BT;

Paso 2: Mantenga presionada la tecla MODE de un estéreo. En este momento, el sistema busca automáticamente otro estéreo al que conectarse.

Consejo: Una vez que la conexión se haya realizado correctamente, se reproducirá un tono que indica que los dos sistemas de audio se emparejaron correctamente y se convierten automáticamente a los canales izquierdo y derecho del sistema de audio para reproducir música.

- a. Esta función sólo se puede utilizar si se encienden dos altavoces del mismo modelo.
- b. La máquina no tiene BT conectado a ningún dispositivo antes del emparejamiento TWS.
- c. Mantenga presionado MODE en uno de los TWS para desconectar el TWS.
- d. El audio recordará el emparejamiento TWS y se conectará automáticamente con el par de audio original después del inicio.
- mi. En el estado de interconexión, si un estéreo está apagado, el otro se apaga al mismo tiempo.



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

 support@qfxusa.com
 (800) 864-CLUB (2582) or (323) 864-6900
 qfxusa.com
 Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased **will fall under**, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX **will not** provide any return or refund to any customer for merchandise and **will only** honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025 ©


1-800-864-2582
Mon-Fri 9AM - 5PM (PST)


support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)



THANK YOU.

QFX Wher the Party Begins!

We would love to hear about your PBX-288 Journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

