


HP-E80



INSTRUCTION MANUAL



Place earbud comfortably onto ear.


Your earbuds are identical and have no fixed “Left” or “Right” marking. When placed in the charging case, the case automatically assigns each earbud as the left or right channel.



This means either earbud can be used in either ear, and they will always charge correctly in any slot.

Recharging the Charging Case

To recharge the charging case, connect the USB-C cable to a USB power source that provides 5V, 300mA minimum power (see connection below): When charging the case, the battery level indicator on the display will show the percentage of charging level up to 100% full charge.



How to Use Your QFX HP-E80 Earbuds

Turning On the Earbuds:

Option 1: Take the earbud out of the charging case — it will turn on automatically.

Option 2: If the earbud is not in the case, tap and hold the touchpad for 5 seconds to turn it on manually.

Turning Off the Earbuds:

Option 1: Put the earbud back into the charging case — it will turn off automatically and start recharging.

Option 2: Press and hold the touchpad to turn it off manually.

Pairing with Your Phone:

Enable Bluetooth on your phone.

1. Look for “QFX HP-E80” in the Bluetooth device list and select it to pair.
2. Once connected, you’re ready to listen to music.
3. Next time you use the earbuds, they will automatically connect to each other and to your phone (as long as Bluetooth is turned on) — no need to pair them again.

Music Functions

- **Pause:** Tap the touch pad on either earbud and it will pause music.
- **Play:** Tap the touch pad on either earbud to resume music.

As the earbuds are identical and have no fixed "Left" and "right", on Music Functions

- - **Increase / Decrease Volume:** Tap the right/left earbud three times.
- - **Previous/ Next Track:** Tap the right/left earbuds twice.

Handsfree Functions

- Tap any earbud to answer a call and tap again to hang-up the call.
- Tap and hold either earbud to reject an incoming call.

MICRÓFONO

PANEL TÁCTIL

PANTALLA DE
VISUALIZACIÓN

ALTAVOZ

INDICADOR LED

PUERTO
DE CARGA

Coloque el
auricular
cómodamente
en la oreja.

Tus auriculares no tienen lado fijo. El estuche asigna automáticamente el canal izquierdo o derecho al cargarlos.



Puedes usar cualquier auricular en cualquier oído;
siempre se cargarán bien.

Recarga del estuche de carga

Para recargar el estuche de carga, conecte el cable USB-C a una fuente de alimentación USB que proporcione una potencia mínima de 5 V y 300 mA (ver la conexión a continuación): Al cargar el estuche, el indicador de nivel de batería en la pantalla mostrará el porcentaje de carga hasta el 100 %.



Cómo usar los auriculares QFX HP-E80

Encendido de los auriculares:

Opción 1: Saca el auricular del estuche de carga; se encenderá automáticamente.

Opción 2: Si el auricular no está en el estuche, mantén pulsado el panel táctil durante 5 segundos para encenderlo manualmente.

Cómo apagar los auriculares:

Opción 1: Vuelva a colocar el auricular en el estuche de carga; se apagará automáticamente y comenzará a recargarse.

Opción 2: Mantenga presionado el panel táctil para apagarlo manualmente.

Emparejamiento con su teléfono:

Habilite el Bluetooth en su teléfono.

1. Busca "QFX HP-E80" en la lista de dispositivos Bluetooth y selecciónalo para emparejarlos.
2. Una vez conectados, podrás escuchar música.
3. La próxima vez que uses los auriculares, se conectarán automáticamente entre sí y a tu teléfono (siempre que el Bluetooth esté activado); no es necesario volver a emparejarlos.

Funciones de la música


- **Pausa:** Toca el panel táctil de cualquiera de los auriculares para pausar la música.
- **Reproducir:** Toca el panel táctil de cualquiera de los auriculares para reanudar la música.

Como los auriculares son idénticos y no tienen botones fijos para "izquierdo" y "derecho", en las funciones de música:

- **- Subir/Bajar volumen:** Toca el auricular derecho/izquierdo tres veces.
- **- Pista anterior/siguiente:** Toca el auricular derecho/izquierdo dos veces.

Funciones de manos libres

- Toca cualquier auricular para responder una llamada y vuelve a tocarlo para colgar.
- Mantén pulsado cualquiera de los auriculares para rechazar una llamada entrante.



Placez l'écouteur confortablement sur l'oreille.

Vos écouteurs n'ont pas de côté fixe. L'étui attribue automatiquement le canal gauche ou droit lors de la charge.



Vous pouvez utiliser l'un ou l'autre écouteur dans l'une ou l'autre oreille ; ils se chargeront toujours bien.

Recharger le boîtier de charge

Pour recharger le boîtier de charge, connectez le câble USB-C à une source d'alimentation USB fournissant une puissance minimale de 5 V et 3001mA (voir connexion ci-dessous) : Lorsque vous chargez le boîtier, l'indicateur de niveau de batterie sur l'écran affiche le pourcentage de charge jusqu'à 100 %.



Comment utiliser vos écouteurs QFX HP-E80

Mise en marche des écouteurs :

Option 1 : Retirez l'écouteur de l'étui de chargement ; il s'allumera automatiquement.

Option 2 : Si l'écouteur n'est pas dans l'étui, appuyez longuement sur le pavé tactile pendant 5 secondes pour l'allumer manuellement.

Éteindre les écouteurs :

Option 1 : Remettez l'écouteur dans l'étui de charge ; il s'éteindra automatiquement et commencera à se recharger.

Option 2 : Appuyez longuement sur le pavé tactile pour l'éteindre manuellement.

Couplage avec votre téléphone :

Activez le Bluetooth sur votre téléphone.

1. Recherchez « QFX HP-E80 » dans la liste des appareils Bluetooth et sélectionnez-le pour l'appairer.
2. Une fois connecté, vous êtes prêt à écouter de la musique.
3. La prochaine fois que vous utiliserez les écouteurs, ils se connecteront automatiquement entre eux et à votre téléphone (à condition que le Bluetooth soit activé) ; inutile de les appairer à nouveau.

Fonctions musicales

- **Pause** : Appuyez sur le pavé tactile de l'un des écouteurs pour mettre la musique en pause.
- **Lecture** : Appuyez sur le pavé tactile de l'un des écouteurs pour reprendre la musique.

Les écouteurs étant identiques et n'ayant pas de « gauche » et « droite » fixes, dans les fonctions musicales,

- - Augmenter/Diminuer le volume : appuyez trois fois sur l'écouteur droit/gauche.
- - Piste précédente/suivante : appuyez deux fois sur l'écouteur droit/gauche.

Fonctions mains libres

- Appuyez sur n'importe quel écouteur pour répondre à un appel, puis appuyez à nouveau pour raccrocher.
- Appuyez longuement sur l'un des écouteurs pour rejeter un appel entrant.



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth Speakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year
Stand Fans	\$20.00	1 Year	1 Year
Portable Rechargeable Fans	\$15.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025 ©



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

THANK YOU.

QFX Where the Party Begins!

We would love to hear about your **HP-E80** journey!

Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

