

# QFX<sup>®</sup>

WHERE THE PARTY BEGINS<sup>™</sup>



## INSTRUCTION MANUAL



## WARNING!



TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN

To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers or under extreme weather conditions. Clean only with a dry cloth. Users should exhibit extra safety when the WARNING or CAUTION symbol appears in this instruction manual and follow all precautions as they are stated.






## ¡ADVERTENCIA!



PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO quite la cubierta de este altavoz. No hay partes reparables por el usuario adentro. Remítir todo servicio a un técnico calificado

Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia ni a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor o bajo condiciones climáticas extremas. Limpiar solamente con un paño seco. Los usuarios deben mostrar una seguridad adicional cuando aparece el símbolo de ADVERTENCIA o PRECAUCIÓN en este manual de instrucciones y seguir todas las precauciones tal como se indican.





## RETRO-38BT Battery

1. Open the battery box in the indicated direction and insert 2 pcs rechargeable batteries, and cover the battery door properly.
  2. When you don't want to use the radio for a long time, please take out the batteries from the unit.
- 

## Batería RETRO-38BT

1. Abra la caja de la batería en la dirección indicada e inserte 2 baterías recargables y cubra la puerta de la batería correctamente.
  2. Cuando no vaya a utilizar la radio durante un periodo prolongado, retire las baterías de la unidad.
- 

## Batterie RETRO-38BT

1. Ouvrez le compartiment à piles dans le sens indiqué, insérez 2 piles rechargeables et refermez correctement le couvercle.
  2. Si vous prévoyez de ne pas utiliser la radio pendant une longue période, veuillez retirer les piles de l'appareil.
- 

## RECEPTION

1. Push the function switch to the "RADIO" position, and select the AM/SW or FM band switch.
  2. Adjust the volume knob to the appropriate position.
  3. Adjust the channel selection button "TUNING" to select your favorite program. If the signal reception is weak, please adjust the position and direction of the telescopic antenna to achieve better reception effect.
- 

## RECEPCIÓN

1. Coloque el interruptor de funciones en la posición «RADIO» y seleccione el interruptor de banda AM/SW o FM.
  2. Ajuste el botón de volumen a la posición adecuada.
  3. Ajuste el botón de selección de canales «TUNING» para seleccionar su programa favorito. Si la recepción de la señal es débil, ajuste la posición y la dirección de la antena telescópica para lograr una mejor recepción.
- 

## RÉCEPTION

1. Placez le sélecteur de fonction sur la position « RADIO » et sélectionnez la bande AM/SW ou FM.
2. Réglez le bouton de volume à la position appropriée.
3. Réglez le bouton de sélection des chaînes « TUNING » pour sélectionner votre programme préféré. Si la réception du signal est faible, veuillez régler la position et l'orientation de l'antenne télescopique afin d'obtenir une meilleure réception.

## **RECORDING**

### **MIC RECORDING TO TAPE**

1. Set the function switch to "TAPE".
2. Insert cassette tape on desired side.
3. Press "PLAY" & "REC" together to record from the built-in mic.

### **USB/MP3.BT RECORD TO TAPE**

1. Set the function switch to "MP3. BT".
2. Insert cassette tape on desired side.
3. Press "PLAY" & "REC" together to record from USB/MP3. BT.

### **RADIO RECORDING TO TAPE**

1. Set the function switch to "RADIO".
  2. Insert cassette tape on desired side.
  3. Press "PLAY" & "REC" together to record from the radio station.
- 

## **GRABACIÓN**

### **GRABACIÓN CON MICRÓFONO EN CASSETTE**

1. Coloque el selector de funciones en «TAPE».
2. Inserte la cinta de cassette en el lado deseado.
3. Pulse «PLAY» y «REC» al mismo tiempo para grabar desde el micrófono integrado.

### **GRABACIÓN USB/MP3.BT EN CASSETTE**

1. Coloque el selector de funciones en «MP3. BT».
2. Inserte la cinta de casete en el lado deseado.
3. Pulse «PLAY» y «REC» al mismo tiempo para grabar desde USB/MP3. BT.

### **GRABACIÓN DE RADIO EN CINTAS**

1. Coloque el selector de funciones en «RADIO».
  2. Inserte la cinta de casete en el lado deseado.
  3. Pulse «PLAY» y «REC» al mismo tiempo para grabar desde la emisora de radio.
- 

## **GRABACIÓN**

### **GRABACIÓN CON MICRÓFONO EN CASSETTE**

1. Coloque el selector de funciones en «TAPE».
2. Inserte la cinta de cassette en el lado deseado.
3. Pulse «PLAY» y «REC» al mismo tiempo para grabar desde el micrófono integrado.

### **GRABACIÓN USB/MP3.BT EN CASSETTE**

1. Coloque el selector de funciones en «MP3. BT».
2. Inserte la cinta de casete en el lado deseado.
3. Pulse «PLAY» y «REC» al mismo tiempo para grabar desde USB/MP3. BT.



## GRABACIÓN DE RADIO EN CINTAS

1. Coloque el selector de funciones en «RADIO».
2. Inserte la cinta de casete en el lado deseado.
3. Pulse «PLAY» y «REC» al mismo tiempo para grabar desde la emisora de radio.

## BLUETOOTH FUNCTION

Turn on the radio bluetooth and the bluetooth of cellphone or other mobile devices with bluetooth function, start to search a bluetooth named "QFX RETRO-38BT" and pair with it. After successful pairing, it will beep. Now cellphone or other mobile device can play the MP3 through bluetooth on radio. You can select play and pause the MP3 by pressing NEXT/PREV/PLAY buttons on radio or cellphone or other mobile devices. If you want to stop using bluetooth function just need to turn off the bluetooth in cellphone or other mobile devices. If want to use it again, only need to open the bluetooth in cellphone or other mobile devices again and pair with "QFX RETRO-38BT" automatically.

## FUNCIÓN BLUETOOTH

Encienda el Bluetooth de la radio y el Bluetooth del teléfono móvil u otros dispositivos móviles con función Bluetooth, busque un Bluetooth llamado «QFX RETRO-38BT» y empareje con él. Una vez emparejado correctamente, se oirá un pitido. Ahora el teléfono móvil u otro dispositivo móvil puede reproducir el MP3 a través del Bluetooth de la radio. Puede seleccionar la reproducción y pausar el MP3 pulsando los botones NEXT/PREV/PLAY de la radio, el teléfono móvil u otros dispositivos móviles. Si desea dejar de utilizar la función Bluetooth, solo tiene que desactivar el Bluetooth en el teléfono móvil u otros dispositivos móviles. Si desea volver a utilizarlo, solo tiene que volver a activar el Bluetooth en el teléfono móvil u otros dispositivos móviles y emparejarse automáticamente con «QFX RETRO-38BT».

## FONCTION BLUETOOTH

Allumez le Bluetooth de la radio et celui de votre téléphone portable ou autre appareil mobile équipé de la fonction Bluetooth, recherchez un appareil Bluetooth nommé « QFX RETRO-38BT » et apparez-le. Une fois l'appairage réussi, un bip retentira. Votre téléphone portable ou autre appareil mobile pourra alors lire les fichiers MP3 via le Bluetooth de la radio. Vous pouvez sélectionner la lecture et la pause du MP3 en appuyant sur les boutons NEXT/PREV/PLAY de la radio, du téléphone portable ou d'autres appareils mobiles. Si vous souhaitez arrêter d'utiliser la fonction Bluetooth, il vous suffit de désactiver le Bluetooth sur votre téléphone portable ou autre appareil mobile. Si vous souhaitez l'utiliser à nouveau, il vous suffit de réactiver le Bluetooth sur votre téléphone portable ou autre appareil mobile et de le coupler automatiquement avec « QFX RETRO-38BT ».



## LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at [www.qfxusa.com](http://www.qfxusa.com) for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.





Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

**QFX USA®, Inc.**

RMA Processing  
 Customer Support Department  
 2957 E. 46th Street | Vernon, CA 90058

 [support@qfxusa.com](mailto:support@qfxusa.com)  
 (800) 864-CLUB (2582) or (323) 864-6900  
 [qfxusa.com](http://qfxusa.com)  
 Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2026 ©



1-800-864-2582  
 Mon-Fri 9AM - 5PM (PST)



[support@qfxusa.com](mailto:support@qfxusa.com)  
 Mon-Fri 9AM - 5PM (PST)



[www.qfxusa.com](http://www.qfxusa.com)

# THANK YOU.

**QFX** When the Party Begins!

We would love to hear about your RETRO-38BT Journey!  
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

