

BT-2005



INSTRUCTION MANUAL



WARNING!



TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO A QUALIFIED TECHNICIAN

To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers or under extreme weather conditions. Clean only with a dry cloth. Users should exhibit extra safety when the WARNING or CAUTION symbol appears in this instruction manual and follow all precautions as they are stated.



¡ADVERTENCIA!



PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO quite la cubierta de este altavoz. No hay partes reparables por el usuario adentro. Remitir todo servicio a un técnico calificado

Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia ni a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor o bajo condiciones climáticas extremas. Limpiar solamente con un paño seco. Los usuarios deben mostrar una seguridad adicional cuando aparece el símbolo de ADVERTENCIA o PRECAUCIÓN en este manual de instrucciones y seguir todas las precauciones tal como se indican.



AVERTISSEMENT !



POUR RÉDUIRE LE RISQUE DE CHOC ÉLECTRIQUE, NE RETIREZ PAS LE CAPOT DE CET ENCEINTE. IL N'Y A AUCUNE PARTIE RÉPARABLE PAR L'UTILISATEUR À L'INTÉRIEUR. CONFIEZ TOUTE RÉPARATION À UN TECHNICIEN QUALIFIÉ.

Pour éviter les incendies ou les chocs électriques, n'exposez pas cet appareil à la pluie ou à l'humidité. Ne stockez ni n'utilisez ce produit à proximité de liquides, de sources de chaleur comme des radiateurs, des registres de chaleur ou dans des conditions climatiques extrêmes. Nettoyez uniquement avec un chiffon sec. Les utilisateurs doivent faire preuve de prudence lorsqu'ils voient le symbole d'AVERTISSEMENT ou de PRECAUTION dans ce manuel d'instructions et suivre toutes les précautions telles qu'indiquées.

BATTERY

The BT-2005 is a rechargeable battery powered speaker. Be sure that you have completely charged the battery prior to first use to maximize the battery's lifespan. Once the USB-C cable is connected to a power source, it will automatically begin charging (8 hours to fully charge the battery) Even if the battery power is low, it will power on when connected to a power source. When the battery is charging, the battery indicator light is red. When the battery charge fully, the indicator light will turn off. Upon completion of the charging, please disconnect the unit. When not in use, the speaker should always be set OFF to prevent the unit from draining the battery. When the unit is not used for prolonged periods of time, the battery will gradually lose its power. It is recommended to fully charge the battery at least every 60 days. When battery is completely empty, the unit cannot perform at 100% of the volume when immediately connected to power source. It is suggested to charge for a while before using with 100% volume. The unit may work and charge with lower-level volume. The volume level would be increased as the unit is charging.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

FCC ID: 2A4V9-9696

FCC Statement


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



1. **⏻ M (POWER/MODE)** : Press and hold to power ON or OFF. Press to toggle between modes (BT, PH, USB/TF input, FM radio, AUX input).
2. **⏮/⏭** : Press and hold to lower volume. Press to listen to previous radio station or MP3 song.
3. **▶⏮ (PLAY/PAUSE)**: Press ▶⏮ to play or pause music while in MP3 mode. In FM mode, press and hold ▶⏮ for auto-radio channel search. This operation will scan all FM stations and save them into memory. The scan procedure may take several minutes and must not be interrupted. In BT mode, press ▶⏮ to answer a phone call or press and hold ▶⏮ to hang up the call. In BT mode, press and hold ▶⏮ to redial last telephone number.
4. **▶⏭/⏮** : Press and hold to increase volume. Press to listen to next radio station or MP3 song. Double press to turn LED front headlights and rear lights ON or OFF.
5. **TF**: Insert a TF card with MP3 formatted music tracks
6. **USB**: Insert a USB drive with MP3 formatted music tracks.
7. **USB-C**: USB-C port for 5V charging. Front LED lights will flash while charging.

Internal Battery Recharging

Plug in the USB cable to a 5VDC, 1 amp minimum source to recharge the internal battery. While charging, indicator light will be solid red color. Once the unit is fully charged, the indicator light will turn off.

Bluetooth Connection

Toggle MODE to select BT mode on the BT-2005. On your Bluetooth-enabled device, turn Bluetooth on, pair it to "QFX BT-2005" and enjoy Bluetooth music from your device.

Hands-Free Calls

When connected via Bluetooth, the BT-2005 can accept incoming phone calls. When you receive an incoming call, press the ▶⏮ button to receive the call and begin speaking with the person calling. To hang up the call, press and hold the ▶⏮ button.


True Wireless Stereo (TWS)

True Wireless Stereo (TWS) allows you connect two BT-2005 units together to play Bluetooth music in wirelessly in stereo. To set up TWS:

1. Push MODE button on both speakers until both speakers are in BT mode.
2. When both speakers are in BT mode, press ▶⏮ button twice on each unit. You will hear a beep. Next time you put both speakers in Bluetooth mode at the same time, both speakers will connect automatically.
3. On your Bluetooth-enabled device, turn Bluetooth ON and pair it to "QFX BT-2005". Enjoy True Wireless Stereo (TWS) sound from your phone or tablet via Bluetooth!

Caution

Do not disassemble, short circuit, or expose unit to fire or hot temperatures. Recycle battery according to local state and national regulations.



1. **⏻ / M (ENCENDIDO/MODO):** Mantén pulsado para encender o apagar. Pulsa para alternar entre los modos (BT, PH, entrada USB/TF, radio FM, entrada AUX).
2. **⏮ / ⏭:** Mantén pulsado para bajar el volumen. Pulsa para escuchar la emisora de radio o canción MP3 anterior.
3. **▶ || (REPRODUCIR/PAUSAR):** Pulsa ▶ || para reproducir o pausar la música en modo MP3. En modo FM, mantén pulsado ▶ || para la búsqueda automática de emisoras. Esta operación escaneará todas las emisoras FM y las guardará en la memoria. El proceso de escaneo puede tardar varios minutos y no debe interrumpirse. En modo BT, pulsa ▶ || para contestar una llamada o mantén pulsado ▶ || para colgar. En modo BT, mantén pulsado ▶ || para volver a marcar el último número.
4. **⏮ / ⏭:** Mantén pulsado para subir el volumen. Pulsa para escuchar la siguiente emisora de radio o canción MP3. Pulsa dos veces para encender o apagar los faros LED delanteros y traseros.
5. **TF:** Inserta una tarjeta TF con pistas de música en formato MP3.
6. **USB:** Inserta una unidad USB con pistas de música en formato MP3.
7. **USB-C:** Puerto USB-C para carga de 5 V. Los LED frontales parpadearán durante la carga.

Recarga de batería interna

Conecte el cable USB a una fuente de 5 VCC, 1 amperio mínimo para recargar la batería interna. Mientras se carga, la luz indicadora se venderá en color rojo. Una vez que la unidad esté completamente cargada, la luz indicadora se apagará.

Conexión Bluetooth

Cambie de MODO para seleccionar el modo BT en el BT-2005. En su dispositivo con Bluetooth, active Bluetooth, emparejelo con "QFX BT-2005" y disfrute de la música Bluetooth desde su dispositivo.

Llamadas manos libres

Cuando está conectado a través de Bluetooth, el BT-2005 puede aceptar llamadas telefónicas entrantes. Al recibir una llamada entrante, presione el botón ▶ || para contestar y comenzar a hablar con la persona que llama. Para colgar la llamada, mantenga presionado el botón ▶ ||.


True Wireless Stereo (TWS)

La tecnología True Wireless Stereo (TWS) le permite conectar dos unidades BT-2005 entre sí para reproducir música por Bluetooth de forma inalámbrica y en estéreo. Para configurar el TWS:

1. Presione el botón MODE en ambos altavoces hasta que ambos se encuentren en modo BT.
2. Una vez que ambos altavoces estén en modo BT, presione el botón ▶ || dos veces en cada unidad. Escuchará un pitido. La próxima vez que ponga ambos altavoces en modo Bluetooth simultáneamente, se conectarán de forma automática.
3. En su dispositivo compatible con Bluetooth, active la función Bluetooth y emparejelo con "QFX BT-2005". ¡Disfrute del sonido True Wireless Stereo (TWS) desde su teléfono o tableta a través de Bluetooth!

Precaución

No desmonte la unidad, no provoque cortocircuitos ni la exponga al fuego o a temperaturas elevadas. Recicle la batería de acuerdo con las normativas locales, estatales y nacionales vigentes.



1. **⏻ / M (MARCHE/ARRÊT/MODE)** : Appuyez longuement pour allumer ou éteindre l'appareil. Appuyez pour basculer entre les modes (BT, PH, entrée USB/TF, radio FM, entrée AUX).
2. **⏮ / ⏭** : Appuyez longuement pour baisser le volume. Appuyez pour écouter la station de radio ou le morceau MP3 précédent.
3. **▶ || (LECTURE/PAUSE)** : Appuyez sur ▶ || pour lire ou mettre en pause la musique en mode MP3. En mode FM, appuyez longuement sur ▶ || pour lancer la recherche automatique des stations. Cette opération analysera toutes les stations FM et les enregistrera. La recherche peut prendre plusieurs minutes et ne doit pas être interrompue. En mode BT, appuyez sur ▶ || pour répondre à un appel ou maintenez-le enfoncé pour raccrocher. En mode BT, maintenez ▶ || enfoncé pour rappeler le dernier numéro composé.
4. **⏮ / ⏭** : Appuyez longuement pour augmenter le volume. Appuyez pour écouter la station de radio ou le morceau MP3 suivant. Appuyez deux fois pour allumer ou éteindre les phares avant et les feux arrière à LED. Carte TF : Insérez une carte TF contenant des fichiers musicaux au format MP3.
5. **USB** : Insérez une clé USB contenant des fichiers musicaux au format MP3.
6. **USB-C** : Port USB-C pour la charge 5 V. Les voyants LED en façade clignotent pendant la charge.
7. **Écran LED** : Affiche les modes, le niveau de volume, la durée de lecture et les stations de radio.

Recharge de la batterie interne

Branchez le câble USB à une source d'alimentation de 5 V CC et 1 A minimum pour recharger la batterie interne. Pendant la charge, le voyant reste rouge. Une fois l'appareil complètement chargé, le voyant s'éteint.

Connexion Bluetooth

Sélectionnez le mode Bluetooth sur le BT-2005 en appuyant sur le bouton MODE. Sur votre appareil compatible Bluetooth, activez le Bluetooth, connectez-le au « QFX BT-2005 » et profitez de votre musique en Bluetooth.

Appels mains libres

Lorsqu'il est connecté via Bluetooth, le BT-2005 permet de prendre des appels téléphoniques entrants. Lorsque vous recevez un appel, appuyez sur le bouton ▶ || pour décrocher et commencer à converser avec votre interlocuteur. Pour raccrocher, appuyez longuement sur le bouton ▶ ||.

True Wireless Stereo (TWS)

La technologie True Wireless Stereo (TWS) vous permet de coupler deux unités BT-2005 afin de diffuser de la musique en stéréo et sans fil via Bluetooth. Pour configurer le mode TWS :

1. Appuyez sur le bouton MODE de chacune des deux enceintes jusqu'à ce qu'elles passent toutes deux en mode BT.
2. Une fois les deux enceintes en mode BT, appuyez deux fois sur le bouton ▶ || de chaque unité. Vous entendrez un signal sonore (bip). La prochaine fois que vous passerez simultanément les deux enceintes en mode Bluetooth, elles se connecteront automatiquement.
3. Sur votre appareil compatible Bluetooth, activez la fonction Bluetooth et jumelez-le avec « QFX BT-2005 ». Profitez d'un son True Wireless Stereo (TWS) depuis votre téléphone ou votre tablette via Bluetooth !

Mise en garde

Ne démontez pas l'appareil, ne provoquez pas de court-circuit et ne l'exposez ni au feu ni à des températures élevées. Veuillez recycler la batterie conformément aux réglementations locales, régionales et nationales en vigueur.



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the date stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(800) 864-CLUB (2582) or (323) 457-9900
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your prouuct or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth Speakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year
Stand Fans	\$20.00	1 Year	1 Year
Portable Rechargeable Fans	\$15.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2026 ©



1-800-864-2582
Mon-Fri 9AM - 5PM (PST)



support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)



www.qfxusa.com

THANK YOU.

QFX Where the Party Begins!

We would love to hear about your BT-2005 Journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

